

MT8815B/MT8820B Radio Communication Analyzer Operation Manual

Eighth Edition


**For safety and warning information, please read this manual before attempting to use the equipment.
Keep this manual with the equipment.**


ANRITSU CORPORATION


Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Ensure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following symbols may be used on all Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in this manual.

Symbols used in manual

DANGER  This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.

WARNING  This indicates a hazardous procedure that could result in serious injury or death if not performed properly.

CAUTION  This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manual

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates a warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MT8815B/MT8820B
Radio Communication Analyzer
Operation Manual

25 September 2006 (First Edition)
15 March 2010 (Eighth Edition)

Copyright © 2006-2010, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

For Safety



WARNING

1. ALWAYS refer to the operation manual when working near locations at which the alert mark shown on the left is attached. If the advice in the operation manual is not followed there is a risk of personal injury or reduced equipment performance. The alert mark shown on the left may also be used with other marks and descriptions to indicate other dangers.

2. IEC 61010 Standard

The IEC 61010 standard specifies four categories to ensure that an instrument is used only at locations where it is safe to make measurements. This instrument is designed for measurement category I (CAT I). DO NOT use this instrument at locations specified as category II, III, or IV as defined below.

Measurement category I (CAT I):

Secondary circuits of a device that is not directly connected to a power outlet.

Measurement category II (CAT II):

Primary circuits of a device that is directly connected to a power outlet, e.g., portable tools or home appliance.

Measurement category III (CAT III):

Primary circuits of a device (fixed equipment) to which power is supplied directly from the distribution panel, and circuits running from the distribution panel to power outlet.

Measurement category IV (CAT IV):

Building service-line entrance circuits, and circuits running from the service-line entrance to the meter or primary circuit breaker (distribution panel).

For Safety

WARNING

Electric Shock

3. To ensure that the instrument is earthed, always use the supplied 3-pin power cord, and insert the plug into an outlet with an earth terminal. If power is supplied without earthing the equipment, there is a risk of receiving a severe or fatal electric shock or causing damage to the internal components.

Repair

WARNING 

4. This equipment cannot be repaired by the operator. DO NOT attempt to remove the equipment covers or unit covers or to disassemble internal components. Only qualified service personnel with a knowledge of electrical fire and shock hazards should service this equipment. There are high-voltage parts in this equipment presenting a risk of severe injury or fatal electric shock to untrained personnel. In addition, there is a risk of damage to precision components.

Calibration



5. The performance-guarantee seal verifies the integrity of the equipment. To ensure the continued integrity of the equipment, only Anritsu service personnel, or service personnel of an Anritsu sales representative, should break this seal to repair or calibrate the equipment. If the performance-guarantee seal is broken by you or a third party, the performance of the equipment cannot be guaranteed. Be careful not to break the seal by opening the equipment or unit covers.

Falling Over

6. This equipment should always be positioned in the correct manner. If the cabinet is turned on its side, etc., it will be unstable and may be damaged if it falls over as a result of receiving a slight mechanical shock.

Always set up the equipment in a position where the power switch can be reached without difficulty.

LCD

7. This instrument uses a Liquid Crystal Display (LCD). DO NOT subject the instrument to excessive force or drop it. If the LCD is subjected to strong mechanical shock, it may break and liquid may leak. This liquid is very caustic and poisonous. DO NOT touch it, ingest it, or get in your eyes. If it is ingested accidentally, spit it out immediately, rinse your mouth with water and seek medical help. If it enters your eyes accidentally, do not rub your eyes, rinse them with clean running water and seek medical help. If the liquid gets on your skin or clothes, wash it off carefully and thoroughly.

For Safety

CAUTION

Cleaning



Check Terminal



1. Keep the power supply and cooling fan free of dust.
 - Clean the power inlet regularly. If dust accumulates around the power pins, there is a risk of fire.
 - Keep the cooling fan clean so that the ventilation holes are not obstructed. If the ventilation is obstructed, the cabinet may over-heat and catch fire.
2. Use two or more people to lift and move this equipment, or use a trolley. There is a risk of back injury, if this equipment is lifted by one person.
3. Never input a signal of more than the indicated value between the measured terminal and ground. Input of an excessive signal may damage the equipment.

For Safety

CAUTION

Replacing Memory Back-up Battery

This equipment uses a Poly-carbomono-fluoride lithium battery to back-up the memory. This battery must be replaced by service personnel when it has reached the end of its useful life; contact the Anritsu sales section or your nearest representative.

Note: The battery used in this equipment has a maximum useful life of 7 years. It should be replaced before this period has elapsed.

External Storage Media

This equipment uses memory cards as external storage media for storing data and programs.

If this media is mishandled or becomes faulty, important data may be lost. To prevent this chance occurrence, all important data and programs should be backed-up.

Anritsu will not be held responsible for lost data.

Pay careful attention to the following points.

- Never remove the memory card from the instrument, while it is being accessed.
- The memory card may be damaged by static electric charges.
- Anritsu has thoroughly tested all external storage media shipped with this instrument. Users should note that external storage media not shipped with this instrument may not have been tested by Anritsu, thus Anritsu cannot guarantee the performance or suitability of such media.

Use in a residential environment

This instrument is designed for an industrial environment.

In a residential environment this instrument may cause radio interference in which case the user may be required to take adequate measures.

Equipment Certificate

Anritsu Corporation certifies that this equipment was tested before shipment using calibrated measuring instruments with direct traceability to public testing organizations recognized by national research laboratories, including the National Institute of Advanced Industrial Science and Technology, and the National Institute of Information and Communications Technology, and was found to meet the published specifications.

Anritsu Warranty

Anritsu Corporation will repair this equipment free-of-charge if a malfunction occurs within one year after shipment due to a manufacturing fault. However, software fixes will be made in accordance with the separate Software End-User License Agreement. Moreover, Anritsu Corporation will deem this warranty void when:

- The fault is outside the scope of the warranty conditions described in the operation manual.
- The fault is due to mishandling, misuse, or unauthorized modification or repair of the equipment by the customer.
- The fault is due to severe usage clearly exceeding normal usage.
- The fault is due to improper or insufficient maintenance by the customer.
- The fault is due to natural disaster including fire, flooding, earthquake, etc.
- The fault is due to use of non-specified peripheral equipment, peripheral parts, consumables, etc.
- The fault is due to use of a non-specified power supply or in a non-specified installation location.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation shall assume no liability for injury or financial loss of the customer due to the use of or a failure to be able to use this equipment.

Anritsu Corporation Contact

In the event that this equipment malfunctions, contact an Anritsu Service and Sales office. Contact information can be found on the last page of the printed version of this manual, and is available in a separate file on the CD version.

Notes On Export Management

This product and its manuals may require an Export License/Approval by the Government of the product's country of origin for re-export from your country.

Before re-exporting the product or manuals, please contact us to confirm whether they are export-controlled items or not.

When you dispose of export-controlled items, the products/manuals need to be broken/shredded so as not to be unlawfully used for military purpose.

Lifetime of Parts

The life span of certain parts used in this instrument is determined by the operating time or the power-on time. Due consideration should be given to the life spans of these parts when performing continuous operation over an extended period. These parts must be replaced at the customer's expense even if within the guaranteed period described in Warranty at the beginning of this manual.

Crossed-out Wheeled Bin Symbol

Equipment marked with the Crossed-out Wheeled Bin Symbol complies with council directive 2002/96/EC (the “WEEE Directive”) in European Union.



For Products placed on the EU market after August 13, 2005, please contact your local Anritsu representative at the end of the product's useful life to arrange disposal in accordance with your initial contract and the local law.

CE Conformity Marking

Anritsu affixes the CE conformity marking on the following product(s) in accordance with the Council Directive 93/68/EEC to indicate that they conform to the EMC and LVD directive of the European Union (EU).

CE marking



1. Product Model

Model: MT8815B/MT8820B Radio Communication Analyzer

2. Applied Directive

EMC: Directive 2004/108/EC

LVD: Directive 2006/95/EC

3. Applied Standards

- EMC: Emission: EN 61326-1: 2006 (Class A)
Immunity: EN 61326-1: 2006 (Table 2)

	Performance Criteria*
IEC 61000-4-2 (ESD)	B
IEC 61000-4-3 (EMF)	A
IEC 61000-4-4 (Burst)	B
IEC 61000-4-5 (Surge)	B
IEC 61000-4-6 (CRF)	A
IEC 61000-4-8 (RPFMF)	A
IEC 61000-4-11 (V dip/short)	B, C

*: Performance Criteria

- A: During testing, normal performance within the specification limits.
- B: During testing, temporary degradation, or loss of function or performance which is self-recovering.
- C: During testing, temporary degradation, or loss of function or performance which requires operator intervention or system reset occurs.

Harmonic current emissions:

EN 61000-3-2: 2006 (Class A equipment)

- LVD: EN 61010-1: 2001 (Pollution Degree 2)

4. Authorized representative

Name:	Loic Metais European Quality Manager ANRITSU S.A. France
Address, city:	16/18 Avenue du Québec SILIC 720 Zone de Courtaboeuf 91951 Les Ulis Cedex
Country:	France

C-tick Conformity Marking

Anritsu affixes the C-tick mark on the following product(s) in accordance with the regulation to indicate that they conform to the EMC framework of Australia/New Zealand.

C-tick marking



1. Product Model

Model: MT8815B/MT8820B Radio Communication Analyzer

2. Applied Standards

EMC:Emission: EN 61326-1: 2006 (Class A equipment)

About This Manual

The MT8815B/MT8820B Radio Communication Analyzer is a measuring instrument platform that allows both transmitter/receiver characteristics measurement in mobile communication systems and call processing tests with one unit.

When using MT8815B/MT8820B, confirm that installed measurement software of specifications and test method that are supported by mobile systems must be installed. Optional devices may be required depending on the function.

This manual explains use of the panel keys and connectors, setting up the main unit, basic operations, common functions for measurement software and basic remote control.

Refer to the separate operation manual of the measurement software or optional devices for transmitter/receiver characteristic measurement and call processing test procedures.

■ Contents of this manual

- Notes and precautions for safe use of MT8815B/MT8820B
- How to use the panel keys and connectors
- Installation of the main unit
- Turning the power On/Off
- Basic operations for the cursor and screens
- Parameter settings (numeric values, character strings etc.)
- Common functions and usage of measurement software
- Basic remote control functions
- Remote control commands implementing common functions
- Performance test and calibration procedures

■ Items not explained in this manual

Refer to the separate operation manual for measurement software or optional devices.

- Functions and usage of measurement software
- Remote control commands implementing the measurement software functions
- Performance test and calibration procedures implemented by the measurement software
- Setting up procedures and usage of optional devices

Checking Accessories

When unpacking, check that the products listed in the attached component list are provided. If a missing or damaged component is found, contact Anritsu Service and Sales offices at the address at the end of paper-edition manual or the separate file of CD-edition manual.

The following components are provided with this product. For details, refer to “1.3 Product Configuration” in this manual.

■ Standard parts

Main unit and standard accessories

- MT8815B/MT8820B Radio Communication Analyzer (main unit, 1)
- Power cord (1)
- CompactFlash card (1)
- PC card adapter (1)
- MT8815B/MT8820B Operation Manual (CD-ROM, 1)

■ Parts on order

Provided on your request. Check the attached component list.

- Option
- Measurement software
- Application parts
- Others

Manual Configuration

Chapter 1 Product Overview

This chapter explains the overview, product configurations and the specifications of MT8815B/MT8820B.

Chapter 2 Setup

This chapter explains the name and function of each part, installation of MT8815B/MT8820B, and connection method with external devices.

Chapter 3 Getting Started

This chapter explains the operation flow of MT8815B/MT8820B from turning On the power and measuring to turning Off the power.

Chapter 4 Basic Operation

This chapter explains the basic operation procedure of MT8815B/MT8820B. Basic operations required for measurement, such as usage of basic items and parameter settings, are provided.

Chapter 5 Using Common Functions

This chapter explains the operation procedure of common functions in measurement software such as initialization and measurement start.

Chapter 6 Common Screen Functions

This chapter explains the common screen functions. Functions explained in this chapter are common for all measurement software.

Chapter 7 Remote Control Using PC

This chapter explains the basic operation of remote control commands and status reports for remote control of MT8815B/MT8820B using a PC.

Chapter 8 Remote Control Commands

This chapter explains the remote control commands implementing common functions in measurement software, such as IEEE488.2 common commands etc.

Chapter 9 Maintenance

This chapter explains the performance test and calibration procedure to use MT8815B/MT8820B in its optimal status.

Notations in This Manual








Notation (font)	Example	Meaning
		Indicates a panel key. Character strings printed on the panel key or function name (in case there is no printing) are written.
		Indicates to press a panel key after pressing  . This procedure is used to execute the function printed on the panel key in blue (Save for ).
Arial	Main1 Input/Output	Indicates the characters printed on the panel; mainly connector name or functions when pressing the panel key after shifting  .
“Century”	“Screen Select”	Character strings written in Century closed with “ ” indicates the description displayed on LCD.
COURIER (Capital English/ numeric characters)	SWP	Indicates the reservation words for remote control command
courier (Lower case English/numeric characters)	SCRSEL screen	Indicates parameter for remote control command. Numeric characters or reservation words in “screen” part.
/* */ (courier)	/*setting date*/	A part closed with “/* */” indicates a remote control command comment. This part is not transmitted as it means the explanation of command to be transmitted.

Table of Contents

For Safety	iii
About This Manual.....	I
Chapter 1 Product Overview	1-1
1.1 Product Overview.....	1-2
1.2 Features	1-2
1.3 Product Configuration	1-3
1.4 Specifications	1-9
Chapter 2 Setup.....	2-1
2.1 Part Names and Functions	2-2
2.2 Installation	2-17
2.3 Connection	2-22
2.4 Memory Card	2-37
Chapter 3 Getting Started.....	3-1
3.1 Power-on.....	3-2
3.2 Initialization	3-4
3.3 Selecting Screen	3-5
3.4 Viewing Screen	3-6
3.5 Calibration	3-8
3.6 Setting Parameter	3-10
3.7 Measurement	3-12
3.8 Reading Measurement Results	3-13
3.9 Power-Off	3-15

Chapter 4 Basic Operation	4-1
4.1 Display Area.....	4-3
4.2 Operating Cursor	4-8
4.3 Operating Screen.....	4-10
4.4 Operating Window	4-16
4.5 Operating User Menu.....	4-19
4.6 Operating Function Menu	4-20
4.7 Setting Parameters	4-30
4.8 Tag Operation	4-38
4.9 Operating Template	4-41
4.10 Operating View Window.....	4-42
4.11 Using User Function Keys	4-43
 Chapter 5 Using Common Functions	 5-1
5.1 Initialization	5-2
5.2 Calibration.....	5-3
5.3 Starting Measurement.....	5-6
5.4 Connecting Call.....	5-8
5.5 Hard Copy.....	5-10
5.6 Functions Can be Set Only for Remote Control	5-12
5.7 Other Functions	5-14
 Chapter 6 Common Screen Functions	 6-1
6.1 Setting Systems and Interfaces.....	6-3
6.2 Selecting Measurement Application to be Activated	6-28
6.3 Displaying System Information	6-31
6.4 Setting Common Cable Loss	6-39
6.5 Saving Parameters	6-54
6.6 Recalling Parameters.....	6-62

Chapter 7 Remote Control Using PC.....	7-1
7.1 Remote Control.....	7-3
7.2 GPIB Interface	7-7
7.3 Serial Interface.....	7-10
7.4 Ethernet (100Base-TX/10Base-T) Interface	7-12
7.5 Command Syntax	7-15
7.6 Command Programming Guide	7-20
7.7 Status Report	7-21
7.8 Establishing Synchronization	7-37
 Chapter 8 Remote Control Commands	 8-1
8.1 Command List by Function	8-2
8.2 Command Specifications in Alphabetical Order	8-17
 Chapter 9 Maintenance.....	 9-1
9.1 Performance Test	9-2
9.2 Calibration.....	9-26
9.3 Cleaning.....	9-29
9.4 Storage and Transportation	9-30
9.5 Troubleshooting	9-32

Chapter 1 Product Overview

This chapter describes the overview, product configuration and specifications of MT8815B/MT8820B.

Replacing terms when using MT8815B

The MT8815B is dedicated for single phone measurements and is not equipped with parallelphone functions. Part (option) names therefore may differ between the MT8815B and MT8820B (as shown in Table 1-1). This document provides explanations of the MT8820B unless otherwise mentioned, so replace the terms shown in Table 1-1 when using the MT8815B. The Connector I/O functions, however, have not been changed.

Table 1-1 Different MT8815B and MT8820B terms

Description in this document	Replace with:
MT8820B	MT8815B
10Base-T-1	10Base-T
AF1	AF
AUX1	AUX
Call Proc I/O-1	Call Proc I/O
GPIB-1	GPIB
HandSet 1	HandSet
Main1	Main
RS-232C-1	RS-232C

1.1	Product Overview	1-2
1.2	Features.....	1-2
1.3	Product Configuration	1-3
1.3.1	Standard configuration	1-3
1.3.2	Options	1-4
1.3.3	Measurement software and options	1-6
1.3.4	Application parts	1-7
1.3.5	Warranty service.....	1-8
1.4	Specifications.....	1-9

1.1 Product Overview

MT8815B/MT8820B Radio Communication Analyzer is a measurement instrument platform that is able to perform both transmitter/receiver characteristics measurement of radio terminals in mobile communication systems and call processing test with one unit.

1.2 Features

MT8815B/MT8820B has the following features:

- (1) Supports the third-generation mobile communication standards
By installing measurement software, you can conduct a test of mobile terminals conforming to the third-generation communication systems.
- (2) Possible to conduct transmission/reception characteristics measurement and call test using a single MT8815B/MT8820B.
By installing measurement software, you can measure transmission/reception characteristics and conduct a call-processing test with a MT8815B/MT8820B.
- (3) High-speed measurement
MT8815B/MT8820B, with state-of-the-art processors and a measurement algorithm, allows high-speed measurement.
- (4) Graphical user interface
The user interface employs the window system thus displaying specified parameters and related measurement results on the same screen.
- (5) Parameter save/recall
The measurement parameters set to MT8815B/MT8820B can be saved as a file, which eliminates the need for repeating similar setting for each measurement.
- (6) Listing the function menu
You can use the **Functions** key to list the function menu for the current screen or window. You can locate the target menu item at a glance.
- (7) Remote control through the GPIB interface
You can use the GPIB, Serial or Ethernet (100Base-TX/10Base-T) interface to remotely control the MT8815B/MT8820B from an external controller such as a PC.

Note:

The remote control function via the Serial interface can be used only with the MT8815B. It is not available for the MT8820B.

1.3 Product Configuration

This section introduces the standard configuration of MT8815B/MT8820B as well as accessories, optional equipment, measurement software products, application parts and peripherals to utilize MT8815B/MT8820B.

1.3.1 Standard configuration

The following table lists standard configuration of one MT8815B/MT8820B:

Table 1.3.1-1 Standard configurations

Item	Model type	Model name	Quantity	Remarks
Main unit	MT8815B/MT8820B	Radio Communication Analyzer	1	
Standard Attachments		Power supply cord	1	
		MT8815B/MT8820B Operation Manual	1	English, CD-ROM
		CF card	1	
	CA68ADP	PC card adopter	1	For CF card

1.3.2 Options

The following table lists options for expanding the functions of MT8815B/MT8820B. All the options are to be ordered separately. For ordering them, specify the model name/symbol, product name and quantity.

Table 1.3.2-1 MT8815B Options

Model type	Model name	Remarks
MT8815B-001	W-CDMA Measurement Hardware	
MT8815B-002	TDMA Measurement Hardware	
MT8815B-003	CDMA2000 Measurement Hardware	
MT8815B-004	1xEV-DO Measurement Hardware	
MT8815B-005	1xEV-DO Measurement Hardware	
MT8815B-007	TD-SCDMA Measurement Hardware	
MT8815B-031	W-CDMA Measurement Hardware Lite	
MT8815B-032	TDMA Measurement Hardware Lite	
MT8815B-011	Audio Board	
MT8815B-101	W-CDMA Measurement Hardware Retrofit	
MT8815B-102	TDMA Measurement Hardware Retrofit	
MT8815B-103	CDMA2000 Measurement Hardware Retrofit	
MT8815B-104	1xEV-DO Measurement Hardware Retrofit	
MT8815B-105	1xEV-DO Measurement Hardware Retrofit	
MT8815B-107	TD-SCDMA Measurement Hardware Retrofit	
MT8815B-131	W-CDMA Measurement Hardware Lite Retrofit	
MT8815B-132	TDMA Measurement Hardware Lite Retrofit	
MT8815B-111	Audio Board Retrofit	
MT8815B-043	CDMA2000 Time Offset Calibration For GPS SG	
MT8815B-143	CDMA2000 Time Offset Calibration For GPS SG Retrofit	

Table 1.3.2-2 MT8820B Options

Model type	Model name	Remarks
MT8820B-001	W-CDMA Measurement Hardware	
MT8820B-002	TDMA Measurement Hardware	
MT8820B-003	CDMA2000 Measurement Hardware	
MT8820B-004	1xEV-DO Measurement Hardware	
MT8820B-005	1xEV-DO Measurement Hardware	
MT8820B-007	TD-SCDMA Measurement Hardware	
MT8820B-031	W-CDMA Measurement Hardware Lite	
MT8820B-032	TDMA Measurement Hardware Lite	
MT8820B-011	Audio Board	
MT8820B-101	W-CDMA Measurement Hardware Retrofit	
MT8820B-102	TDMA Measurement Hardware Retrofit	
MT8820B-103	CDMA2000 Measurement Hardware Retrofit	
MT8820B-104	1xEV-DO Measurement Hardware Retrofit	
MT8820B-105	1xEV-DO Measurement Hardware Retrofit	
MT8820B-107	TD-SCDMA Measurement Hardware Retrofit	
MT8820B-131	W-CDMA Measurement Hardware Lite Retrofit	
MT8820B-132	TDMA Measurement Hardware Lite Retrofit	
MT8820B-111	Audio Board Retrofit	
MT8820B-012	Parallel Phone Measurement Hardware	For MT8820B only
MT8820B-112	Parallel Phone Measurement Hardware Retrofit	
MT8820B-043	CDMA2000 Time Offset Calibration For GPS SG	
MT8820B-143	CDMA2000 Time Offset Calibration For GPS SG Retrofit	

1.3.3 Measurement software and options

Measurement software and options available for MT8815B/MT8820B is to be ordered separately.

For detailed function and performance of the measurement software, please contact Anritsu or your nearest distributor.

The following table lists measurement software products available for MT8815B/MT8820B. For the software option, refer to each applicable software operation manual.

Table 1.3.3-1 Measurement software

Model type	Model name	Remarks
MX882000C	W-CDMA Measurement Software	MT8820B-001 (or MT8820B-101) and MX882050C(or MX882051C) are required.
MX882001C	GSM Measurement Software	MT8820B-002 (or MT8820B-102) is required.
MX882002C	CDMA2000 Measurement Software	MT8820B-003 (or MT8820B-103) is required.
MX882003C	1xEV-DO Measurement Software	MT8820B-003 (or MT8820B-103), MT8820B-004 (or MT8820B-104) and MX882002C are required.
MX882005C	PHS Measurement Software	MT8820B-002 (or MT8820B-102) is required.
MX882006C	1xEV-DO Measurement Software	MT8820B-003 (or MT8820B-103), MT8820B-005 (or MT8820B-105) and MX882002C are required.
MX882007C	TD-SCDMA Measurement Software	MT8820B-001 (or MT8820B-101), MT8820B-007 (or MT8820B-107) are required.
MX882030C	W-CDMA Measurement Software Lite	MT8820B-031 (or MT8820B-131) is required.
MX882031C	GSM Measurement Software Lite	MT8820B-032 (or MT8820B-132) is required.
MX882050C	W-CDMA Call Processing Software	MX882000C is required.
MX882051C	W-CDMA Call Processing Software	MX882000C is required.
MX882070C	W-CDMA Ciphering Software	MX882000C and MX882050C are required.
MX882071C	W-CDMA Ciphering Software	MX882000C and MX882050C are required.
MX882010C	Parallel Phone Measurement Software	MT8820B-012 (or MT8820B-112) is required. MT8820B only.

Note:

For the MT8815B, the model name becomes MT8815B-XXX (XXX: option number). (Refer to Table 1.3.2-1 “MT8815B Options”.)

1.3.4 Application parts

Use application parts (accessories) as required. All the application parts are to be ordered separately. For ordering them, specify the model name/symbol, article name and quantity.

Table 1.3.4-1 Application parts

Model type/ Symbol	Model name	Remarks
W2778AE	MT8815B/MT8820B Operation Manual	English, Printed document
J0576B	Coaxial cable, 1.0 m	N-P•5D-2W•N-P
J0576D	Coaxial cable, 2 m	N-P•5D-2W•N-P
J0127A	Coaxial cable, 1 m	BNC-P•RG58A/U•BNC-P
J0127C	Coaxial cable, 0.5 m	BNC-P•RG58A/U•BNC-P
J0007	GPIB connection cable, 1.0 m	408JE-101
J0008	GPIB connection cable, 2.0 m	408JE-102
A0013	Handset	S80AF-16 (01) (DG) handset
A0058A	Handset	
J1267B	RS-232C cable	D-SUB 9-pin, female-female interlink
MN8110B	I/O adapter	For Call Processing I/O
B0332	Clip	4/1 set
B0333G	Rack mount kit (for MT8820B)	
B0612A	Rack mount kit (for MT8815B)	
B0544	Carrying case (for MT8815B)	Hard type, with Protective cover and casters
B0545	Carrying case (for MT8815B)	Hard type, with protective cover, no caster
B0499	Carrying case (for MT8820B)	Hard type, with Protective cover and casters
B0499B	Carrying case (for MT8820B)	Hard type, with protective cover, no caster

1.3.5 Warranty service

Table 1.3.5-1 MT8815B Warranty service

Model type	Model name	Remarks
MT8815B-ES210	2-year Warranty extension Service	
MT8815B-ES310	3-year Warranty extension Service	
MT8815B-ES510	5-year Warranty extension Service	

Table 1.3.5-2 MT8820B Warranty service

Model type	Model name	Remarks
MT8820B-ES210	2-year Warranty extension Service	
MT8820B-ES310	3-year Warranty extension Service	
MT8820B-ES510	5-year Warranty extension Service	

1.4 Specifications

The following tables show the specifications for MT8815B/MT8820B:

Table 1.4-1 Specifications

Item	Specifications
General	<p>Frequency range: 30 to 2700 MHz</p> <p>Maximum input level: +35 dBm (Main 1)</p> <p>Main 1 input/output connector</p> <ul style="list-style-type: none"> • Impedance: 50 Ω • VSWR ≤ 1.2 (<1.6 GHz), ≤ 1.25 (1.6 to 2.2 GHz), ≤ 1.3 (>2.2 GHz) • Connector: N type <p>AUX 1 output connector</p> <ul style="list-style-type: none"> • Impedance: 50 Ω • VSWR ≤ 1.3 (when SG output level is ≤ -10 dBm) • Connector: SMA type <p>Reference oscillator</p> <ul style="list-style-type: none"> • Frequency: 10 MHz • Level: TTL • Activation characteristics: $\leq 5 \times 10^{-8}$ (Using the frequency obtained 24 hours after power-on as a reference) • Aging rate: $\leq 2 \times 10^{-8}$/day, $\leq 1 \times 10^{-7}$/year (Using the frequency obtained 24 hours after power-on as a reference) • Temperature characteristics: $\leq 5 \times 10^{-8}$ • Connector: BNC type <p>External reference signal input</p> <ul style="list-style-type: none"> • Frequency: 10 or 13 MHz (± 1ppm) • Level: ≥ 0 dBm • Impedance: 50 Ω • Connector: BNC type

Table 1.4-1 Specifications (Cont'd)

Item	Specification
RF signal generator	<p>Frequency</p> <ul style="list-style-type: none"> Frequency range: 30 to 2700 MHz (settable range: 0.4 to 2700 MHz) Setting resolution: 1 Hz By the accuracy of Standard Signal Generator <p>Output level</p> <ul style="list-style-type: none"> Level range: -140 to -10 dBm (Main 1), -130 to 0 dBm (AUX1) Resolution: 0.1 dB Level accuracy: <ul style="list-style-type: none"> Main 1: ± 1.0 dB (-120 to -10 dBm, after calibration) AUX 1: ± 1.0 dB (-110 to 0 dBm, after calibration) <p>Signal purity</p> <ul style="list-style-type: none"> Non-harmonic spurious: ≤ -50 dBc (at offset frequency of 100 kHz or more) Harmonics: ≤ -25 dBc <p>Un-interruptible level variable</p> <ul style="list-style-type: none"> Variable range: 0 to -30 dB Set resolution: 1 dB
Other	<p>Display</p> <ul style="list-style-type: none"> Color TFT LCD, Size: 8.4", Number of dots: 640 × 480 dots <p>External control</p> <ul style="list-style-type: none"> GPIO: Controlled by an external controller, assuming the MT8815B/MT8820B as a device (except some functions such as power switch etc.). No controller function Interface function: SH1, AH1, T6, L4, SR1, RL1, PP0, DC1, DT1, C0, E2 Serial (RS-232C): Controlled by an external controller (except some functions such as power switch etc.). No controller function for external device. (MT8815B only. Refer to Table 7.4.1-1 "Standards".) Ethernet (100Base-TX/10Base-T): Controlled by an external controller, assuming the MT8815B/MT8820B as a device (except some functions such as power switch etc.). No controller function
Power	<p>MT8815B</p> <p>100 to 120 Vac/200 to 240 Vac (-15%/+10%, maximum: 250 V) 47.5 to 63 Hz, ≤ 300 VA (All options installed)</p> <p>MT8820B</p> <p>100 to 120 Vac/200 to 240 Vac (-15%/+10%, maximum: 250 V) 47.5 to 63 Hz, ≤ 300 VA (Option 01 installed), ≤ 550 VA (All options installed)</p>
Dimensions, Mass	<p>MT8815B</p> <p>426 mm (W), 221.5 mm (H), 351 mm (D) (except protrusions), ≤ 17.8 kg (All options installed)</p> <p>MT8820B</p> <p>426 mm (W), 221.5 mm (H), 498 mm (D) (except protrusions), ≤ 26 kg (All options installed)</p>

Table 1.4-1 Specifications (Cont'd)

Item	Specification
Operating temperature and humidity range	0 to 50°C, ≤95% (no condensation)
Storage temperature and humidity	−20 to +60°C, ≤85% (no condensation)
EMC	Conducted disturbance: EN 61326-1: 2006(Class A) Radiated disturbance: EN 61326-1: 2006(Class A) Harmonic Current Emission: EN 61000-3-2: 2006(Class A) Electrostatic Discharge: EN 61326-1: 2006(Table 2) Electromagnetic Field Immunity: EN 61326-1: 2006(Table 2) Fast Transient / Burst: EN 61326-1: 2006(Table 2) Surge: EN 61326-1: 2006(Table 2) Conducted RF: EN 61326-1: 2006(Table 2) Power Frequency Magnetic Field: EN 61326-1: 2006(Table 2) Voltage Dips / Short Interruptions: EN 61326-1: 2006(Table 2)
Safety	In conformance with EN61010-1:2001 (Pollution Degree 2)

Table 1.4-2 Specifications (MX882010C Parallelphone Measurement Software)

Item	Specification
Application	When the MX882010C Parallelphone Measurement Software is installed in the MT8820B in combination with the MT8820B-012 (or MT8820B-112) Parallelphone Measurement Hardware, the Phone-2 side becomes enabled. In this event, the functions that accord with the installed measurement software and the measurement hardware equipped on the Phone-2 side are available on the Phone-2 side, and two phones can be measured simultaneously.
General	Main 2 input/output, AUX2 output <ul style="list-style-type: none"> The same characteristics performance and functions as those of the Main 1 input/output and AUX1 output specified by the MT8820B and the measurement software installed in the MT8820B are applied to the Main 2 input/output and AUX2 output. AF2 input/output <ul style="list-style-type: none"> The same characteristics performance and functions as those of the AF1 input/output specified by the measurement software are applied to the AF2 input/output. This is enabled only when the MT8820B-011 (or MT8820B-111) Audio Board is installed.

Chapter 2 Setup

This chapter describes names and functions of each part, installation method of MT8815B/MT8820B and connection procedures with external devices.

2.1	Part Names and Functions	2-2
2.1.1	Exterior	2-2
2.1.2	Front panel	2-3
2.1.3	Rear panel	2-14
2.2	Installation.....	2-17
2.2.1	Transportation.....	2-17
2.2.2	Installation	2-18
2.2.3	Piggyback installation	2-20
2.2.4	Installation on rack.....	2-21
2.3	Connection.....	2-22
2.3.1	Power Requirements	2-22
2.3.2	Connecting the Power Cord	2-22
2.3.3	Connecting to phone	2-24
2.3.4	Connecting GPIB cable	2-25
2.3.5	RS-232C port.....	2-26
2.3.6	10 Base-T port.....	2-26
2.3.7	100Base-TX/10Base-T port.....	2-27
2.3.8	Reference signal input/output connector.....	2-27
2.3.9	Event trigger connector	2-28
2.3.10	Serial port	2-29
2.3.11	Call processing I/O port.....	2-30
2.3.12	Checking power to be input to connector	2-36
2.4	Memory Card	2-37
2.4.1	Precautions for use.....	2-37
2.4.2	Inserting and removing Memory card.....	2-37
2.4.3	Formatting memory card	2-38

2.1 Part Names and Functions

This section describes the names and functions of the panel keys for operating MT8815B/MT8820B and connectors for connecting to external devices.

2.1.1 Exterior

The front panel is composed of the LCD panel, panel keys and connectors.

The rear panel includes the power inlet, GPIB connector, etc.

On the sides of MT8815B/MT8820B are provided two grips for transporting MT8815B/MT8820B.




Fig. 2.1.1-1 External appearance

2.1.2 Front panel




Fig. 2.1.2-1 Front panel (1)

1. **Preset** Preset key
Starts initialization.
2. **Remote** Remote lamp
Illuminates while MT8815B/MT8820B is operating in the remote control mode.
3. **Local** Local key
Switches from remote control operation mode to local control mode.
4. **Copy** Copy key
Performs hard copy of a current screen.
Shift + **Copy** Copy as
Performs copy of all screens.
5. **Power** Power switch
Switches power state between power on (On) and standby (Stby).




Fig. 2.1.2-2 Front Panel (2)

6. **U1**, **U2**, **U3**, **U4**, **U5**, **U6**, **U7** User function keys
Execute user menu contents displayed in the leftmost area of the screen, when the common window is enabled.
- When the measurement window is set to Active, each function of user function keys is as follows.
- U1** User function key 1
Enables the measurement result window.
- U2** User function key 2
Enables the setting window.
- U3** User function key 3
Enables the specific window for each measurement other than the measurement result window and setting window.
- U4** User function key 4
Decreases the size of the window at the lower part of the screen.
- U5** User function key 5
Enlarges the size of the window at the lower part of the screen.
- U6** User function key 6
Collapses the item list in the setting window.
- U7** User function key 7
Expands the item list in the setting window.

7. User User key
Currently not available.
8. **Memory Card** Memory card slot
Insert a PCMCIA-compliant PC-card-type memory card (Type II) in this slot.




Fig. 2.1.2-3 Front panel (3) (left: MT8815B, right: MT8820B)

- 9. **Serial Bus 1** Serial bus connector 1
Currently not available.
- 10. **Serial Bus 2** Serial bus connector 2
Currently not available.
- 11. **Handset 1** Handset connector 1
Handset connector (RJ12) used for a voice communication test on Phone 1.
To use this connector, the voice codec and audio board options are required.
- 12. **Handset 2** Handset connector 2
Handset connector (RJ12) used for a voice communication test on the second phone (Phone 2), which is available when the Parallel-phone Measurement Software is installed.
To use this connector, the voice codec and audio board options are required.




Fig. 2.1.2-4 Front panel (4) – AF connector (left: MT8815B, right: MT8820B)

Event Trig connectors (MT8815B)

13. **Event Trig Input** Trigger input connector
A BNC connector for a trigger signal input from an external device and Tx measurement on the phone in synchronization with an external device.
14. **Event Trig Output** Trigger output connector
A BNC connector used for outputting event timing to the external device allocated to the phone.

AF connectors

15. **AF1 Input** AF1 input connector
A BNC input connector used for AF measurement on Phone 1. The voice codec and audio board options are required.
16. **AF1 Output** AF1 output connector
A BNC output connector used for AF measurement on Phone 1. The voice codec and audio board options are required.
17. **AF2 Input** AF2 input connector
A BNC input connector used for AF measurement on the second phone (Phone 2), which is available when the Parallelphone Measurement Software is installed. The voice codec and audio board options are required.
18. **AF2 Output** AF2 output connector
A BNC output connector used for AF measurement on the second phone (Phone 2), which is available when the Parallelphone Measurement Software is installed. The voice codec and audio board options are required.

CAUTION

Do not feed power exceeding the maximum permissible power specified on the label or in the specification to the AF input connector. Do not feed signals to the AF output connector. Such attempts may damage the internal circuits thus causing a fire accident or failure.




Fig. 2.1.2-5 Front panel (5) – RF connector (left: MT8815B, right: MT8820B)

RF connectors

- 19. AUX1 Output AUX1 output connector
SMA type auxiliary output connector used for RF measurement on Phone 1.
- 20. Main1 Input/Output Main1 input/output connector
N type connector used for RF measurement on Phone 1.
- 21. AUX2 Output AUX2 output connector
SMA type connector used for RF measurement on the second phone (Phone 2), which is available when the Parallelphone Measurement Software is installed.
- 22. Main2 Input/Output Main2 input/output connector
N type connector used for RF measurement on the second phone (Phone 2), which is available when the Parallelphone Measurement Software is installed.

CAUTION

Do not feed power exceeding the maximum permissible power specified on the label or in the specification to the RF input connector. Do not feed signals to the RF output connector. Such attempts may damage the internal circuits thus causing a fire accident or failure.




Fig. 2.1.2-6 Front panel (6)

23. **F1**, **F2**, **F3**, **F4**, **F5**, **F6**, **F7** Function keys
Executes function menu items displayed in the rightmost area of the screen.
24. **Next** Page switch key
Switches pages of the menu displayed in the rightmost area of the screen.
25. **Functions** All function key
Lists the function menus.
26. **Screen** Screen selection key
Selects a screen.
Shift + **Screen** Phone Change key
When the Parallelphone Measurement Software is installed, this key switches the screen operation for Phone 1 or Phone 2, to display on the LCD and to operate by the front panel.




Fig. 2.1.2-7 Front panel (7)

Screen control keys (Screen Control)

27. **Focus** Focus key
Switches between windows to be operated.
28. **View** View key
Opens/Closes the View window.
Shift + **View** Alt View Alt View key
Currently not available.
29. **Scroll Up** Up scroll key
Scrolls up screens or windows.
Shift + **Scroll Up** Window size key
Enlarges the size of the window at the lower part of the screen.
30. **Scroll Down** Down scroll key
Scrolls down screens or windows.
Shift + **Scroll Down** Window size key
Decreases the size of the window at the lower part of the screen.

Measurement keys (Measure)

31. **Single** Single key
Starts measurement in the single mode.
32. **Continuous** Continuous key
Starts measurement in the continuous mode.
33. **Stop** Measurement stop key
Stops measurement.




Fig. 2.1.2-8 Front panel (8)

Channel/level keys (Channel/Level)

34. **Channel** Channel key
Sets the input channel.
35. **Input Freq** Input frequency key
Sets the input frequency.
Shift + **Input Freq** Output Freq Output frequency key
Sets the output frequency.
36. **Output Level** Output level key
Sets the output level.
37. **Input Level** Input level key
Sets the input level.

Call processing keys (Call)

38. **Start Call** Phone call key
Makes a call from MT8815B/MT8820B to a phone.
39. **End Call** Network-side ending key
Releases communications with a phone from MT8815B/MT8820B.




Fig. 2.1.2-9 Front panel (9)

Utility key (Utility)

40. **Recall** Recall key
Starts reading parameter files.
Shift + **Recall** **Save** Save key
Starts saving of parameter files.
41. **std** Standard key
Starts change of the system.
42. **Config** Configuration key
Opens the Configuration menu.

Cursor operation/data entry keys (Cursor/Data Entry)

43. **^** **v** **<** **>** Cursor keys
Moves cursor or enters parameters.
44. Rotary control
Turning this knob moves cursor or enters parameters. Pressing this knob starts entering or determines the parameters.
45. **Set** Set key
Starts entering or determines the entered parameters.
46. **Cancel** Cancel key
Cancels the current input value and returns the previous settings.




Fig. 2.1.2-10 Front panel (10)

Cursor operation/data entry keys (Cursor/Data Entry) <continued>

47. **Shift** Shift key
Press this key, before executing functions indicated in blue on the panel.
48. **BS** Back space key
Deletes one character before the cursor, while a value is being entered.
49. Unit and enter keys
Sets the unit for values being input and validates parameters.

Unit key	GHz, dBm, dB, W
Unit key	MHz, dBμV/V, s, mW
Unit key	kHz, mV, ms, μW
Enter	Default unit, Hz, μV, μs, nW
50. Numeric keypad/symbol key

0	to	9	,	.	,	-/+
----------	----	----------	---	----------	---	------------

 Starts parameter entry or enters numeric values.

Shift	+	4	to	Shift	+	9	A to F
--------------	---	----------	----	--------------	---	----------	--------

 Enters A to F for hexadecimal notation.

2.1.3 Rear panel




Fig. 2.1.3-1 Rear panel (1) (left: MT8815B, right: MT8820B)

1. GPIB-1 GPIB connector 1
Remote control connector for Phone 1 through GPIB.
2. GPIB-2 GPIB connector 2
Remote control connector for Phone 2 (available when the Parallelphone Measurement Software is installed) through GPIB.

Event Trig connector (MT8820B)

3. Event Trig Out-1 Trigger output connector 1
BNC connector for outputting the event timing to external device allocated to Phone 1.
4. Event Trig Out-2 Trigger output connector 2
BNC connector for outputting the event timing to external device allocated to Phone 2 (available when the Parallelphone Measurement Software is installed).
5. Event Trig In-1 Trigger input connector 1
BNC connector for inputting trigger signal from external device and performing transmission measurement on Phone 1 in synchronization with the external device.
6. Event Trig In-2 Trigger input connector 2
BNC connector for inputting trigger signal from external device and performing transmission measurement on Phone 2 (available when the Parallelphone Measurement Software is installed) in synchronization with the external device.
7. 10 MHz/13 MHz Ref In Reference signal input connector
BNC connector for inputting an external reference signal. The frequency lock range is ± 1 ppm and the input level range is 2 to 5 Vpp.
8. 10 MHz Buff Out Reference signal output connector
BNC connector for outputting a reference signal from MT8815B/MT8820B.
9. Freq Adjust Frequency adjustment
Adjuster knob (trimmer) for the reference oscillation frequency.




Fig. 2.1.3-2 Rear panel (2) (left: MT8815B, right: MT8820B)

10. Serial Serial port
9-pin D-Sub connector for remote control via RS-232C.
11. 100BTX/10BT 100Base-TX/10Base-T port
RJ-45 connector for the remote control via Ethernet (100Base-TX/10Base-T).
12. 10BT-1 10Base-T port 1
An interface for packet or communication test allocated to Phone 1.
13. 10BT-2 10Base-T port 2
An interface for packet or communication test allocated to Phone 2 (available when the Parallelphone Measurement Software is installed).
14. Call Proc I/O-1 call processing input/output port 1
15-pin mini D-Sub connector for call processing allocated to Phone 1.
15. Call Proc I/O-2 call processing input/output port 2
15-pin mini D-Sub connector for call processing allocated to Phone 2 (available when the Parallelphone Measurement Software is installed).
16. RS-232C-1 RS-232C port 1
Data interface for packet or communication test allocated to Phone 1.
17. RS-232C-2 RS-232C port 2
Data interface for packet or communication test allocated to Phone 2 (available when the Parallelphone Measurement Software is installed).





Fig. 2.1.3-3 Rear panel (3) (left: MT8815B, right: MT8820B)

- 18. Serial Bus-1 Serial bus connector 1
Currently, not available.
- 19. Serial Bus-2 Serial bus connector 2
Currently, not available.
- 20. Functional earth terminal
This is the terminal that is electrically connected to the chassis of the equipment.
- 21. Power inlet Power cable inlet. Permissible power range is 100 to 120 Vac or 200 to 240 Vac (47.5 to 63 Hz). This power inlet supports both 100 and 200-V system with no need to make particular setting change.
- 22. Main power switch
Turns the main power to On or Off. Turning the main power switch on, power switch on the front panel turns standby (Stby).
- 23. Safety labels
WARNING label for safe operation of MT8815B/MT8820B. Observe the description on the label.

WARNING 
NO OPERATOR SERVICE-
ABLE PARTS INSIDE.
REFER SERVICING TO
QUALIFIED PERSONNEL.

2.2 Installation

Install MT8815B/MT8820B after you have taken it from a package box and have checked the packed items. This section describes how to install it and precautions before use.

2.2.1 Transportation

Carry MT8815B/MT8820B with the grips provided on both sides of it and keeping it horizontal.

CAUTION

1. Do not move MT8815B/MT8820B with the power turned on. Such an attempt may damage the internal circuits thus resulting in a fire accident, electric shock and/or failure.
 2. Carry MT8815B/MT8820B with the grips provided on both sides of it, and keep it in a horizontal position while you are transporting it. Carrying MT8815B/MT8820B only with one of the grips while inclining it may cause an excessive force on the internal precision parts, which may be damaged.
 3. MT8815B/MT8820B should be carried by two or more persons or placed on a transportation cart. MT8815B/MT8820B is too heavy for one person to carry. Doing so gives burden to the waist thus causes possible injury. Avoid strong vibration in loading the cart with MT8815B/MT8820B.
-

2.2.2 Installation

Install MT8815B/MT8820B horizontally in a stable place at a low-drift temperature between 0 and 50°C. Keep the rear and sides of MT8815B/MT8820B at least 10 cm apart from obstacles such as walls and peripherals in order to provide space around the exhaust holes.




Fig. 2.2.2-1 Installation place




Fig. 2.2.2-2 Installation direction

CAUTION

In order to avoid fire accidents, personal damage and/or failure, do not use MT8815B/MT8820B in the following places:

- **Unstable place**

Avoid installing MT8815B/MT8820B in an unstable place, that is, in a place with vibration, on an unstable stand or in a slanted place. Otherwise, it will lose balance and be turned down or fall down, leading to injury.

- **Humid or dusty place**

Avoid installing MT8815B/MT8820B in a humid or dusty place. Drops of water or accumulated dust may constitute a short circuit, thus causing a fire accident, electric shock and/or failure.

- **High temperature**

Avoid direct sunlight or high temperatures. Otherwise the internal temperature will rise, and may result in a fire accident and/or failure.

- **Place where it is exposed to active gas**

Avoid installing MT8815B/MT8820B in a place that may be exposed to active gas. Otherwise MT8815B/MT8820B may be damaged, thus causing a fire accident and/or failure.

- **Excessive fluctuation in temperature**

Avoid excessive fluctuation in temperature. When using MT8815B/MT8820B at normal temperatures after using it at low temperatures for a long time, make sure that turn on its power after it is dried up well. Otherwise drops of water produced inside may constitute a short circuit thus causing a fire accident, electric shock and/or failure.

CAUTION

Do not block the airflow from the exhaust fan of MT8815B/MT8820B. Otherwise the internal temperature will rise and may cause a fire accident. Avoid using MT8815B/MT8820B in the following way:

- Using MT8815B/MT8820B in the upright position
- Using MT8815B/MT8820B with the protective cover
- Using MT8815B/MT8820B with dust accumulated on the fan

2.2.3 Piggyback installation

To install two units of MT8815B/MT8820B in a piggyback structure, mate four feet (at the corners of the bottom of the upper unit) with four adjusters (at the corners of the top of the lower unit). Anchor the two units using a band designed to prevent them from falling. Do not piggyback 3 or more MT8815B/MT8820B units.




Fig. 2.2.3-1 Piggyback installation

2.2.4 Installation on rack

To install MT8815B/MT8820B on a rack, Rack-mount (separately ordered) is required. For how to attach rack-mount, refer to its operation manual.

2.3 Connection

This section describes the protective grounding method and provision of various cables.

2.3.1 Power Requirements

For normal operation of the instrument, observe the power voltage range described below.

Power source	Voltage range	Frequency
100 Vac system	100 to 120 V	47.5 to 63 Hz
200 Vac system	200 to 240 V	47.5 to 63 Hz

Changeover between 100 and 200 V systems is made automatically.

CAUTION

Supplying power exceeding the above range may result in electrical shock, fire, failure, or malfunction.

2.3.2 Connecting the Power Cord

Check that the main power switch on the rear panel is turned off (switched to the (O) side).

Insert the power plug into an outlet, and connect the other end to the power inlet on the rear panel. To ensure that the instrument is earthed, always use the supplied 3-pin power cord, and insert the plug into an outlet with an earth terminal.

WARNING

If the power cord is connected without the instrument earthed, there is a risk of receiving a fatal electric shock. In addition, the peripheral devices connected to the instrument may be damaged.

When connecting to the power supply, DO NOT connect to an outlet without an earth terminal. Also, avoid using electrical equipment such as an extension cord or a transformer.

CAUTION

If an emergency arises causing the instrument to fail or malfunction, disconnect the instrument from the power supply by either turning off the main power switch on the rear panel (switch to the (O) side), or by pulling out the power cord or the power inlet.

When installing the instrument, place the instrument so that an operator may easily operate the main power switch. If the instrument is mounted in a rack, a power switch for the rack or a circuit breaker may be used for power disconnection.

It should be noted that, the power switch on the front panel of the instrument is a standby switch, and cannot be used to cut the main power.

2.3.3 Connecting to phone

Methods for connecting MT8815B/MT8820B to a phone to be measured differ according to AF of a phone, RF connector type or assignment. This section describes the basic connection method.

Note:

To perform RF signal measurement, check that output connector of MT8815B/MT8820B is in conformance with the RF Output setting (Refer to Section 6.1.14 “Setting signal output connector”).

(Ex. 1) Connecting Main1 Input/Output with phone

Use an RF cable to connect the Main1 Input/Output on the front panel of MT8815B/MT8820B to the RF signal input/output connector of a phone. When direct connection is not allowed, use an adapter separately.




Fig. 2.3.4-1 Example of connection to a phone (1)

(Ex. 2) Outputting from AUX1 Output and inputting from Main1 Input/Output connector.

Use an RF cable to connect AUX1 Output to the input connector of a phone and Main Input/Output and RF output connector of a phone. When direct connection is not allowed, use an adapter separately.




Fig. 2.3.4-2 Example of connection to a phone (2)

2.3.4 Connecting GPIB cable

MT8815B/MT8820B is provided with GPIB connector as remote control interface. Connect the connector of the GPIB cable to GPIB-1 (or GPIB-2) on the rear panel.





Fig. 2.3.4-1 Stack connection of GPIB connector



12	11	10	9	8	7	6	5	4	3	2	1
GND	ATN	SRQ	IFC	NDAC	NRFD	DAV	EOI	DIO4	DIO3	DIO2	DIO1
24	23	22	21	20	19	18	17	16	15	14	13
GND	GND	GND	GND	GND	GND	GND	REN	DIO8	DIO7	DIO6	DIO5

Fig. 2.3.4-2 Signal assignment of GPIB connector


CAUTION

Connect a GPIB cable before turning MT8815B/MT8820B on. Otherwise the internal circuit parts in the interface unit may be damaged.

2.3.5 RS-232C port

The RS-232C-1 and RS-232C-2 ports (D-Sub, 9-pin, female) are connectors for performing data communication test between MT8815B/MT8820B and a phone.

Table 2.3.5-1 Signal assignment of RS-232C




Pin No.	Signal name	Description
1	CF (DCD)	Carrier detection (input to MT8815B/MT8820B)
2	BB (RXD)	Receive data (input to MT8815B/MT8820B)
3	BA (TXD)	Transmission data (output from MT8815B/MT8820B)
4	CD (DTR)	Data terminal ready (output from MT8815B/MT8820B)
5	AB (GND)	Ground
6	CC (DSR)	Data set ready (input to MT8815B/MT8820B)
7	CA (RTS)	Signal request (output from MT8815B/MT8820B)
8	CB (CTS)	Send ready (input to MT8815B/MT8820B)
9	CE (RI)	Ring indicator (input to MT8815B/MT8820B)

2.3.6 10 Base-T port

The 10Base-T-1 and 10Base-T-2 ports on the rear panel are connectors for performing high-speed data communication test between MT8815B/MT8820B and a phone.

Table 2.3.6-1 Signal assignment of 10Base-T




Pin No.	Signal name
1	TD+
2	TD-
3	RD+
4	NC
5	NC
6	RD-
7	NC
8	NC

2.3.7 100Base-TX/10Base-T port

The 100Base-TX/10Base-T port on the rear panel is a connector for using the remote control.

Table 2.3.7-1 Signal assignment of 100Base-TX/10Base-T



Pin No.	Signal name
1	TD+
2	TD-
3	RD+
4	NC
5	NC
6	RD-
7	NC
8	NC

2.3.8 Reference signal input/output connector

The BNC-type 10 MHz/13 MHz Ref In on the rear panel of MT8815B/MT8820B is a connector inputting an external reference signal. Input the signal with the frequency accuracy of ± 1 ppm and the level of 2 to 5 Vp-p.

Reference frequency to be used needs to be set in the Reference Frequency on System Configuration screen. Following reference signals can be used in MT8815B/MT8820B.

- 10 MHz Built-in reference signal in MT8815B/MT8820B
- 10 MHz External input reference signal
- 13 MHz External input reference signal

The BNC-type 10 MHz Buff Out outputs the internal 10 MHz reference signal of the TTL level.




Fig. 2.3.8-1 10 MHz/13 MHz Ref In and 10 MHz Buff Out

2.3.9 Event trigger connector

The Event Trig Out-1 and Event Trig Out-2 on the front panel of the MT8815B or rear panel of the MT8820B are BNC connectors for outputting the event timing to an external device.

The Event Trig In-1 and Event Trig In-2 are BNC connectors for inputting a trigger signal from an external device, and performing transmission measurement on Phone 1 or Phone 2 in synchronization with the external device.





Fig. 2.3.9-1 Event Trig

2.3.10 Serial port

The MT8815B is equipped with a Serial port as a remote control interface. Connect an RS-232C cable connector to the Serial (D-Sub 9-pin, male) port on the rear panel.

Table 2.3.10-1 Serial and signal assignment



Pin No.	Signal name	Description
1	(NC)	Not connected
2	BB (RXD)	Receive data (input to MT8815B/MT8820B)
3	BA (TXD)	Transmission data (output from MT8815B/MT8820B)
4	(NC)	Not connected
5	AB (GND)	Ground
6	(NC)	Not connected
7	CA (RTS)	Signal request (output from MT8815B/MT8820B)
8	CB (CTS)	Send ready (input to MT8815B/MT8820B)
9	(NC)	Not connected

Note:


Remote control via the Serial interface is only for the MT8815B.
It cannot be used with the MT8820B.

2.3.11 Call processing I/O port

The Call Proc I/O-1 and Call Proc I/O-2 ports (mini D-Sub, 15-pin) on the rear panel of MT8815B/MT8820B are used to input/output signals related to the call-processing test.


Pin assignment varies depending on the measurement software. Check the measurement software to be used.

Table 2.3.11-1 Signal assignment of Call Proc I/O
When using W-CDMA, TD-SCDMA, GSM or PHS measurement software



Pin No	Signal name	Description
1	BER_DAT_IN	Inputs the data for BER measurement. The phone inputs the demodulated data of the TTL or CMOS level.
2	BER_DAT_OUT	Outputs the demodulated data of the CMOS level.
3	FRAME_TRG_IN	Inputs the trigger signal in a frame period (for PHS only.)
4	DSUB15_RSV4	Reserved
5	DSUB15_RSV7	Reserved
6	FRAME_TRG_OUT	Outputs the trigger signal of the CMOS level in a frame period.
7	BER_CLK_IN	Inputs the clock signal for BER measurement. Input the data clock of the TTL or CMOS level, demodulated by the tested terminal.
8	BER_CLK_OUT	Outputs the demodulated data clock of the CMOS level.
9	DSUB15_RSV2	Reserved
10	DSUB15_RSV5	Reserved
11	SYNC IN	Inputs the synchronization signal of the TTL or CMOS level from the master unit, when two units of MT8815B/MT8820B are synchronized.
12	SYNC OUT	Outputs the synchronization signal of the CMOS level to the slave unit, when two units of MT8815B/MT8820B are synchronized.
13	GND	Ground
14	DSUB15_RSV3	Reserved
15	DSUB15_RSV6	Reserved

Table 2.3.11-2 Signal assignment of Call Proc I/O port
When using CDMA2000 or 1xEV-DO measurement software



Pin No	Signal name	Description
1	RSV_1	Reserved
2	PP2S Multi	Timing signal for even seconds. (LVCMOS level pulse signal, 813.8 ns interval)
3	(NC)	Not connected
4	RSV_OUT_1	Reserved
5	RSV_OUT_2	Reserved
6	Slot	1.25 ms interval slot signal (LVCMOS level pulse signal, 813.8 ns interval)
7	RSV_2	Reserved
8	Frame	20 ms interval frame signal (LVCMOS level pulse signal, 813.8 ns interval)
9	(NC)	Not connected
10	(NC)	Not connected
11	SYNC IN	Inputs the synchronization signal of the TTL or CMOS level from the master unit, when two units of MT8815B/MT8820B are synchronized.
12	SYNC OUT	Outputs the synchronization signal of the CMOS level to the slave unit, when two units of MT8815B/MT8820B are synchronized.
13	GND	Ground
14	DSUB15_RSV3	Reserved
15	DSUB15_RSV6	Reserved

MN8110B I/O adapter is available separately as an application part for the call processing port.

MN8110B is a unit that converts D-Sub 15-pin connector into a BNC connector. Connect the Call Proc. I/O port (D-Sub 15-pin) on the rear panel to that on MT8815B/MT8820B using the connection cable provided with MN8110B. This allows input/output of the MT8815B/MT8820B Call Proc. I/O port input/output signal with the BNC connector.




Fig. 2.3.11-1 External view of MN8110B




Fig. 2.3.11-2 MN8110B Front panel

<When using W-CDMA, GSM or PHS measurement software>

- | | |
|-------------------------|---|
| 1. Data Input | Data input connector |
| 2. Data Clock Input | Data clock input connector |
| 3. Data Output | Data output connector |
| 4. Data Clock Output | Data clock output connector |
| 5. Frame Trigger Output | Trigger signal output connector |
| 6. Frame Trigger Input | Trigger signal input connector |
| 7. SYNC Input | Synchronization signal input connector |
| 8. SYNC Output | Synchronization signal output connector |

<When using CDMA2000, 1xEV-DO measurement software>


- | | |
|------------------------|---|
| 1. RSV1 | Reserved |
| 2. RSV2 | Reserved |
| 3. PP2S Output | PP2S output |
| 4. Frame Output | Frame interval signal output |
| 5. Slot Output | Slot interval signal output |
| 6. Frame Trigger Input | Trigger signal input connector |
| 7. SYNC Input | Synchronization signal input connector |
| 8. SYNC Output | Synchronization signal output connector |

**Table 2.3.11-3 Relationships between front panel connector and
MT8815B/MT8820B Call Proc I/O port
When using W-CDMA, TD-SCDMA, GSM or PHS measurement software**


MN8110B front panel	Call Proc. I/O on MT8815B/MT8820B
Connector name	Signal name
Data Input	BER_DAT_IN
Data Clock Input	BER_CLK_IN
Data Output	BER_DAT_OUT
Data Clock Output	BER_CLK_OUT
Frame Trigger Output	FRAME_TRG_OUT
Frame Trigger Input	FRAME_TRG_IN
SYNC Input	SYNC IN
SYNC Output	SYNC OUT

**Table 2.3.11-4 Relationships between front panel connector and
MT8815B/MT8820B Call Proc I/O port
When using CDMA2000 or 1xEV-DO measurement software**

MN8110B front panel	Call Proc. I/O on MT8815B/MT8820B
Connector name	Signal name
RSV1	RSV_OUT_1
RSV2	RSV_OUT_2
PP2S Output	PP2S
Frame Output	Frame
Slot Output	Slot
Frame Trigger Input	None
SYNC Input	SYNC IN
SYNC Output	SYNC OUT

**Fig. 2.3.11-3 MN8110B Rear panel**

1. Call Proc. I/O MT8815B/MT8820B interface connector

**Fig. 2.3.11-4 Connection between MT8815B/MT8820B and MN8110B****Table 2.3.11-5 MN8110B standards**

Dimensions	213 mm (W), 44 mm (H), 150 mm (D) (projecting items not included)
Mass	1 kg or less

2.3.12 Checking power to be input to connector

Avoid feeding a power exceeding the maximum permissible power to input connectors of MT8815B/MT8820B. Do not input signals to connectors dedicated for output or the internal circuits should be damaged.

Table 2.3.12-1 Maximum permissible power

Connector name	Maximum permissible power
Main1 Input/Output	35 dBm
10 MHz/13 MHz Ref In	2 to 5 Vp-p
Event Trig In-1	TTL level
Call Proc. I/O-1	TTL level
AF Input	5000 mV(Peak)

CAUTION

MT8815B/MT8820B is not provided with a circuit for protecting the internal circuits from the input power exceeding the maximum permissible power. Never feed the power exceeding the maximum permissible power. Such an attempt may damage the internal circuits thus causing a fire accident or failure.

2.4 Memory Card

Memory cards available to MT8815B/MT8820B are PC-card-type (Type II) memory cards. Use a compactflash card with PC card adapter attached. Please use an attached memory card.

2.4.1 Precautions for use

Note the following points when using a memory card:

- (1) Never remove a memory card while MT8815B/MT8820B is accessing the card. Otherwise data saved on the card may be lost and besides the card itself may be damaged.
- (2) A memory card that has been magnetized or exposed to static electricity may no longer work.
- (3) Avoid high temperatures and humidity as well as direct sunlight when storing the memory card.
- (4) It is recommended to backup the data when saving data onto a memory card. Anritsu Corporation will not be responsible for data loss in the memory card.
- (5) The memory card shipped with the instrument has been thoroughly tested. Users should note that, as not all other such devices have been tested in this manner, Anritsu is unable to guarantee their performance or suitability.

2.4.2 Inserting and removing Memory card

Insert a memory card into the memory card slot on the front panel.

Insert a memory card, with the notch for preventing incorrect insertion on the memory card (PC-card adapter) in the direction as shown in the figure below. You can insert a single memory card at a time.




Fig. 2.4.2-1 Inserting a memory card

Press the eject button on the right side of the memory card slot to remove the card.

2.4.3 Formatting memory card

Format a memory card to be used in the MS-DOS format beforehand. An unformatted memory card cannot be used. MT8815B/MT8820B is not equipped with the format function.

Chapter 3 Getting Started

This chapter outlines the basic procedures for using MT8815B/MT8820B, from power-on to power-off. For details of each operation when power is on, refer to Chapters 4 to 6 of this manual or operation manual for the measurement software.

3.1	Power-on.....	3-2
3.2	Initialization	3-4
3.3	Selecting Screen.....	3-5
3.4	Viewing Screen.....	3-6
3.5	Calibration.....	3-9
3.6	Setting Parameter.....	3-10
3.7	Measurement	3-12
3.8	Reading Measurement Results	3-13
3.9	Power-Off.....	3-15

3.1 Power-on

CAUTION

Turn on the power after making sure that MT8815B/MT8820B is dried up well. When using MT8815B/MT8820B at normal temperatures after using it at low temperatures near 0°C, drops of water produced inside may constitute a short circuit thus causing failure.

To power on MT8815B/MT8820B, turn on both the main power switch on the rear panel and the power switch on the front panel.

[Procedure]

1. Turn on the main power switch on the rear panel. This turns on the Stby lamp on the front panel. The illuminating Stby lamp indicates that the main power switch is on.
When turned into Standby status, preheating of the reference crystal oscillator circuit starts. To operate MT8815B/MT8820B at lower temperatures, preheat MT8815B/MT8820B at least 24 hours to enhance stability of the crystal oscillator.




Fig. 3.1-1 Standby status (Stby lamp for the power switch is On.)

2. Next, hold down the power switch on the front panel for at least one second to turn it on. The Stby lamp goes Off and the power On lamp goes On.




Fig. 3.1-2 Power-on status (power On lamp for the power switch is On.)

3. Some time after the power lamp goes on, various messages are displayed on the screen and the measurement software is started.

Note:

To switch between power On and Off, you must hold down the power switch on the front panel for at least one second. This is to prevent the power from being turned On or switched to standby (Stby) by mistake.

3.2 Initialization

When the power is turned On, perform initialization. Initialization aims at returning the parameters set for MT8815B/MT8820B in the default status. Initialization prevents MT8815B/MT8820B from being influenced by the previous setting. For details, refer to Section 5.1 “Initialization.”

Notes:

1. Initialization cannot be performed on the Standard Load screen. When the Standard Load screen and Common External Loss screen is displayed, therefore, change the screen to another one before starting initialization by referring to Section 4.3 “Operating Screen.”
2. Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

[Procedure]

1. Press to display the Preset pop-up window.



Fig. 3.2-1 Preset

2. Press “Preset” to perform the initialization.

3.3 Selecting Screen

Select a screen corresponding to the items to be set after initialization. Functions and operation status of MT8815B/MT8820B depends on the screen.

Select measurement screen (Phone-1 or Phone-2 Screen) to set or measure a parameter. Measurement screen is the general name for screens in which measurements are performed. Several screens are prepared for measurement and they differ depending on the measurement software.

Select Common Screen to display system settings and information. Common Screen can be selected in any software.

For details of the screen operation, refer to Section 4.3 “Operating Screen.”

Example:

Selecting Fundamental Measurement screen for measurement screen in W-CDMA measurement software.

Note:

MX882000C W-CDMA measurement software must be loaded.

[Procedure]

1. Press Screen to display Screen Select pop-up window.




Fig. 3.3-1 Screen Select

2. Turn the rotary control to move the cursor on “Fundamental Measurement” under the “Select Phone-1 Screen” (or “Select Phone-2 Screen”) tree.
3. Press the rotary control to open the Fundamental Measurement screen.

3.4 Viewing Screen

This section describes how to view a screen using the Fundamental Measurement screen of W-CDMA measurement software as an example. For details, refer to Section 4.1 “Display Area.”




Fig. 3.4-1 W-CDMA•Fundamental Measurement screen

1. Date and time
Shows date and time, or user-defined character string.
2. Screen type
Shows the name of the currently selected screen.
3. RF signal output connector
Shows message on currently selected RF connector or UNCAL status.
4. Call processing status
Shows current call processing status.
5. Measurement mode
Shows measurement mode under execution. This is displayed only during measurement.
6. Window list bar
Lists windows that are currently opened or active.

7. The phone currently being measured and measurement software (Phone-1)
When Phone-1 is being measured, shows the measurement software being used. The first connector, such as Main 1 or GPIB-1, is used.
8. The phone currently being measured and measurement software (Phone-2)
This tab is displayed only when the Parallelphone Measurement Software is installed in MT8820B. When Phone-2 is being measured, shows the measurement software being used. The second connector, such as Main 2 or GPIB-2, is used.
The display for Phone-1 and Phone-2 can be switched by pressing Shift + Screen.
9. Function menu
Functions to be executed by pressing the corresponding function key on the right hand side.
10. Measurement indicator or error messages
Shows measurement progress/completion messages or error message when an error occurs.
11. Transmission power monitor value for a phone
Shows transmission power monitor value for a phone.
12. Upper window
Display field for results of each measurement.
13. Lower window
Display field for the Parameter window for parameter settings and others.
14. Tag
A marker for major items such as parameter or measured result groups. A tag becomes active when the cursor is put on a parameter or measured result.
15. Cursor
Used to select values to be set to parameters or scroll a window.
16. Scroll bar
Appears when all information cannot be displayed within the current screen/window size. You can see all information by scrolling the screen/window.

17. Band Calibration Warning

A warning is displayed if, after performing Band Calibration, the internal temperature of the MT8815B/MT8820B changes by more than the specified temperature range.

18. Reference Unlock Warning

A warning is displayed to show that the reference clock is unlocked.

Note:

The Band Calibration and Ref. Unlock warnings are not displayed while operating in the remote control mode.

3.5 Calibration

Perform calibration before measurement. This flattens the frequency characteristics of the level accuracies for the input/output levels to calibrate level accuracy error due to internal temperature change. The measurement accuracy varies with changes in temperature. Execute calibration not to affect the temperature change.

Band Calibration and Full Calibration can be performed by a single MT8815B/MT8820B unit. Band Calibration performs calibration within the band of all the communication systems supported by all the measurement softwares. Full Calibration performs calibration within the input/output band for MT8815B/MT8820B (30 to 2700 MHz).

Note:

It takes about one and a half minutes to perform Full Calibration.

To exclude the effects of the ambient temperature, it is best to consider ambient temperature changes and periodically perform Band Calibration. Full Calibration takes care of the same items in Band Calibration but takes more time. After turning on the power, perform Full Calibration after initializing settings to the Factory Initial level or when executing a performance test.

Note:

Wait at least 60 minutes after turning the power on before performing Full Calibration.

After performing Full Calibration, to exclude the effects of the ambient temperature, consider ambient temperature changes and periodically perform Band Calibration.

Example:

To perform calibration at MT8815B/MT8820B input/output band

[Procedure]

1. Press to display the function menu containing the Full Calibration menu.




Fig. 3.5-1 Full Calibration menu

2. Press "Full Calibration" to perform calibration.

3.6 Setting Parameter

Set parameters for measurement conditions on the screen setting (Parameter) window to be measured.

To operate a window such as setting window, the window must be active. For details of window operations, refer to Section 4.4 “Operating Window”.

Example:

Changing Reference Level from -10.0 dBm to -15.0 dBm in the setting window on the W-CDMA measurement software Fundamental Measurement screen.

[Procedure]

1. Check that Fundamental Measurement screen is open.



Fig. 3.6-1 Checking the screen

2. The setting window is displayed at the lower part of the screen. Check that the Setting (Parameter) window is active at the window list bar.

The setting window is active.




Fig. 3.6-2 Setting window

3. If the setting window is not active, press **Focus** to activate the setting window. The cursor is displayed when the setting window is activated.
4. Turn the rotary control to move the cursor on “Input Level”.




Fig. 3.6-3 Input Level selection

5. Press the rotary control to open the pop-up window and start entry of values. The upper and lower limits for input values are displayed.




Fig. 3.6-4 Starting to enter

6. Use the numeric keypad to enter a value to be changed. To enter -15.0 dBm, press , , , , and of the numeric keypad in this order.




Fig. 3.6-5 Entering numeric values

7. After inputting, press the rotary control to determine the value.




Fig. 3.6-6 Determining the value

3.7 Measurement

Start measurement after all the parameters necessary for measurement have been specified, the terminal to be tested has been prepared and the state of MT8815B/MT8820B has been checked. For details, refer to Section 5.3 “Starting Measurement”.

[Procedure]

Press .

Note:

Measurement can be executed only on the measurement screen and cannot be executed on the common screen. Measurement items differ depending on the measurement screen.

When measurement is completed normally, a message indicating completion of measurement appears in the measurement indicator error status area.



Fig. 3.7-1 Message for measurement complete

An error message as shown in the figure below if an error occurs during the measurement. Check the setting and measure again. Error messages differ depending on the error type occurred.



Fig. 3.7-2 Error message example

3.8 Reading Measurement Results

When the measurement has been completed, read the measurement results. The measurement results are displayed in the measurement results window of the measurement screen.

Example:

To read measurement results for Occupied Bandwidth in W-CDMA measurement software.

[Procedure]

1. Occupied Bandwidth measurement is performed on the Fundamental Measurement screen. Select Fundamental Measurement screen and start measurement.
2. Check that the measurement is completed. If an error message is displayed, check the setting and perform the measurement again.

End

Fig. 3.8-1 Checking measurement completion

3. Measurement result window is displayed on the upper part of the screen. Press **Focus** to activate the measurement result window (Fundamental Meas. Window). Then, the cursor is displayed on the measurement result window.




Fig. 3.8-2 Activating the measurement result window

4. Press **[F3]** “Occupied Bandwidth” to display the measurement results for Occupied Bandwidth. Other measurement results can be viewed by turning the rotary control.




Fig. 3.8-3 Displaying measurement results

3.9 Power-Off

Power Off MT8815B/MT8820B when it is not used. Turn Off both the main power switch on the rear panel and the power switch on the front panel.

[Procedure]

1. Hold down the power switch on the front panel for at least one second to turn it Off. The power On lamp goes Off and the Stby lamp goes On. In case you use MT8815B/MT8820B immediately afterwards, keep MT8815B/MT8820B in this status. Power is fed to the internal circuits to stabilize the reference crystal oscillator.




Fig. 3.9-1 Standby status (Stby lamp for the power switch is On.)

2. If MT8815B/MT8820B is not used for a long time, press the main power switch on the rear panel to turn it Off. The Stby lamp goes Off and the main power is turned Off.



Fig. 3.9-2 Power-Off status (both Stby lamp and On lamp are Off)

Chapter 4 Basic Operation

This chapter describes basic operation required for a measurement including screen description, how to enter parameters and execute functions.

4.1	Display Area.....	4-3
4.1.1	Names and positions in display area.....	4-3
4.1.2	Status area	4-4
4.1.3	Measurement-indicator/error-status area	4-5
4.1.4	User menu area.....	4-7
4.1.5	Window area.....	4-7
4.1.6	Entry area	4-7
4.1.7	Function menu area.....	4-7
4.1.8	Transmission-power monitor-value area	4-7
4.2	Operating Cursor	4-8
4.2.1	Cursor type	4-8
4.2.2	Moving cursor	4-9
4.3	Operating Screen.....	4-10
4.3.1	Screen type	4-10
4.3.2	Selecting screen	4-11
4.3.3	Scrolling screen	4-14
4.3.4	Change screen color pattern	4-15
4.4	Operating Window	4-16
4.4.1	Window type	4-16
4.4.2	Window status	4-16
4.4.3	Activating window	4-17
4.4.4	Changing window size.....	4-17
4.4.5	Scrolling window.....	4-18
4.5	Operating User Menu	4-19
4.5.1	Executing user menu.....	4-19
4.6	Operating Function Menu	4-20
4.6.1	Viewing function menu	4-20
4.6.2	Switching menu page	4-21
4.6.3	Displaying menu list of all pages	4-23
4.6.4	Types of function menus	4-24
4.6.5	Execution menu.....	4-25
4.6.6	Numeric value entry menu	4-25
4.6.7	Character string entry menu.....	4-27
4.6.8	Item display menu	4-27
4.6.9	Item selection menu	4-28
4.6.10	Tag selection menu	4-28
4.6.11	Toggle menu.....	4-29
4.6.12	Screen selection menu	4-29

4.7	Setting Parameters	4-30
4.7.1	Settable parameters	4-30
4.7.2	Parameter type	4-30
4.7.3	Parameter setting procedures	4-31
4.7.4	Setting list selection type parameter	4-31
4.7.5	Setting numeric value type parameter.....	4-32
4.7.6	Setting numeric value group type parameter	4-34
4.7.7	Setting character string parameter	4-35
4.7.8	Setting channel, frequency or level	4-36
4.8	Tag Operation	4-38
4.8.1	Tag status.....	4-38
4.8.2	Activating tag	4-39
4.8.3	Jump to tag.....	4-40
4.9	Operating Template	4-41
4.9.1	Opening template	4-41
4.9.2	Closing template.....	4-41
4.10	Operating View Window	4-42
4.10.1	Opening view window.....	4-42
4.10.2	Closing view window	4-42
4.11	Using User Function Keys	4-43
4.11.1	Selecting active window	4-43
4.11.2	Changing window size.....	4-43
4.11.3	Changing Item List setting for tag.....	4-44

4.1 Display Area

This section describes the contents displayed on LCD of MT8815B/MT8820B. Display position is determined according to the display contents.

4.1.1 Names and positions in display area

The screen consists of the following seven display areas. Some areas are not displayed depending on the operation statuses.




Fig. 4.1.1-1 Display area

1. Status area (Refer to 4.1.2)
2. Measurement-indicator/ Error-status area (Refer to 4.1.3)
3. User menu area (Refer to 4.1.4)
4. Window area (Refer to 4.1.5)
5. Entry area (Refer to 4.1.6)
6. Function menu area (Refer to 4.1.7)
7. Transmission-power monitor-value area (Refer to 4.1.8)

4.1.2 Status area

The status area displays the measurement software type, opened screen type, window status, and basic information to indicate the current operation status such as date/time, call processing status, etc.




Fig. 4.1.2-1 Status area

1. Title
The date and time or character information is displayed. The title can be set on the System Configuration screen.
2. Screen type
The screen type currently being opened is displayed. It indicates operation mode for MT8815B/MT8820B.
3. Output connector/status for RF signal
Connector type or status for RF signal output from MT8815B/MT8820B is displayed. Output connector for RF signal can be set in RF Output on the System Configuration screen.

Table 4.1.2-1 Output connector/status for RF signal

Display	Description
Output Main	Main input/output connector
Output AUX	AUX auxiliary output connector
Output UNCAL	Output level is UNCAL status (Output signal is outside of guaranteed accuracy.
Output CW	Outputs non-modulation CW signals.
Output Off	Output Off.

4. Call processing status
The call processing status is displayed. It indicates the communication status between MT8815B/MT8820B and the phone.

5. Measurement mode

The current measurement mode is displayed. This is displayed only during measurement.

Table 4.1.2-2 Measurement mode

Display	Measurement mode
Single	Single measurement mode
Continuous	Continuous measurement mode

6. Window list bar

The types and active/inactive status of the opened windows are displayed.

7. Phone under measurement and measurement software

The phone under measurement and the software type are displayed.

8. Band Calibration warning

A warning is displayed if, after performing Band Calibration, the internal temperature of the MT8815B/MT8820B changes by more than the specified temperature range. For details about how to specify the temperature range for which this warning is displayed, refer to Section 6.1.11 “Setting temperature range for warning display”.

9. Reference Unlock warning

A warning is displayed to show that the reference clock is unlocked.

Note:

The Band Calibration and Reference Unlock warnings are not displayed while operating in the remote control mode.

4.1.3 Measurement-indicator/error-status area

The measurement-indicator/error-status area displays the measurement progress status and an error occurrence type on the measurement screen. They are not displayed on the common screen.

(1) Display under measurement

Display during the measurement.




Fig. 4.1.3-1 Under measurement

- (2) Display for normal measurement completion
Display for normal measurement completion.



Fig. 4.1.3-2 Normal completion of measurement

- (3) Display for error message
A message indicating the error type is displayed when an error occurs during the measurement.



Fig. 4.1.3-3 Error message example

4.1.4 User menu area

User menu area displays seven user menus. User menu is a list for executable functions displayed on each screen or window. Press **U1** to **U7** user function keys to execute a user menu.

4.1.5 Window area

Window area displays parameters and measurement results indicating MT8815B/MT8820B settings and measurement conditions. Format and content of a window area differs depending on the screen or window. For some screens, two windows are displayed in upper and lower areas.

4.1.6 Entry area

Entry area is displayed when Pressing **Channel** or **Input Freq** to enter parameter for channel or input frequency or when specifying the parameter file number. It displays a numeric value being entered or error messages.

4.1.7 Function menu area

The function menu area displays seven function menus. The function menu is a list for executable functions displayed on each screen or window. Press **F1** to **F7** user keys to execute a function.

4.1.8 Transmission-power monitor-value area

Transmission-power monitor-value area displays the measured monitor value of transmission power for an active phone. The most accurate measurement result for transmission power is displayed in the window area.

The transmission-power monitor value is displayed on the measurement screen only and will be updated in a given time regardless of the start of measurement by **Single**, etc. Time for updating differs according to the measurement software. This will not be displayed on the common screen.

4.2 Operating Cursor

The cursor is used to scroll the screens and windows, select a desired parameter or digit of numeric value, and activate a tag.

4.2.1 Cursor type

The cursor can be classified as follows according to their shapes and functions. In this manual, all the types are called “cursor” without making distinction except for special reason.

(1) Normal cursor

The cursor is used to select parameter and digit of numeric value. The parameter or the numeric value of the digit at the cursor position can be changed.

Level				
Input Level	-10.0	dBm		
Output Level (Total)	-65.7	dBm	On	Level Continuous Off
AWGN Level	-20.0	dB	Off	

Fig. 4.2.1-1 Normal cursor

(2) Line cursor

The line cursor is displayed in the measurement result display window. The tag in the area indicated with the line cursor enters the active state.

Power Measurement		(Meas. Count : 1/ 1)		
	Avg.	Max	Min	
TX Power	-65.23	-65.23	-65.23	dBm
	300.2	300.2	300.2	pW

Fig. 4.2.1-2 Line cursor

(3) Menu cursor

Cursor displayed in the pop-up windows for all menus by pressing **Functions**. It selects a function menu.

T A G	Power Measurement	T A G	Bit Error Rate
T A G	Frequency Error	T A G	Block Error Rate









Fig. 4.2.1-3 Menu cursor

4.2.2 Moving cursor

The cursor is moved in the following ways:

How the cursor moves when turning the rotary control differs according to the advancement direction specified for the rotary control. If the advancement direction is “Left/Right”, the cursor moves right when the rotary control is turned to the right or left when the rotary control is turned to the left. If the advancement direction is “Up/Down”, the cursor moves down when the rotary control is turned to the right or up when the rotary control is turned to the left. For details about how to specify the rotary control advancement direction, refer to Section 6.19 “Setting advancement direction for using the rotary control to move cursor”.

Table 4.2.2-1 Operating a cursor

Cursor	Operation when “Left/Right” is specified	Operation when “Up/Down” is specified
Moving upward	<ul style="list-style-type: none"> Turn the rotary control to the left.  	<ul style="list-style-type: none"> Turn the rotary control to the left 
Moving downward	<ul style="list-style-type: none"> Turn the rotary control to the right.  	<ul style="list-style-type: none"> Turn the rotary control to the right. 
Moving to the left	<ul style="list-style-type: none"> Turn the rotary control to the left.  	<ul style="list-style-type: none"> 
Moving to the right	<ul style="list-style-type: none"> Turn the rotary control to the right.  	<ul style="list-style-type: none"> 

Note:

Even if an attempt is made to move the line cursor when the window can be scrolled up or down, the window is scrolled and the line cursor remains displayed in the center of the window. When the displayed window section is at the upper or lower end of scroll, the line cursor can be moved up or down.

4.3 Operating Screen

Screen indicates current operation status. Executable functions, display contents and settable parameters vary depending on the screen. To execute a desired function, select a screen that allows to execute the function.

4.3.1 Screen type

The screens vary depending on the measurement software. They are classified into the following two types according to their characteristics:

(1) Measurement screen (Phone-1 or Phone-2 Screen)

A screen to execute a measurement. The types and functions of the measurement screens vary depending on measurement software products.

(2) Common Screen

The common screens provide the functions common for all measurement software. Common screen includes the following screens. Measurement cannot be executed when a common screen is selected.

- System Configuration screen (Setting systems/interface)
- System Information screen (Indicating system information)
- Common External Loss screen (Setting common cable loss)
- Parameter Save screen (Saving parameters)
- Parameter Recall screen (Reading parameters)
- Standard Load screen (Selecting measurement software)

4.3.2 Selecting screen

The screen is selected in the following four ways:

- (1) Press Screen to open the screen selection list and select any screen
- (2) Execute the screen selection function of the user menu
- (3) Execute the screen selection function of the function menu
- (4) Execute the GPIB command to select a screen

- (1) Press Screen to open the screen selection list and select any screen

Normally, press Screen to select a screen. Select any screen from the Screen Select pop-up window displayed by pressing Screen.

Example:

To select the System Information screen: (one of the common screen)

[Procedure]

1. Press Screen to display the Screen Select pop-up window.




Fig. 4.3.2-1 Screen Select

2. Turn the rotary control to move the cursor onto "System Information."

3. If “System Information” cannot be found, turn the rotary control and move the cursor onto the “Select Common Screen” and perform one of the following operations to display the common screen list:
 - Press the rotary control
 - Press
 - Press




Fig. 4.3.2-2 System Information selection

4. Perform one of the following operations to open the System Information screen:
 - Press rotary control
 - Press
 - Press

(2) Executing the screen select function of the user menu

A screen can be opened by executing the screen select function of the user menu. Screen name such as System Information Screen are displayed in the user menu.

Example:

To open System Information screen from System Configuration screen

System Information screen is opened by pressing “System Information Screen” in the System Configuration screen.

(3) Execute the screen select function in the function menu

A screen can be opened by executing the screen select function of the function menu. However, selectable screens in the function menu are limited for some screens. The screen name is displayed with -> mark in the function menu for screen select function.

Example:

To open the System Configuration screen from the Configuration menu

[Procedure]

1. Press **Config** to open Configuration menu



Fig. 4.3.2-3 Configuration menu

2. Press **F1** "System Config" to open System Configuration screen.

(4) Execute the GPIB command to select a screen

A screen can be opened by executing the GPIB command "SCRSEL."

Example:

To open the System Information screen:

■ Example of programming by remote control

```
SCRSEL SYSINFO /*Open the System Information screen*/
```

4.3.3 Scrolling screen

When the scroll bar is displayed at the right edge of the screen (on the left of the function menu), scrolling enables the items that have remained to be displayed.



Fig. 4.3.3-1 Scroll bar

The screen is scrolled by one of the following ways:

Table 4.3.3-1 Scrolling a screen

Scrolling the screen	Operation
Scrolling upward	<ul style="list-style-type: none"> • Turn the rotary control to the left • <input type="button" value="^"/> • <input type="button" value="Scroll Up"/>
Scrolling downward	<ul style="list-style-type: none"> • Turn the rotary control to the right • <input type="button" value="v"/> • <input type="button" value="Scroll Down"/>

When operating , or rotary control, the screen is scrolled together with an up-and-down movement of the cursor. When pressing or , the screen is scrolled by the window width.

4.3.4 Change screen color pattern

It is possible to change the color of the letters, background or other details shown on the screen. There are five color patterns to choose from on the measurement screen.

Press to move to the Color Setting menu. Press the color Pattern function key fitting the color desired.



Fig. 4.3.4-1 Color Setting menu

Example:

To change the screen color pattern to Pattern 2

[Procedure]

1. Press to open the desired measurement screen.
2. Press to display the Color Setting menu.
3. Press "Color Pattern 2" to set screen color pattern to Pattern 2.

4.4 Operating Window

The window is a field to set the measurement condition parameter and display the measurement result. The window is displayed only in the measurement screen, which is unique for each screen.

4.4.1 Window type

Windows can be classified as follows.

- (1) Setting window
A window is for setting the parameter. It is displayed in the lower part of the window area in default.
- (2) Measurement result window
A window to display the measurement result. It is displayed in the upper part of the window area in default.
- (3) Screen specific window
Windows other than setting or measurement result window that are specific for the measurement screen.

Two windows for setting and measurement result are already opened when measurement screens open and they cannot be closed. On the other hand, measurement screen specific windows may require some operations to open and they can be closed.

4.4.2 Window status

Multiple windows can be opened in a screen. A window must be active to operate the window such as changing the window size and setting parameters in the window. One window can be activated in one screen.

Window list bar indicates the window type being opened and active/non-active status.




Fig. 4.4.2-1 Window list bar

Cursor is displayed on the activated window when the windows for Measurement result and setting are displayed.

4.4.3 Activating window

Press to activate the window to be operated. Each time is pressed, active window changes in sequence. Press until the desired window becomes active.

4.4.4 Changing window size

To display more parameters and items in a window, enlarge the window size. The window size can only be changed in the vertical direction on the screen.

To change the window size, select “Window Size” from the function menu. Window size can be specified from Full Window, 70%, 50% or 30%, setting window area vertical width as Full Window.

If two windows are displayed and when changing one window size, another window size changes. For example, if lower active window is specified to display in 70%, upper non-active window is displayed in 30%.

When setting the window size to 100%, all the opened window sizes are set to 100% and an active window is displayed on the window. By pressing , another opened window is activated and displayed in the size of 100%.

Example:

To set the window size to 50%:

[Procedure]

1. Press to change the page of the function menu and display Window Size menu.
2. Press “Window Size” to display Window Size of the function menu.
3. Press “50%” to change the proportion of the window.

■ Example of programming by remote control

```
WINSIZE 50          /*Set the active window size to 50%*/
```

4.4.5 Scrolling window

As with the screen, the window can be scrolled up and down when the scroll bar is displayed. Scrolling the window is effective only for an active window.

The window scrolling operations are described in the table below.

Table 4.4.5-1 Scrolling a window

Scrolling the window	Operation
Scrolling upward	<ul style="list-style-type: none">• Turn the rotary control to the left• <input type="button" value="^"/>• <input type="button" value="Scroll Up"/>
Scrolling downward	<ul style="list-style-type: none">• Turn the rotary control to the right• <input type="button" value="v"/>• <input type="button" value="Scroll Down"/>

When operating , or rotary control, the screen is scrolled together with an up-and-down movement of the cursor. When pressing or , the screen is scrolled by the window width.

4.5 Operating User Menu

User menu is the executable function list displayed in each screen or window. Up to seven functions: U1 to U7 are displayed and user menu is executed by pressing the corresponding user function keys.

User menus are displayed only on the common screen and are all screen select function menus.




Fig. 4.5-1 User menu

4.5.1 Executing user menu

To execute the user menu, Press user function keys on the left of menu to be executed.




Fig. 4.5.1-1 Executing user menu

4.6 Operating Function Menu

Function menu is displayed in each screen or window and executed by pressing the function keys on the right of the menu to be executed.

4.6.1 Viewing function menu

The number of function menu items displayed on one screen is 7 (F1 to F7). The more functions that do not appear are displayed by switching the function menu page number of the function menu.




Fig. 4.6.1-1 Viewing the function menu

1. Menu title:
The title of the function menu is displayed.
2. Menu list:
The function to be executed is displayed.
3. Menu page:
The number of pages for the function menu and page number being selected is displayed.

4.6.2 Switching menu page

When a screen or window has seven or more functions, menus are displayed by switching the pages.

Press to switch the menu page. Press to change the page.

Example:

To switch from page1 to 2 of the function menu.

[Procedure]

1. Page 1 of the function menu is displayed.




Fig 4.6.2-1 Page 1 of the function menu

2. Press .
3. Page 2 of the function menu is displayed.



Fig. 4.6.2-2 Page 2 of the function menu

4.6.3 Displaying menu list of all pages

Menus in all the pages for displayed menu title can be displayed as a list.
Press **Functions** to display all menus.

Functions		
Parameter	Parameter	Parameter
T A G Common	Relative (AF)	Window Size *
T A G Physical Channel		Color Setting *
T A G Call Processing	Handover To GSM	
T A G TX Measurement Setup		Modulation On Off
T A G RX Measurement Setup	Select Scenario	Band Calibration
T A G Audio	Load Scenario	Full Calibration
T A G Fundamental Measurement	Delete Scenario	
1 2 3	1 2 3	1 2 3

Fig. 4.6.3-1 Displaying the all menu list

Operations described in a table below are performed in a pop-up window for all menus.

Table 4.6.3-1 Operating pop-up window for all menus

Pop-up window for all menus	Operation
Display/hide all menus	<input type="button" value="Functions"/>
Move the cursor upward	<ul style="list-style-type: none"> • Turn the rotary control to the left • <input type="button" value="^"/> (Move between pages)
Move the cursor downward	<ul style="list-style-type: none"> • Turn the rotary control to the right • <input type="button" value="v"/> Move between pages
Move the cursor to the left	<input type="button" value="<"/>
Move the cursor to the right	<input type="button" value=">"/>
Execute the menu for cursor	<ul style="list-style-type: none"> • Press the rotary control • <input type="button" value="Set"/> • <input type="button" value="Enter"/>
Execute the menu on the page on which cursor is displayed	<input type="button" value="F1"/> to <input type="button" value="F7"/>

Example:

To perform Band Calibration with all menus displayed

[Procedure]

1. Press to open the desired measurement screen.
2. Press to open the Functions menu.
3. Press and to move the cursor to Band Calibration.
4. Press to start calibration within the system band.

4.6.4 Types of function menus

The following types of function menus are provided according to the functions:

- (1) Execution menu
- (2) Numeric value entry menu
- (3) Character string entry menu
- (4) Item display menu
- (5) Item selection menu
- (6) Tag selection menu
- (7) Toggle menu
- (8) Screen selection menu

4.6.5 Execution menu

Press function key in the execution menu to set execution status for displayed function. Screen selection function and calibration execution function are included in the execution menu.




Fig. 4.6.5-1 Example of an execution menu

Example:

To execute Full Calibration on the measurement screen

Press F6 "Full Calibration" to execute Full Calibration.

4.6.6 Numeric value entry menu

Menu to enter the numeric value for parameter, etc. Pop-up window to enter the numeric value is opened by pressing the function key of the numeric value entry key.









Menus for which a pop-up window opens, including the Numeric value entry menu, are displayed with a # mark.




Fig. 4.6.6-1 Example of a numeric value entry menu

Operations in the pop-up window are described in Table 4.6.6-1.

Table 4.6.6-1 Operations in numeric value entering pop-up window

Numeric value entry	Operation
Increase the value for cursor by 1	<ul style="list-style-type: none"> • Turn the rotary control to the right • 
Reduce the value for cursor by 1	<ul style="list-style-type: none"> • Turn the rotary control to the left • 
Move the cursor to the left	
Move the cursor to the right	
Enter the numeric value	Numeric keypad
Deleting the value for cursor	
Determine the numeric value and entry end /moving to the next entry item*	<ul style="list-style-type: none"> • Press rotary control • 
Determine the numeric value and entry end	
Cancel the entry	

*: For multiple entry items, the cursor selects one entry item. If an entry item is on the right of the cursor, press rotary control or  to determine the numeric value of the current cursor position and move to the next item on the right. If no item is on the right, the value for cursor position is determined.

4.6.7 Character string entry menu

A menu to enter a character string. Press function key of the character string entry menu to open the pop-up window to enter character strings.

Menus for which a pop-up window opens, including the Character string entry menu, are displayed with a # mark.

Operations in the pop-up window are described below.

Table 4.6.7-1 Operations in character string entry pop-up window

Character strings entry	Operation
Move the cursor in the Entry column to the left	<ul style="list-style-type: none"> • <input type="button" value="←"/> • <input type="button" value="↑"/>
Move the cursor in the Entry column to the right	<ul style="list-style-type: none"> • <input type="button" value="→"/> • <input type="button" value="↓"/>
Move the cursor to select the characters to the left.	Turn the rotary control to the left
Move the cursor to select the characters to the right.	Turn the rotary control to the right
Select characters (input to Entry column)	<ul style="list-style-type: none"> • Press rotary control • <input type="button" value="Enter"/>
Determine character strings	<input type="button" value="Set"/>
Chancel entry	<input type="button" value="Cancel"/>

4.6.8 Item display menu

A menu to display item selection menu for displayed item. Press the function key of item display menu to display the item selection menu.

Item display menu is displayed with asterisk (*).



Fig. 4.6.8-1 Example of an item display menu

4.6.9 Item selection menu

This menu is displayed by executing the item display menu. Options on menu title are displayed. Press function key for item selection to select one of the options.




Fig. 4.6.9-1 Example of an item selection menu

4.6.10 Tag selection menu

By pressing the function key for a tag selection menu, the selected tag is activated and displayed at the top of the screen or window. Operations are similar to the execution menu.

TAG mark is displayed on the left of the tag selection menu.



Fig. 4.6.10-1 Example of a tag selection menu

4.6.11 Toggle menu

Toggle menu displays two options. Cursor is displayed on one item, indicating the selected status. Cursor moves alternatively by pressing the function key for toggle menu. Parameter is determined to the value displayed in the toggle menu every time the cursor moves.




Fig. 4.6.11-1 Example of a Toggle menu

4.6.12 Screen selection menu

By pressing the function key for a screen selection menu, the corresponding screen is displayed. Note that only limited screens can be displayed from the screen selection menu.

A “->” mark is displayed on the screen selection menu.



Fig. 4.6.12-1 Example of a screen selection menu

4.7 Setting Parameters

Setting status and measurement conditions are called parameter. In this section, procedures for setting parameters are described for each parameter type.

4.7.1 Settable parameters

Parameters displayed on the setting window can be classified into two types: one that can be changed the value and one that is only for display and no value can be changed. Parameter values may be changed or may not be able to be set because of one parameter value since multiple parameter relate with each other.

Cursor can be moved onto the settable parameter but cannot be move onto the unsettable parameter. Unsettable parameters are closed with parenthesis.

- (1) Settable parameter

A screenshot of a parameter setting window. The text 'Call Processing' is displayed in yellow on a blue background. To the right of the text is a small white square button with a black border and the text 'On' inside.

Fig. 4.7.1-1 Settable parameter

- (2) Unsettable parameter

A screenshot of a parameter setting window. The text 'Frequency Separation (190.0)MHz' is displayed in yellow on a blue background. The value '(190.0)' is enclosed in parentheses.

Fig. 4.7.1-2 Unsettable parameter (for display only)

4.7.2 Parameter type

Parameter can be classified into the following types according to their format and entry methods:

- (1) List selection type
This parameter is used to select an item such as date format from a list of choices.
- (2) Numeric value type
This parameter is used to enter numeric values such as channel number and frequency.
- (3) Numeric value group type
This type of parameter is a set of several numeric value-type parameters. Date and time are of this type.
- (4) Character string type
This parameter is configured of character string to be displayed in a file name and a title.

4.7.3 Parameter setting procedures

Manual parameter setting is performed by procedures below regardless of a parameter type.

[Procedure]

1. Move the cursor onto the parameter to be set.
2. Start entry.
3. Select parameter or enter numeric values or character strings.
4. Determine the entered value.

During remote control, values are directory changed by sending a programming command. All parameters can be set in any screen satisfying setting conditions.

4.7.4 Setting list selection type parameter

The procedure for setting a list-selection-type parameter is as follows:

[Procedure]

1. Turn the rotary control and move the cursor onto the parameter to be set.
2. Start entry by one of the following operations.
 - Press the rotary control
 - Press
 - Press
3. When starting entry, selection list pop-up window is displayed.




Fig. 4.7.4-1 Example of a selection list

4. Turn the rotary control and move the cursor onto the value to be set.
5. Determine the value by one of the following operations.
 - Press the rotary control
 - Press
 - Press
6. Pop-up window is closed and entered value is displayed.

4.7.5 Setting numeric value type parameter

The procedure for setting a numeric-value-type parameter is as follows:

[Procedure]

1. Turn the rotary control to move the cursor onto the parameter to be set.
2. Perform one of the following operations to start entry.
 - Press the rotary control
 - Press
 - Press
 - Press numeric keypad
 - Press
 - Press

} To step 3
} To step 7
3. When starting entry with rotary control, or , the pop-up window to enter the numeric value is opened.



Fig. 4.7.5-1 Example of the numeric value entry pop-up window

4. Enter numeric values by the operations described in Table 4.7.5-1.

Table 4.7.5-1 Operations in the numeric value entry pop-up window

Numeric value entry	Operation
Increase the value for cursor by 1	<ul style="list-style-type: none"> • Turn the rotary control to the right • <input type="button" value="^"/>
Reduce the value for cursor by 1	<ul style="list-style-type: none"> • Turn the rotary control to the left • <input type="button" value="v"/>
Move the cursor to the left	<input type="button" value="<"/>
Move the cursor to the right	<input type="button" value=">"/>
Numeric value entry	Numeric keypad
Reverse the symbol	<input type="button" value="-/+"/>
Delete the value for cursor	<input type="button" value="BS"/>
Cancel the entry operation	<input type="button" value="Cancel"/>

5. Determine the value by one of the following operations. Unit is set to the one displayed on the pop-up window.
 - Press the rotary control
 - Press
 - Press
6. Pop-up window is closed and entered value is displayed.
7. When the value entry starts with numeric keypad, or , the value is displayed according to the entry keys (pressing deletes the previous value). Operation for numeric value entry is described in the table below.

Table 4.7.5-2 Operation for numeric value entry

Numeric value entry	Operation
Numeric value entry	Numeric keypad
Reverse the symbol	<input type="button" value="-/+"/>
Delete the value for the cursor	<input type="button" value="BS"/>
Cancel the entry operation	<input type="button" value="Cancel"/>

8. Determine the value by one of the following operations and finish the entry.
 - Press rotary control
 - Press
 - Press
 } Determined with default unit
 - Press the unit key → Determined with specified unit

4.7.6 Setting numeric value group type parameter

The procedure for setting a numeric-value-group-type parameter is as follows:

[Procedure]

1. Turn the rotary control to move the cursor onto the parameter to be set.
2. Perform one of the following operations to start entry.
 - Press the rotary control
 - Press
 - Press
3. When starting entry, the pop-up window to enter the numeric value is opened.




Fig. 4.7.6-1 Example of the numeric value group entry pop-up window

4. Operation for numeric value entry is described in the table below.

Table 4.7.6-1 Operations in the numeric value group entry pop-up window

Numeric value entry	Operation
Increase the value for the cursor by 1	<ul style="list-style-type: none"> • Turn the rotary control to the right • <input type="button" value="↑"/>
Reduce the value for the cursor by 1	<ul style="list-style-type: none"> • Turn the rotary control to the left • <input type="button" value="↓"/>
Move the cursor to the left	<input type="button" value="←"/>
Move the cursor to the right	<input type="button" value="→"/>
Numeric value entry	Numeric keypad
Reverse the symbol	<input type="button" value="-/+"/>
Delete the value for cursor	<input type="button" value="BS"/>
Cancel the entry operation	<input type="button" value="Cancel"/>
Determine the value where the cursor is placed and move the cursor to the next item.	<ul style="list-style-type: none"> • Press the rotary control • <input type="button" value="Enter"/>

5. Press to determine the entry.
6. The pop-up window is closed and entered value is displayed.

4.7.7 Setting character string parameter

The procedure for setting a character-string-type parameter is as follows:

[Procedure]

1. Turn the rotary control to move the cursor onto the parameter to be set.
2. Perform one of the following operations to start entry.
 - Press the rotary control
 - Press
 - Press
3. When starting entry, the pop-up window to enter the character string is opened.
4. Perform the operations in Table 4.7.7-1 to enter the character string.

Table 4.7.7-1 Operations in character string entry pop-up window

Character string entry	Operation
Move the cursor in the Entry column to the left	<input type="button" value="←"/>
Move the cursor to the character at right most in the Entry column	<input type="button" value="^"/>
Move the cursor in the Entry column to the right	<input type="button" value="→"/>
Move the cursor to the character at left most in the Entry column	<input type="button" value="v"/>
Move the cursor to select the characters to the left	Turn the rotary control to the left
Move the cursor to select the characters to the right	Turn the rotary control to the right
Enter selected characters to the Entry column	<ul style="list-style-type: none"> • Press rotary control • <input type="button" value="Enter"/>
Delete a character just before the cursor in the Entry column	<input type="button" value="BS"/>
Cancel the entry	<input type="button" value="Cancel"/>

5. Press to determine the character string in the Entry column.
6. Finish entry and close the pop-up window.

4.7.8 Setting channel, frequency or level

Pressing the channel level key of the panel key ease the operation to set the input/output channel, frequency and level on the measurement screen.

Table 4.7.8-1 Parameter and channel level key

Parameter	Channel level key
Channel	<input type="button" value="Channel"/>
Input frequency	<input type="button" value="Input Freq"/>
Output frequency Output Freq.	<input type="button" value="Shift"/> + <input type="button" value="Input Freq"/>
Input level	<input type="button" value="Input Level"/>
Output level	<input type="button" value="Output Level"/>

Note:

Concrete parameter types and qualities vary depending on the measurement software.

[Procedure]

1. Press a channel level key corresponding to the parameter to be set.
2. Enter numeric values in the entry area by the operations described in Table 4.7.8-2.

Table 4.7.8-2 Operations in the entry area

Entry area	Panel key
Increase the value for cursor by 1* ¹	<ul style="list-style-type: none"> • Turn the rotary control to the right • <input type="button" value="↑"/>
Reduce the value for cursor by 1* ¹	<ul style="list-style-type: none"> • Turn the rotary control to the left • <input type="button" value="↓"/>
Move the cursor to the left* ²	<input type="button" value="←"/>
Move the cursor to the right* ²	<input type="button" value="→"/>
Enter the numeric value	Numeric keypad
Deleting the value for cursor	<input type="button" value="-/+"/>
Determine the numeric value and entry end /moving to the next entry item* ³	<input type="button" value="BS"/>
Determine the numeric value and entry end	<input type="button" value="Cancel"/>

- *1: When the value is changed, the display value is set (frequency or level changes).
 - *2: This operation is invalid after pressing the numeric keypad, , or . It is validated again by pressing , or the rotary control.
 - *3: Pressing after turning the rotary control or pressing , , or deletes all the displayed value.
-
- 3. Press one of the following keys if the numeric keypad, or is pressed at the end of operations in the entry area.
 - Press rotary control
 - Press
 - Press
 - 4. Press one of the following keys to determine the entry and close the entry area.
 - Press rotary control
 - Press
 - Press

4.8 Tag Operation

Tag is generic name for parameters and display items, which is displayed on the left side of a screen or a window. Each parameter and measurement result belonging to Tag is displayed under the tag. By tracing a tag, parameters and display items can be found speedily.

4.8.1 Tag status

A tag can be active or non-active. Only one tag can be active for one screen or window and other tags are all non-active.

To open a view window or template, a tag for which a view window or template belongs must be active.




Fig. 4.8.1-1 Tag status

4.8.2 Activating tag

A tag can be activated by the following operation.

- (1) Move the cursor onto the parameter belonged to the tag.
- (2) Move the cursor within the tag display area.
- (3) Execute the tag selection menu in the function menu.

(1) Move the cursor onto a parameter belonged to the tag

In the common screen or setting window, tag can be activated by moving the cursor onto a parameter belonged to the tag.

Example:

To activate the Phone-1 (or Phone-2) tag on the System Configuration screen.

[Procedure]

1. Open Configuration screen.
2. Turn the rotary control to move the cursor onto the GPIB Address. As GPIB Address is a parameter that belongs to the Phone-1 (or Phone-2) tag, the Phone-1 (or Phone-2) tag becomes active.

(2) Move the cursor within the tag display area

In the measurement result display window, the tag can be activated by moving the cursor (line cursor) within the tag display area. The tag display area includes the area between a tag and the next tag.

Example:

To activate the Occupied Bandwidth tag on the Fundamental Measurement screen/measurement result window of W-CDMA measurement software.

[Procedure]

1. Open Fundamental Measurement screen.
2. Press Focus to activate the measurement result window by pressing.
3. Turn the rotary control to move the cursor within the display area of the Occupied Bandwidth tag.

(3) Execute the tag selection menu in the function menu

Function menu marked with “TAG” is the tag selection menu. By executing the function menu on which tag name to be activated is written, the tag is activated.

Example:

To activate the Occupied Bandwidth tag on the Fundamental Measurement screen/measurement result window of the W-CDMA measurement software.

[Procedure]

1. Open Fundamental Measurement screen.
2. Press to activate the measurement result window.
3. Press “Occupied Bandwidth.”

4.8.3 Jump to tag

By executing a function menu marked with “TAG,” parameters and display items belonged to a tag can be displayed faster than displaying by scroll. The displayed tag is activated.

4.9 Operating Template

Template is to judge the measurement result waveform. A template can be opened when a mark as shown in the figure below is displayed in the setting window.



Fig. 4.9-1 Template mark

Note:

The screen cannot be switched to another window when a template is opened. Close the template to switch to other window.

4.9.1 Opening template

A template can be opened by the following two methods.

- (1) Open from the setting window.
- (2) Open from the function menu on the view window.

(1) Open from the setting window

[Procedure]

1. Press to open the measurement screen.
2. Press to activate the setting window.
3. Turn the rotary control to move the cursor onto the template mark.
4. Press one of the following keys to open the template.
 - Press rotary control
 - Press
 - Press

(2) Open from the function menu on the view window.

[Procedure]

1. Press to open the view window.
2. Press to display the “Template” menu.
3. Open the template by pressing the “Template” function key.

4.9.2 Closing template

Execute “Close” in the function menu to close the template.

[Procedure]

1. Press to display the first page of the function menu.
2. Press “Close” to close the template.

4.10 Operating View Window

Open the view window to display the measurement waveform. A view window can be displayed for each tag in the measurement result window on the measurement screen. For a tag that can display the view window, a view window mark as shown in the figure below is displayed on the right of the tag.



Fig. 4.10-1 View window mark

4.10.1 Opening view window

A view window is displayed in the measurement result window on the measurement screen.

[Procedure]

1. Press **Screen** to open the measurement screen.
2. Press **Focus** to activate the parameter window.
3. Press “Fundamental Measurement” on the function menu.
4. Set “Measurement Mode” to Normal.
5. Press **Focus** to activate the measurement result window.
6. Activate the tag to which the view window to be displayed is assigned.
7. Press **View** to open the view window.

4.10.2 Closing view window

To close a view window, press **View** while the view window is displayed.

[Procedure]

1. Close the view window by performing one of the followings:
 - Press **View**
 - Press **F7** “Close” on the first page of the function menu

Note:

Operations in the view window differ depending on the view window. Refer to the operation manual of the measurement software.

4.11 Using User Function Keys

The function keys **U1** to **U7** can be pressed to easily manipulate measurement windows, such as by switching the active window or changing the window size.

4.11.1 Selecting active window

The user function keys **U1**, **U2**, and **U3** can be used to select the active window.

Table 4.11.1-1 Selecting the active window

Window to activate	Key to press
Measurement result window	U1
Setting window	U2
Measurement screen-specific window	U3

4.11.2 Changing window size

The user function keys **U4** and **U5** can be used to change the window size proportion.

When **U4** is pressed, the window size proportion increases, using the lower window as a reference. If the lower window has the maximum size when **U4** is pressed, the window is minimized.

When **U5** is pressed, the window size proportion decreases, using the lower window as a reference. If the lower window has the minimum size when **U5** is pressed, the window is maximized.

4.11.3 Changing Item List setting for tag

The user function keys **U6** and **U7** can be used to change the Item List setting for the active tag and to expand or collapse the displayed tag.

When **U6** is pressed, the displayed active tag is collapsed. For example, if Item List is “Detail” when **U6** is pressed, Item List changes to “Standard”. If **U6** is pressed again, Item List changes to “No Display”, and the displayed tag can be collapsed.

When **U7** is pressed, the displayed active tag is expanded. For example, if Item List is “No Display” when **U7** is pressed, Item List changes to “Standard”. If **U7** is pressed again, Item List changes to “Detail”, and the displayed tag can be collapsed.

Chapter 5 Using Common Functions

This chapter describes the operation procedure of the common functions for the measurement software such as initialization, measurement start and methods for saving/reading parameters. Refer to Chapter 6 for the common screen functions.

5.1	Initialization	5-2
5.2	Calibration.....	5-3
	5.2.1 Calibrating communication system band.....	5-3
	5.2.2 Calibrating all input/output bands	5-5
5.3	Starting Measurement	5-6
	5.3.1 Measurement mode.....	5-6
	5.3.2 Starting measurement in Single mode	5-6
	5.3.3 Starting measurement in Continuous mode..	5-6
	5.3.4 Starting measurement in Synchronous single mode	5-7
	5.3.5 Stopping measurement	5-7
5.4	Connecting Call	5-8
	5.4.1 Connecting call	5-8
	5.4.2 Ending call	5-9
5.5	Hard Copy	5-10
	5.5.1 Media and format of saving destination.....	5-10
	5.5.2 Taking hard copy	5-10
5.6	Functions Can be Set Only for Remote Control	5-12
	5.6.1 Setting LCD power source	5-12
	5.6.2 Setting image operation	5-12
	5.6.3 Setting delimiter.....	5-12
	5.6.4 Setting terminator	5-12
	5.6.5 Setting processing at error occurrence	5-13
5.7	Other Functions	5-14
	5.7.1 Outputting non-modulation CW signals.....	5-14

5.1 Initialization

Before starting a new measurement, perform initialization. Initialization returns all the parameters to the known state to prevent from being affected by the previous operations.

The procedure for initialization is as follows.

[Procedure]

1. Press **Preset** to open the Preset menu.
2. Press **F1** “Preset” to execute the initialization.

Notes:

1. Initialization cannot be performed on the Standard Load screen. When the Standard Load screen and Common External Loss screen is displayed, therefore, change the screen to another one before starting initialization by referring to Section 4.3 “Operating a screen.”
2. Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

■ Example of programming by remote control

*RST

Initialization by execution of Preset menu or remote control initializes the following items:

- Selection screen
- All parameters on the measurement screen
- Call processing status
- Measurement status/results display

The following items are not initialized:

- Setting for the System Configuration screen
- Calibration data acquired by executing Band Calibration
- Calibration data acquired by executing Full Calibration
- Screen color pattern

5.2 Calibration

Calibration flattens the frequency characteristics of level accuracy against input and output levels and adjusts the level accuracy changes caused by internal temperature change. Calibration is performed after power is turned on or a terminal to be tested is changed.

Band Calibration and Full Calibration can be performed by a single MT8815B/MT8820B unit. Band Calibration performs calibration within the band of all the communication systems supported by all the measurement software. Full Calibration performs calibration for RF input/output bands for MT8815B/MT8820B.

To perform calibration, execute Band Calibration or Full Calibration in the function menu. Calibration can be performed from any measurement screen or window with the same kind of operation. Calibration cannot be performed on a common screen.

5.2.1 Calibrating communication system band

Band Calibration performs calibration within all the bands of the communication system supported by all the measurement software. Band Calibration takes less time than Full Calibration.

Perform Band Calibration after changing the tested phone, and other occasions.

[Procedure]

1. Press **Screen** to select the desired measurement screen.
2. Press **Next** to switch from the function menu page and display the Band Calibration menu.



Fig. 5.2.1-1 Band Calibration menu

3. Press **F5** “Band Calibration” to perform calibration.

■ Example of programming by remote control

BANDCAL

By using remote control, Band Calibration can be automatically performed when the internal temperature changes by more than the specified temperature range after Band Calibration.

(Example) Automatically performing Band Calibration when the internal temperature changes by 2°C

■ Example of programming by remote control

BANDCAL_TEMP 2

5.2.2 Calibrating all input/output bands

Full Calibration performs calibration on the RF input/output bands (30 to 2700 MHz) for MT8815B/MT8820B.

Full Calibration is performed when the MT8815B/MT8820B is turned on.

The time for the last Full Calibration is displayed at “Full CAL Time” field on System Information screen.

Note:

Wait at least 60 minutes after turning the power on before performing Full Calibration.

After performing Full Calibration once, perform Band Calibration at any time between measurements, such as when replacing phones.

[Procedure]

1. Press to select desired measurement screen.
2. Press to switch function menu page and display the Full Calibration menu.



Fig. 5.2.2-1 Full Calibration menu

3. Press “Full Calibration” to perform calibration.

■ Example of programming by remote control

FULLCAL

5.3 Starting Measurement

A measurement is performed on the measurement screen (Phone-1 or Phone-2 Screen). A measurement cannot be performed on the Common Screen.

Common screen on which a measurement cannot be performed

- System Configuration screen
- System Information screen
- Common External Loss screen
- Parameter Save screen
- Parameter Recall screen
- Standard Load screen

5.3.1 Measurement mode

The following three measurement modes are available:

(1) Single mode

A measurement is performed only once. Averaging measurements are made by the specified number of averaging times (number of measurements).

(2) Continuous mode

A measurement in Single mode is repeated unless the measurement stop condition is met by pressing , etc.

(3) Synchronous single mode (for remote control only)

This mode is only for remote control. A measurement is performed in the single mode. If the measurement is started with SWP command, the next command is not processed until the measurement finishes. This can prevent from returning the response of the measurement result before the measurement completion.

5.3.2 Starting measurement in Single mode

[Procedure]

Press on the measurement screen.

■ Example of programming by remote control

SNGLS

5.3.3 Starting measurement in Continuous mode

[Procedure]

Press on the measurement screen.

■ Example of programming by remote control

CONTS

5.3.4 Starting measurement in Synchronous single mode

[Procedure]

Transmits SWP command on the measurement screen.

■ Example of programming by remote control

SWP

5.3.5 Stopping measurement

To stop a measurement under execution, press on the front panel.

Under remote control, measurement start commands SNGLS, S2 (single) or CONTS, S1 (continuous mode) are used. If SWP or TS command is used, the MEASSTOP command is not processed until the measurement ends.

To check if the measurement is being performed, view the measurement indicator error status area. Refer to Section 4.1.3 “Measurement-indicator/error-status area”.

Note:

A measurement operation is aborted when changing parameters while the measurement is being performed.

[Procedure]

Press during the measurement.

■ Example of programming by remote control

```
SNGLS                      /*Starts a measurement in the single mode*/  
MEASSTOP                   /*Stops a measurement*/
```

5.4 Connecting Call

MT8815B/MT8820B can realize pseudo network function in the mobile communication system. By physically connecting MT8815B/MT8820B to phone with RF cable and connecting a call, establish the communication between the network and the phone to control the phone.

Call processing status to connect/release a call is different depending on the specifications of mobile communication systems. Refer to the operation manual for the measurement software.

This clause describes the basic operations using a panel key.

5.4.1 Connecting call

Connecting a call means establishing communication status between MT8815B/MT8820B and a phone being tested. To connect a call, call from MT8815B/MT8820B (network) or from the phone being tested to MT8815B/MT8820B.

Note:

To connect a call, the call processing status must be in idle (wait).

(1) Calling from MT8815B/MT8820B

Call from MT8815B/MT8820B to the phone as follows:

[Procedure]

1. Connect MT8815B/MT8820B to the phone with RF cable (refer to Section 2.3.3 “Connecting to phone”).
2. Set a parameter required for connecting a call. Then put MT8815B/MT8820B into idle status.
3. Put the phone into idle status. The location or phone number of the phone must be registered to MT8815B/MT8820B.
4. Press Start Call.

(2) Calling from the phone

Call from the phone to MT8815B/MT8820B as follows:

[Procedure]

1. Connect MT8815B/MT8820B to the phone with RF cable (refer to Section 2.3.3 “Connecting to phone”).
2. Set a parameter required for connecting a call. Then put MT8815B/MT8820B into idle status.
3. Put the phone into idle status. The location or phone number of the phone must be registered to MT8815B/MT8820B.
4. Call from the phone using any phone number (emergency call, etc.).

5.4.2 Ending call

Ending a call means terminating communication status between MT8815B/MT8820B and the phone being tested and putting them into idle status. A call can be ended from MT8815B/MT8820B (network) or from the phone, just as when connecting a call.

Note:

To end a call, the call processing status must be in communication. The term indicating communication status varies depending on the measurement software.

(1) Ending from MT8815B/MT8820B

Perform the following procedures to end a call from MT8815B/MT8820B:

[Procedure]

1. Check that the call-processing status is in communication (calling).
2. Press on the front panel.

(2) Ending from the phone

Perform the following procedures to end a call from a phone:

[Procedure]

1. Check that the call-processing status is in communication (calling).
2. Press the button on the phone, or perform the equivalent operation.

5.5 Hard Copy

Hard copy is a function to save an image displayed on LCD of MT8815B/MT8820B in the file. This function is useful for recording the measurement result or waveform or pasting on a report.

5.5.1 Media and format of saving destination

A hard copy is saved in a memory card with a bitmap format file (extension: .bmp). When taking a hard copy of the active screen, the file is saved to the memory card in the bitmap format (which uses the file extension .bmp), and, when taking a hard copy of all screens, the file is saved to the memory card in a compressed format (which uses the file extension .TGZ).

When taking a hard copy of the active screen, The file name is made of two parts: WCACP and a three-digit sequential number plus “.bmp”. The smallest unused number from WCACP000.bmp. to WCAP999.bmp is used. If there are already 1000 files from WCACP000.bmp. to WCAP999 in the save destination folder, saving cannot be performed.

When taking a hard copy of all screens, the file name is made of two parts: WCACP and a three-digit sequential number plus “.TGZ”. The smallest unused number from WCACP000.TGZ. to WCAP999.TGZ is used. If there are already 1000 files from WCACP000.TGZ. to WCAP999 in the save destination folder, saving cannot be performed.

Note:

The file format for a memory card is MS-DOS.

5.5.2 Taking hard copy

[Procedure]

1. Press .
2. Copy is completed when a message “Hard Copy/Complete: WCACP***.BMP” is displayed.

Note:

Never eject the memory card until a message “Hard Copy/Complete: WCACP***.BMP” is displayed.

5.5.3 Taking hard copy of all screens

[Procedure]

1. Press + .
2. When the message “Do you want to copy all screen? –All operation will be locked.(approx 1 minute) –Please don’t remove memory card.” is displayed, turn the rotary control to move the cursor onto “Yes”.
3. Press the rotary control to confirm copying.
4. Copy is completed when message “Hard Copy/Complete: WCACP***.TGZ” is displayed.

Note:

1. Do not remove the memory card under any circumstances before the message “Hard Copy/Complete: WCACP***.TGZ” is displayed.
2. The function for taking a hard copy of all screens cannot be used on the Parameter Save screen, the Parameter Recall screen, the CommonExternal Loss screen, or the Standard Load screen.

5.6 Functions Can be Set Only for Remote Control

This clause describes the special functions that can be executed only in the remote control mode.

5.6.1 Setting LCD power source

Turn the LCD power source off when the mode is remote control and information display on the screen is not required so that electric power consumption can be restrained. In this operation, the measurement throughput can be improved by turning off the image operation.

■ Example of programming by remote control

```
DISPL OFF          /*Turns the LCD power off*/  
DISPL ON           /*Turns the LCD power on (normal display)*/
```

5.6.2 Setting image operation

Turn the image operation off when the mode is remote control and information display on the screen is not required so that the measurement throughput can be improved. This is because time for displaying the measurement result on the screen after the measurement is omitted. “Screen Off” is displayed when the image operation is off.

■ Example of programming by remote control

```
SCREEN OFF         /*Turns the image operation Off*/  
SCREEN ON          /*Turns the image operation On (normal display)*/
```

5.6.3 Setting delimiter

Set the delimiter to be added at the end of a query message for the remote control command. Set the delimiter according to settings of the remote control communication program to be used.

■ Example of programming by remote control

```
DELM 0             /*Sets delimiter to LF*/  
DELM 1             /*Sets delimiter to CR/LF*/
```

5.6.4 Setting terminator

Sets a terminator added at the end of a query message for the remote control command. Set the terminator in conformance with the settings for the remote control communication program currently being used.

■ Example of programming by remote control

```
TRM 0              /*Set the terminator to LF*/  
TRM 1              /*Set the terminator to CR/LF*/
```

5.6.5 Setting processing at error occurrence

Sets a processing for the case when an error occurred.

(1) Normal mode

Continues the processing for succeeding commands ignoring an occurrence of an error. An error pop-up window for the error occurrence is displayed only at the error occurrence, but deleted when the succeeding command is processed.

(2) Error remain mode

Displays the error pop-up window until the next error occurred. If a new error occurs for the succeeding command, an error pop-up window for it is displayed.

(3) Stop mode

When an error occurs, command processing is interrupted while an error pop-up window is being displayed.

The manual control mode can be returned from any mode by pressing Local. In this case, the displayed message is deleted.

■ Example of programming by remote control

```
REMDISP NORMAL      /*Normal mode*/  
REMDISP REMAIN      /*Error remain mode*/  
REMDISP STOP        /*Stop mode*/
```

5.7 Other Functions

5.7.1 Outputting non-modulation CW signals

Normally, RF signals output from MT8815B/MT8820B are modulated signal. However, output of non-modulation CW signal may be required in the special occasion such as a performance test. Return to the normal mode that outputs the modulation signal when a performance test is completed.

The procedure for outputting non-modulation CW signals is as follows.

[Procedure]

1. Press **Screen** to select the desired measurement screen.
2. Press **Next** to switch from the function menu page and display the Modulation menu.




Fig. 5.7.1-1 Modulation menu

3. Press **F4** “Modulation” to output non-modulation CW signals.

■ Example of programming by remote control

```
MOD OFF          /*Outputs non-modulation CW signals*/  
MOD ON           /*Outputs modulation signals (normal mode)*/
```


Chapter 6 Common Screen Functions

This chapter describes the functions and procedures on common screen such as the System Configuration screen and System Information screen.

6.1	Setting Systems and Interfaces	6-3
6.1.1	Opening System Configuration screen.....	6-3
6.1.2	Viewing System Configuration screen.....	6-4
6.1.3	Setting reference frequency	6-11
6.1.4	Displaying date/time or character string	6-12
6.1.5	Setting character string to be displayed	6-13
6.1.6	Setting date display format.....	6-14
6.1.7	Setting date	6-15
6.1.8	Setting time.....	6-16
6.1.9	Setting advancement direction for using rotary control to move cursor.....	6-17
6.1.10	Setting beep sound.....	6-18
6.1.12	Setting IP address and subnet mask for 100Base-TX/10Base-T	6-19
6.1.13	Setting 100Base-TX/10Base-T default gateway	6-20
6.1.14	Setting signal output connector	6-20
6.1.15	Setting remote controller	6-22
6.1.16	Setting GPIB address	6-23
6.1.17	Setting Baud Rate for RS-232C (Serial).....	6-23
6.1.18	Setting Parity for RS-232C (Serial)	6-24
6.1.19	Setting Data Bit for RS-232C (Serial).....	6-24
6.1.20	Setting Stop Bit for RS-232C (Serial)	6-25
6.1.21	Setting IP address and subnet mask for 10Base-T	6-25
6.1.22	Setting 10Base-T default gateway	6-27
6.2	Selecting Measurement Application to be Activated .	6-28
6.2.1	Opening Standard Load screen	6-28
6.2.2	Viewing Standard Load screen.....	6-28
6.2.3	Phone switching operation	6-29
6.2.4	Loading measurement application	6-30
6.2.5	Unloading measurement application	6-30
6.3	Displaying System Information	6-31
6.3.1	Opening System Information screen	6-31
6.3.2	Viewing System Information screen	6-32
6.3.3	Checking Maintenance Information.....	6-37
6.3.4	Checking Software Version	6-37
6.3.5	Checking Software Option.....	6-37
6.3.6	Checking Hardware Revision	6-37

	6.3.7	Outputting System Information parameters...	6-38
6.4		Setting Common Cable Loss	6-39
	6.4.1	Opening Common Cable Loss	6-39
	6.4.2	Viewing Common Cable Loss	6-40
	6.4.3	Setting Common Cable Loss List	6-44
	6.4.4	Deleting Common Cable Loss List	6-45
	6.4.5	Editing Common Cable Loss List	6-45
	6.4.6	Saving Common Cable Loss List	6-46
	6.4.7	Recalling Common Cable Loss List	6-48
	6.4.8	Opening Common cable Loss Graph	6-48
	6.4.9	Viewing Common Cable Loss Graph window	6-49
	6.4.10	Setting the start frequency of Common Cable Loss Graph.....	6-52
	6.4.11	Setting the stop frequency of Common Cable Loss Graph.....	6-53
	6.4.12	Setting the scale on the vertical axis of Common Cable Loss Graph.....	6-53
6.5		Saving Parameters	6-54
	6.5.1	Parameter saving function.....	6-54
	6.5.2	Saving destination of parameter file	6-54
	6.5.3	Parameter saving method	6-55
	6.5.4	Quick saving	6-55
	6.5.5	Quick saving with specified number	6-56
	6.5.6	Opening Parameter Save screen	6-56
	6.5.7	Viewing Parameter Save screen.....	6-57
	6.5.8	Saving file with specified file name.....	6-60
	6.5.9	Overwrite saving.....	6-61
	6.5.10	Updating media information	6-61
6.6		Recalling Parameters	6-62
	6.6.1	Parameter recalling function.....	6-62
	6.6.2	Parameter recalling destination	6-62
	6.6.3	Parameter recalling method	6-62
	6.6.4	Quick recalling	6-63
	6.6.5	Opening Parameter Recall screen	6-63
	6.6.6	Viewing Parameter Recall screen	6-64
	6.6.7	Recalling with file name specified	6-67
	6.6.8	Reloading media information.....	6-67

6.1 Setting Systems and Interfaces

This section describes setting method for MT8815B/MT8820B systems such as reference frequency, date and time, and interfaces such as GPIB. Systems and interfaces are set on the System Configuration screen.

6.1.1 Opening System Configuration screen

[Procedure]

1. Press **Config** to open the Configuration menu.



Fig. 6.1.1-1 Configuration menu

2. System Configuration is opened by pressing **F1** "System Config".

The screen can also be opened by pressing **Screen** to select the screen or using user menu screen switching function

6.1.2 Viewing System Configuration screen



Fig. 6.1.2-1 System Configuration screen (upper: MT8815B, lower: MT8820B)

Parameter

Notes:

1. The following parameters cannot be initialized by Preset.
2. RS232C (Serial) is displayed only for the MT8815B.

(1) Common parameter (tag)

Sets basic system values for MT8815B/MT8820B.

(a) Frequency

(i) Ref. Frequency

Sets the frequency of externally input reference signal.

- Set value: 10 MHz (INT) MT8815B/MT8820B internal
10 MHz Reference signal
- 10 MHz (EXT) External input 10 MHz
Reference signal
- 13 MHz (EXT) External input 13 MHz
Reference signal
- Initial value: 10 MHz (INT)

(b) Display

(i) Display Title

Sets the type of the title to be displayed in the upper-left corner of the screen

- Set value: Off (display Off)
User Define (user-defined character string)
Date/Time (date and time)
- Initial value: Date/Time

(ii) Title

Sets a user-defined character string to be displayed in the upper-left corner of the screen.

- Set value: Up to 25 characters
- Initial value: ANRITSU

(iii) Date Format

Sets the date display format

- Set value: YYYY/MM/DD (Year/Month/Date)
MM/DD/YYYY (Month/Date/Year)
DD/MM/YYYY (Date/Month/Year)
- Initial value: YYYY/MM/DD

(iv) Date (Year/Month/Day)

Sets the date display format.

- Set value: 2001/01/01 to 2030/12/31

(v) Time (Hour:Minute:Second)

Sets the time in 24-hour system.

- Set value: 00:00:00 to 23:59:59

- (c) Key Input
 - Sets advancement direction for using rotary control to move cursor.
 - Set value: Up/Down, Left/Right
 - Initial value: Up/Down
- (d) Hard Copy
 - (i) Format (BMP (Color)) Saves
 - Saves the screen display on the memory card with a bit map format file (extension .bmp).
 - The settings cannot be changed.
- (e) Beep Sound
 - Sets whether or not to beep for an error, etc.
 - Set value: On (beep), Off (does not beep)
 - Initial value: On
- (f) Band Calibration
 - Sets temperature range for warning display after Band Calibration.
 - Set value: 1 to 10 degrees (1 degree steps)
 - Initial value: 2 degrees
- (g) 100BTX/10BT
 - (i) IP Address
 - Sets the IP address for the MT8815B/MT8820B.
 - Set value: 0.0.0.0 to 255.255.255.255
 - Initial value: 192.168.20.3
 - (ii) Subnet Mask
 - Sets the subnet mask for the MT8815B/MT8820B.
 - Set value: 0.0.0.0 to 255.255.255.255
 - Initial value: 255.255.255.0
 - (iii) Default Gateway
 - Sets the default gateway for the MT8815B/MT8820B.
 - Set value: 0.0.0.0 to 255.255.255.255
 - Initial value: 192.168.20.1

(2) Phone-1 (Phone-2) parameter (tag)

Sets the interface for Phone-1 (or Phone-2).

(a) RF Output

Sets the connector for output destination of RF signal.

- Set value: Main, AUX
- Initial value: Main

(b) Remote Interface

(i) Connect to Controller

Sets the controller for the remote control.

- Set value: GPIB
Serial(RS232C)
100BTX/10BT
- Initial value: GPIB

Note:

Serial(RS232C) is displayed only for the MT8815B.

(ii) GPIB Address

Sets the GPIB interface address for remote control.

- Set value: 0 to 30
- Initial value: 1

(iii) Port Number

This is the Ethernet (100Base-TX/10Base-T) port number for the remote control. The port numbers, 56001 and 56002, are assigned to Phone-1 and Phone-2, respectively. The settings cannot be changed.

(c) RS232C (Serial)

(i) Baud Rate

Sets the baud rate (transmission speed) of the communication port used for RS-232C.

- Set value: 38400 bps
19200 bps
9600 bps
4800 bps
2400 bps
1200 bps
- Initial value: 4800 bps

(ii) Parity

Sets the parity check on the communication port used for RS-232C.

- Set value: Even: Even parity
Odd: Odd parity
Off: No parity (None)
- Initial value: Off

(iii) Data Bit

Sets the bit length of the communication port used for RS-232C.

- Set value: 7 bits
8 bits
- Initial value: 8 bits

(iv) Stop Bit

Sets the stop bit for RS-232C.

- Set value: 1 bit
2 bits
- Initial value: 1 bit




Fig. 6.1.2-2 RS232C selection

Note:

The RS232C (Serial) is displayed for only the MT8815B.

(d) 10Base-T

(i) IP Address

Sets the IP address for the MT8815B/MT8820B for Phone-1 (or Phone-2).

- Set value: 0.0.0.0 to 255.255.255.255
- Initial value: 192.168.20.2

(ii) Subnet Mask

Sets the subnet mask of the MT8815B/MT8820B for Phone-1 (or Phone-2).

- Set value: 0.0.0.0 to 255.255.255.255
- Initial value: 255.255.255.0

(iii) Default Gateway

Sets the default gateway of the MT8815B/MT8820B for Phone-1 (or Phone-2).

- Set value: 0.0.0.0 to 255.255.255.255
- Initial value: 192.168.20.1

User menu

User		
Back To GSM	U1	Returns to the measurement screen displayed before switching to the common function screen. The display varies depending on the measurement software.
	U2	None
Standard Load Screen	U3	Opens the Standard Load screen.
System Information Screen	U4	Opens the System Information screen.
External Loss Screen	U5	Opens the Common External Loss screen.
Parameter Save Screen	U6	Opens the Parameter Save screen.
Parameter Recall Screen	U7	Opens the Parameter Recall Screen.
1		

Function menu

System Config.

T
A
G Common

F1 Activates the Common parameter tag.

T
A
G Phone-1

F2 Activates the Phone-1 (or Phone-2) parameter tag. ("Phone-2" is displayed for Phone-2.)

F3 None

F4 None

F5 None

F6 None

F7 None

1

6.1.3 Setting reference frequency

Set the reference frequency to be used for measurement.

In addition to the 10 MHz internal reference signal, MT8815B/MT8820B can use the 10 MHz or 13 MHz external reference signal input from the 10 MHz/13 MHz Ref. In on the rear panel. By default, the 10 MHz internal reference signal is set.

Example:

To use an externally input 10 MHz reference signal

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Ref.Frequency."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "10 MHz (EXT)."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

```
REF 10MHZEXT      /*To set to external input 10 MHz reference sig-  
                    nal*/
```

Note:

Check that the reference signal code is connected to the reference signal input connector when using external input reference signals.

6.1.4 Displaying date/time or character string

The Title displayed in the upper left of the screen can be selected from among the date/time, any character string, and display off. The date/time cannot be displayed together with a character string.

Displaying the date and time

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Display Title."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "Date/Time."
6. Press the rotary control to display date and time.

■ Example of programming by remote control

TTL DATE

Displaying any character string

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Display Title."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "User Define."
6. Press the rotary control to display the character string.

■ Example of programming by remote control

TTL USER

Setting title display to Off

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Display Title."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "Off."
6. Press the rotary control to set the title display off.

■ Example of programming by remote control

```
TTL OFF
```

6.1.5 Setting character string to be displayed

Up to 25 characters can be set for the character string to be displayed in the left end of the screen. By default, "ANRITSU" is set.

Example:

To set the character string of the title to "Line1":

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Title."
4. Press the rotary control to open the pop-up window for entering the title.
5. Press **BS** to delete the already entered characters.
6. Turn the rotary control to move the cursor in the file list onto "L."
7. Enter "L" in the Entry column.
8. Enter "i", "n", "e", and "1" in the same way.
9. Press **Set** to fix the title.
10. Set "Display Title" to "User" to display the set character string.

■ Example of programming by remote control

```
TITLE "Line1"          /*Sets the character string*/  
TTL USER               /*Display the character string*/
```

6.1.6 Setting date display format

MT8815B/MT8820B is able to set the date display format. By default, the date is displayed in the format of year/month/day order.

Example:

To display the date in the format of month/day/year (MM/DD/YYYY):

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Date Format."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "MM/DD/YYYY."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

DATEMODE MDY

6.1.7 Setting date

The date can be adjusted. The date is set in order of year, month, and day, regardless of the display format.

Example:

To set the date to December 24, 2003:

[Procedure]

1. Press to open the Configuration menu.
2. Press "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Date (Year/Month/Day)"
4. Press the rotary control to open the pop-up window.
5. Press the numeric keypad to set the year to 2003.
6. Press the rotary control to determine the year, and then move the cursor to the month column.
7. Press the numeric keypad to set the month to 12.
8. Press the rotary control to determine the month and then move the cursor to the day column.
9. Press the numeric keypad to set the day to 24.
10. Press to end the setting.

■ Example of programming by remote control

DATE 2003,12,24

Note:

Press to end the input while the cursor is on the year or month column.

6.1.8 Setting time

The time for the internal clock can be adjusted. The time is set and displayed on a 24-hour system.

Example:

To set the time to 12:15:00:

[Procedure]

1. Press to open the Configuration menu.
2. Press "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto [Display Time (Hour:Minute:Second)].
4. Press the rotary control to open the pop-up window.
5. Press the numeric keypad to set the hour to 12.
6. Press the rotary control to determine the hour, and then move the cursor to the minute column.
7. Press the numeric keypad to set the minute to 15.
8. Press the rotary control to determine the minute, and then move the cursor to the second column.
9. Press the numeric keypad to set the second to 00.
10. Press to end the setting.

■ Example of programming by remote control

TIME 12,15,00

Note:

Press to end the input while the cursor is on the year or month column.

6.1.9 Setting advancement direction for using rotary control to move cursor

The advancement direction for using the rotary control to move the cursor can be set. It is set to Up/Down by default.

Example:

To set the rotary control advancement direction to “Left/Right”:

[Procedure]

1. Press Config to open the Configuration menu.
2. Press F1 “System Config” to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto [Encoder].
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto “Left/Right”.
6. Press the rotary control to fix the value.

■ Example of programming by remote control

ENCODER LEFTRIGHT

6.1.10 Setting beep sound

Beep sound emitted at the error of setting operation can be set. It is set to On by default.

Example:

To set the beep sound to Off:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Beep Sound."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "Off."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

ALARM OFF

6.1.11 Setting temperature range for warning display

The range in which to warn that the internal temperature has changed after performing Band Calibration can be set. If the temperature increases (or decreases) by more than the specified temperature range after performing Band Calibration, a warning is displayed. It is set to 2°C by default.

Example:

To set a temperature range of 2°C:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Warning Range".
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to set the Warning Range to 2.
6. Press the rotary control to fix the value.

■ Example of programming by remote control

CALCHK_RANGE 2

6.1.12 Setting IP address and subnet mask for 100Base-TX/10Base-T

MT8815B/MT8820B can perform remote control by using Ethernet (100Base-TX/10Base-T). TCP/IP is used as the protocol.

Ethernet (100Base-TX/10Base-T) IP address cannot be set by remote control. Set IP address by manual operation before performing the remote control.

This section describes the setting method for the IP Address and Subnet Mask of Ethernet (100Base-TX/10Base-T).

The IP address for MT8815B/MT8820B can be set in “IP Address” within “100BTX/10BT” on the System Configuration screen.

The subnet mask for MT8815B/MT8820B can be set in “Subnet Mask” within “100BTX/10BT” on the System Configuration screen.

The default setting for the IP address is 192.168.20.3 and subnet mask is 255.255.255.0.

Example:

To set the IP address to 192.168.0.5 and subnet mask to 255.255.255.0:

[Procedure]

1. Press to open the Configuration menu.
2. Press “System Config” to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto “IP Address” in “100BTX/10BT.”
4. Press the rotary control to open the pop-up window.
5. Press the numeric keypad to enter 192. Entering a 3-digit number moves the cursor to the next entry box.
6. Press the numeric keypad to enter 168.
7. Press the numeric keypad to enter 0.
8. Move the cursor to next entry box by pressing .
9. Press the numeric keypad to enter 5.
10. Press to fix the value.
11. In the same manner, set subnet mask by moving cursor onto “Subnet Mask.”

6.1.13 Setting 100Base-TX/10Base-T default gateway

Set the Default Gateway that is used to connect to the external network. The default setting is 192.168.20.1.

Ethernet (100Base-TX/10Base-T) default gateway cannot be set by remote control. Set default gateway by manual operation before performing the remote control.

Example:

To set default gateway to 192.168.0.1:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Default Gateway" in "100BTX/10BT."
4. Press the rotary control to open the pop-up window.
5. Press the numeric keypad to enter 192. Entering a 3-digit number moves the cursor to the next entry box.
6. Press the numeric keypad to enter 168.
7. Press the numeric keypad to enter 0.
8. Move the cursor to the next entry box by pressing **>**.
9. Press the numeric keypad to enter 1.
10. Press **Set** to fix the value

6.1.14 Setting signal output connector

Set whether the RF signal of MT8815B/MT8820B is output from the Main1 Input/Output connector or from the AUX1 output connector. The signal output to Phone-1 is output from the RF1 connector.

The signal output to the Phone-2 is output from the RF2 connector.

The signal output connector is set in any of the following ways:

- (1) Opening the Configuration menu from any screen for setting
- (2) Use the System Configuration screen for setting

Opening the Configuration menu from any screen for setting RF output connector

[Procedure]

1. Press **Config** to open the “Configuration” menu.
2. Press **F2** “RF-1 (2) Config” to open the “RF-1 (2) Configuration” pop-up window.
3. Turn the rotary control to move the cursor onto “RF Output.”
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto the connector that outputs the RF signal.
6. Press the rotary control to determine the value.
7. Turn the rotary control to move the cursor onto “Close.”
8. Press the rotary control to close the pop-up window.

Using the System Configuration screen for setting

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** “System Config” to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto “RF Output” of “Phone-1” (or “Phone-2”).
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto the connector that outputs the RF signal.
6. Press the rotary control to fix the value.

■ Example of programming by remote control

RFOUT MAIN / *Sets output destination to Main* /

6.1.15 Setting remote controller

This section explains how to set the remote controller to be used.

Example:

To set the remote controller to Ethernet (100Base-TX/10Base-T):

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** “System Config” to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto “Connect to Controller”.
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto “100BTX/10BT”.
6. Press the rotary control to fix the value.

6.1.16 Setting GPIB address

The computer performing remote control searches for the measuring instrument that receives the instructions sent from the computer, based on the GPIB address. Before performing remote control through the GPIB interface, confirm that the address set in the computer matches the address of MT8815B/MT8820B. The address that can be set on MT8815B/MT8820B is primary address.

GPIB address cannot be set by remote control. Set GPIB address by manual operation before performing the remote control.

Example:

To set the GPIB address for Phone 1 to 3:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open System Configuration screen.
3. Turn the rotary control to move the cursor onto "GPIB – Address" of "Phone-1."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to set the GPIB address to 3.
6. Press the rotary control to fix the value.

6.1.17 Setting Baud Rate for RS-232C (Serial)

Sets the baud rate (transmission speed) of the communication port used for the RS-232C.

Example:

To set the baud rate of the communication port to 1200 bps:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open System Configuration screen.
3. Turn the rotary control to move the cursor onto "Baud Rate."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "1200 bps."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

BAUD 1200

6.1.18 Setting Parity for RS-232C (Serial)

Sets the parity check of the communication port used for the RS-232C.

Example:

To set the parity check of the communication port to Even:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open System Configuration screen.
3. Turn the rotary control to move the cursor onto "Parity."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "Even."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

PRTY EVEN

6.1.19 Setting Data Bit for RS-232C (Serial)

Sets the bit length of the communication port used for the RS-232C.

Example:

To set the bit length of the communication port to 7 bits:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open System Configuration screen.
3. Turn the rotary control to move the cursor onto "Data Bit."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "7 bits."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

DTAB 7

6.1.20 Setting Stop Bit for RS-232C (Serial)

Sets the stop bit of the communication port used for the RS-232C.

Example:

To set the bit length of the communication port to 2 bits:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open System Configuration screen.
3. Turn the rotary control to move the cursor onto "Stop Bit."
4. Press the rotary control to open the pop-up window.
5. Turn the rotary control to move the cursor onto "2 bits."
6. Press the rotary control to fix the value.

■ Example of programming by remote control

STPB 2

6.1.21 Setting IP address and subnet mask for 10Base-T

Using corresponding measurement software and its optional functions, it is possible to conduct IP protocol communication via the MT8815B/MT8820B between a phone connected to its RF connector and a server connected to its 10Base-T port.

This section describes the setting method for the IP Address and Subnet Mask of the MT8815B/MT8820B.

The IP address for MT8815B/MT8820B can be set in "IP Address" within "10Base-T" on the System Configuration screen.

The subnet mask for MT8815B/MT8820B can be set in "Subnet Mask" within "10Base-T" on the System Configuration screen.

The default setting for the IP address is 192.168.20.2 and subnet mask is 255.255.255.0.

The IP address for the phone connected to Main 1 Input/Output connector (or Main 2 Input/Output connector for the Phone-2) can be set on the measurement screen. For further details, refer to the manuals for measurement software and options.

Note:

Before carrying out data communication with the MT8815B/MT8820B, be sure to confirm that the IP address, subnet mask and default gateway are all set correctly.

Example:

To set the IP address to 192.168.0.5 and subnet mask to 255.255.255.0:

[Procedure]

1. Press **Config** to open the Configuration menu.
2. Press **F1** "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "IP Address" in "10Base-T."
4. Press the rotary control to open the pop-up window.
5. Press the numeric keypad to enter 192. Entering a 3-digit number moves the cursor to the next entry box.
6. Press the numeric keypad to enter 168.
7. Press the numeric keypad to enter 0.
8. Move the cursor to next entry box by pressing **>**.
9. Press the numeric keypad to enter 5.
10. Press **Set** to fix the value.
11. In the same manner, set subnet mask by moving cursor onto "Subnet Mask."

■ Example of programming by remote control

PSETIPADDR 192,168,0,5

PSETSNM 255,255,255,0

6.1.22 Setting 10Base-T default gateway

Set the Default Gateway that is used to connect to the external network using the MT8815B/MT8820B data communication function. The default setting is 192.168.20.1.

Example:

To set default gateway to 192.168.0.1:

[Procedure]

1. Press to open the Configuration menu.
2. Press "System Config" to open the System Configuration screen.
3. Turn the rotary control to move the cursor onto "Default Gateway" in "10Base-T."
4. Press the rotary control to open the pop-up window.
5. Press the numeric keypad to enter 192. Entering a 3-digit number moves the cursor to the next entry box.
6. Press the numeric keypad to enter 168.
7. Press the numeric keypad to enter 0.
8. Move the cursor to the next entry box by pressing .
9. Press the numeric keypad to enter 1.
10. Press to fix the value.

■ Example of programming by remote control

PSETDEFGTWY 192,168,0,1

6.2 Selecting Measurement Application to be Activated

Measurement applications can be switched faster by activating the measurement applications installed in the MT8815B/MT8820B in advance. Up to three measurement applications can be selected for each phone.

6.2.1 Opening Standard Load screen

[Procedure]

- 1. Press **Screen** to open the Select Screen pop-up window.
- 2. Turn the rotary control to move the cursor onto “Standard Load.”
- 3. Press the rotary control to open the Standard Load screen.

The Standard Load screen can also be opened by the screen switching function of user menu.

6.2.2 Viewing Standard Load screen



Fig. 6.2.2-1 Standard Load screen

- (1) Standard Load Window
Select a measurement application (software) to be loaded to the Phone-1 (or Phone-2). Up to three applications can be set (Standard 1 through Standard 3).
Note:
The software operates the same, irrespective of the Standard in which the software is loaded.
- (2) Software List Window
Displays a list of applications installed in the MT8815B/MT8820B.

User menu

User	
Back To GSM	U1 Returns to the measurement screen displayed before switching to the common function screen. The display varies depending on the measurement software.
System Config. Screen	U2 Opens the System Configuration screen.
	U3 None
System Information Screen	U4 Opens the System Information screen.
External Loss Screen	U5 Opens the Common External Loss screen.
Parameter Save Screen	U6 Opens the Parameter Save screen.
Parameter Recall Screen	U7 Opens the Parameter Recall screen.
1	

6.2.3 Phone switching operation

Switches the Phone to be displayed on the LCD or to be operated by the panel.

[Procedure]

1. Press **Shift** + **Screen**.

When Phone-1 is displayed, it is switched to Phone-2. When Phone-2 is displayed, it is switched to Phone-1.

■ Example of programming by remote control

This operation cannot be controlled by remote.

6.2.4 Loading measurement application

Select measurement applications from those installed in the MT8815B/MT8820B in advance, so that the switching among the measurement applications can be executed faster. Up to three measurement applications can be selected for each phone measurement set.

The following shows the procedure to load measurement application.

[Procedure]

1. Display the Standard Load screen. Refer to Section 6.2.1 “Opening Standard Load screen” for setting method.
2. Turn the rotary control to move the cursor onto “Standard1.”
3. Press to select the measurement application to be loaded.

Note:

Even if software has already been loaded in the selected Standard, it is possible to load other software in that Standard by overwriting the existing one.

■ Example of programming by remote control

```
STDLOAD 1,GSM /*Loads GSM to Standard1*/
```

6.2.5 Unloading measurement application

This section describes how to unload the measurement application.

[Procedure]

1. Display the Standard Load screen. By referring to the section 6.2.1 “Opening Standard Load screen.”
2. Turn the rotary control to move the cursor onto “Standard1.”
3. Press “Unload” to open the pop-up window for verification.
4. Turn the rotary control to move the cursor onto “OK”, and Press .

■ Example of programming by remote control

```
STDUNLOAD 1 /*Unloads Standard1 software*/
```

6.3 Displaying System Information

Version information and serial number about software that composes MT8815B/MT8820B can be displayed on the screen. All the system information is displayed on the System Information screen.

6.3.1 Opening System Information screen

[Procedure]

1. Press Screen to open the Select Screen pop-up window.
2. Turn the rotary control to move the cursor onto “System Information.”
3. Press the rotary control to open the System Information screen.

The System Information screen can also be opened by the screen switching function of user menu.

6.3.2 Viewing System Information screen




Fig. 6.3.2-1 System Information screen
(upper: MT8815B, lower: MT8820B)

- (1) Maintenance Information
 - (a) Serial Number
The serial number of the MT8815B/MT8820B
 - (b) Power On Time
The accumulated time (total power-on time) for the MT8815B/MT8820B
 - (c) Full Cal Time
The date and time when Full Calibration was last executed
 - (d) CF Type
The size of the internal CF card
 - (e) CF Unused Area
The free space size in the software installation area
- (2) Software Version
 - (a) Firmware
 - (i) MT8815B/MT8820B
The version of the firmware installed in the MT8815B/MT8820B
 - (ii) IPL
The version of the IPL installed in the MT8815B/MT8820B
 - (iii) OS
The version of the OS installed in the MT8815B/MT8820B
 - (b) Standard
The version of the software loaded in the MT8815B/MT8820B
- (3) Software Option
The list of the software options installed in the MT8815B/MT8820B
- (4) Hardware Revision
The information about the hardware installed in the MT8815B/MT8820B is displayed.
 - (a) Main CPU
The ID and revision number of the main CPU are displayed.
 - (b) TDMA COM
The ID, revision number, and CoreFPGA version of the TDMA COM are displayed.

Note:

When the MT8820B Parallel Phone Measurement Hardware and MX882010C Parallel Phone Measurement Software are installed, TDMA COM1 is displayed for Phone-1 and TDMA COM2 is displayed for Phone-2.

(c) CDMA2000 COM

The ID, revision number, and CoreFPGA version of the CDMA2000 COM are displayed.

Note:

When the MT8820B Parallel Phone Measurement Hardware and MX882010C Parallel Phone Measurement Software are installed, CDMA2000 COM1 is displayed for Phone-1 and CDMA2000 COM2 is displayed for Phone-2.

(d) 1xEV-DO COM

The ID and revision number of the 1xEV-DO COM are displayed.

Note:

When the MT8820B Parallel Phone Measurement Hardware and MX882010C Parallel Phone Measurement Software are installed, 1xEV-DO COM1 is displayed for Phone-1 and 1xEV-DO COM2 is displayed for Phone-2.

(e) W-CDMA COM

The ID and revision number of the W-CDMA COM are displayed.

Note:

When the MT8820B Parallel Phone Measurement Hardware and MX882010C Parallel Phone Measurement Software are installed, W-CDMA COM1 is displayed for Phone-1 and W-CDMA COM2 is displayed for Phone-2.

(f) Measure DSP

The ID, revision number, and CoreFPGA version of the Measure DSP are displayed.

Note:

When the MT8820B Parallel Phone Measurement Hardware and MX882010C Parallel Phone Measurement Software are installed, Measure DSP1 is displayed for Phone-1 and Measure DSP2 is displayed for Phone-2.

(g) DAC/ADC

The ID and revision number of the DAC/ADC are displayed.

(h) Audio

The CoreFPGA version of the Audio is displayed.

User menu

User		
Back To GSM	U1	Returns to the measurement screen displayed before switching to the common function screen. The display varies depending on the measurement software.
System Config. Screen	U2	Opens the System Configuration screen.
Standard Load Screen	U3	Opens the Standard Load screen.
	U4	None
External Loss Screen	U5	Opens the Common External Loss screen.
Parameter Save Screen	U6	Opens the Parameter Save screen.
Parameter Recall Screen	U7	Opens the Parameter Recall Screen.
1		

Function menu

System Info.

T
A Maintenance
G Information

F1

Displays Maintenance Information and activates the tag.

T
A Software
G Version

F2

Displays Software Version and activates the tag.

T
A Software
G Option

F3

Displays Software Option and activates the tag.

T
A Hardware
G Revision

F4

Displays Hardware Revision and activates the tag.

F5

None

Information
Save

F6

Executes Information Save.

F7

None

1

6.3.3 Checking Maintenance Information

The following gives an explanation about how to check Maintenance Information in the System Information screen.

[Procedure]

1. Open the System Information screen.
2. Press **F1** “Maintenance Information” to display and check Maintenance Information.

6.3.4 Checking Software Version

The following gives an explanation about how to check Software Version in the System Information screen.

[Procedure]

1. Open the System Information screen.
2. Press **F2** “Software Version” to display and check Software Version.

6.3.5 Checking Software Option

The following gives an explanation about how to check Software Option in the System Information screen.

[Procedure]

1. Open the System Information screen.
2. Press **F3** “Software Option” to display and check Software Option.

6.3.6 Checking Hardware Revision

The following gives an explanation about how to check Hardware Revision in the System Information screen.

[Procedure]

1. Open the System Information screen.
2. Press **F4** “Hardware Revision” to display and check Hardware Revision.

6.3.7 Outputting System Information parameters

Various parameters displayed in the System Information screen can be output (saved) to a memory card in text format.

[Procedure]

1. Insert a memory card in the memory card slot on the front panel of the MT8815B/MT8820B.
2. Press **F6** “Information Save” to save the parameters displayed in the System Information screen to the memory card.

Table 6.3.7-1 Parameters in System Information screen to be saved

Parameters	Description
File Date	Date when Information Save was executed
Serial Number	Serial number of MT8815B/MT8820B
Time Information	Power On Time
Phone1 Time	Full Cal Time (Phone1)
Phone2 Time	Full Cal Time (Phone2)
CF Information	CF Type and CF Unused Area
Installed Software	Information about all installed measurement software applications
Load Software	Information about the loaded software
Software Option	Information about all the installed options
Hardware Revision	Information about the installed hardware

Notes:

1. Phone2 Time is displayed only when the MT8820B Parallel Phone Measurement Hardware and MX882010C Parallel Phone Measurement Software are installed in the MT8820B.
2. The parameters are saved in a text-formatted file with the fixed file name “SysInfo.txt.” If this file already exists when saving, it is overwritten.
3. The file output destination is “/MT8820B” in the memory card.

■ Example of programming by remote control

SYSINFOSAVE

6.4 Setting Common Cable Loss

The Common Cable Loss setting screen consists of the Common Cable Loss List and the Common Cable Loss Graph window and enables you to set the common cable loss that can be used in common between the systems.

Setting common cable loss is enabled when the External Loss is set to Common for all the systems.

Example:

To set the External Loss to “Common” by GSM:

[Procedure]

1. Press **Screen** to open the Select Screen pop-up window.
2. Turn the rotary control to move the cursor onto “Fundamental Measurement.”
3. Press the rotary control to open the Fundamental Measurement screen.
4. Press **Focus** several times until the Parameter window is activated.
5. Press **F1** “Common” to move the cursor onto “External Loss.”
6. Press the rotary control to display the pop-up window.
7. Turn the rotary control to move the cursor to “Common.”
8. Press the rotary control to fix the value.

6.4.1 Opening Common Cable Loss

[Procedure]

1. Press **Screen** to open the Select Screen pop-up window.
2. Turn the rotary control to move the cursor onto “Common External Loss.”
3. Press the rotary control to open the Common External Loss screen.

Other than the above, there is the method to use the screen switching function in the user menu.

6.4.2 Viewing Common Cable Loss

2006/05/25 13:07

Phone-1

<Common External Loss>

#-CDMA

Ext. Loss List

Ext. Loss View

User	No.	Frequency [MHz]	DL (Main) [dB]	UL (Main) [dB]	DL (AUX) [dB]	Loss List
Back To #-CDMA	1	300.000000	15.00	-20.00	30.00	Regist Loss into List
	2	500.000000	0.00	-10.00	10.00	
	3	1000.000000	20.00	0.00	-20.00	
System Config. Screen	4	2000.000000	40.00	-40.00	0.00	Delete Loss from List
	5	2500.000000	30.00	15.00	-10.00	
	6	2700.000000	55.00	0.00	-55.00	
Standard Load Screen	7	-----	-----	-----	-----	Edit Loss of List
	8	-----	-----	-----	-----	
	9	-----	-----	-----	-----	
System Information Screen	10	-----	-----	-----	-----	Delete All List
	11	-----	-----	-----	-----	
	12	-----	-----	-----	-----	
	13	-----	-----	-----	-----	
	14	-----	-----	-----	-----	
	15	-----	-----	-----	-----	
Parameter Save Screen	16	-----	-----	-----	-----	Save List
	17	-----	-----	-----	-----	
	18	-----	-----	-----	-----	
Parameter Recall Screen	19	-----	-----	-----	-----	Load List
	20	-----	-----	-----	-----	
	21	-----	-----	-----	-----	
1	22	-----	-----	-----	-----	1

Fig. 6.4.2-1 Ext. Loss List screen

(1) Frequency

Sets the frequency of the Common Cable Loss List.

- Range 0.4 to 2700 MHz
- Setting unit Hz/kHz/MHz/GHz
- Initial value —
- Resolution 10 Hz

(2) DL (Main)

Sets Downlink of Main in the Common Cable Loss List.

- Range -55.00 to +55.00 dB
- Setting unit dB
- Initial value —
- Resolution 0.01 dB

(3) UL (Main)

Sets Uplink of Main in the Common Cable Loss List.

- Range -55.00 to +55.00 dB
- Setting unit dB
- Initial value —
- Resolution 0.01 dB

(4) DL (AUX)

Sets Downlink of AUX in the Common Cable Loss List.

- Range -55.00 to +55.00 dB
- Setting unit dB
- Initial value —
- Resolution 0.01 dB

Notes:

1. The common cable list always displays 100 lists and the values of the lists for only the registered data are displayed.
2. One of values displayed in the list is further added at the time of registering Frequency value.

User menu

User	
Back To GSM	U1 Returns to the measurement screen displayed before switching to the common function screen. The display varies depending on the measurement software.
System Config. Screen	U2 Opens the System Configuration screen.
Standard Load Screen	U3 Opens Standard Load screen.
System Information Screen	U4 Opens the System Information screen.
	U5 None
Parameter Save Screen	U6 Opens the Parameter Save screen.
Parameter Recall Screen	U7 Opens the Parameter Recall screen.
1	

Function menu

Loss List	
Regist Loss into List	F1 Opens the Regist Loss into List menu.
Delete Loss from List	F2 Opens the Delete Loss from List menu.
Edit Loss of List	F3 Opens the Edit Loss of List menu.
Delete All List	F4 Opens the Delete All List menu.
	F5 None
Save List	F6 Opens the Save List menu.
Load List	F7 Opens the Load List menu.
1	

6.4.3 Setting Common Cable Loss List

The following gives an explanation about how to set the values of the common cable loss.

Example:

To set the common cable loss list to the value of “2500.000000, 30.00, 15.00, -10.00”:

[Procedure]

1. Press **F1** “Regist Loss into List” to open the Regist Loss into List menu.
2. Press the numeric keypad to enter 2500.000000. Entering an 11-digit number moves the cursor automatically to “DL (Main).”
3. Press the numeric keypad to enter 30.00.
4. Press **>** to move the cursor to “UL (Main).”
5. Press the numeric keypad to enter 15.00.
6. Press **>** to move the cursor to “DL (AUX).”
7. Press the numeric keypad to enter -10.00.
8. Press **Set** to fix the value.

If the same value as the already registered Frequency is set, the overwrite confirmation pop-up window opens. However, for remote control, it is overwritten without condition.

Notes:

1. The common cable loss list can be also directly entered for the list: the value is directly entered at the position where a cursor exists.
2. When the Regist Loss into List is set or a frequency is set by the direct entry, automatic sorting* of No. is performed.

*: Automatic sorting is to sort lists in ascending order for a frequency.

■ Example of programming by remote control

LOSSTBLVAL 2500.000000MHz,30.00,15.00,-10.00

6.4.4 Deleting Common Cable Loss List

The following gives an explanation about how to delete the values of the common cable loss.

Example:

To delete Nos. 3 to 5 of the common cable loss list:

[Procedure]

1. Press **F2** “Delete Loss From List” to open the Delete Loss From List menu.
2. Press the numeric keypad to enter 3.
3. Press **>** to move the cursor.
4. Press the numeric keypad to enter 5.
5. Press **Set** to fix the value.

Notes:

1. Using **F4** “Delete All List” enables all to be deleted.
2. To delete only one list, specify only the left entry box.

■ Example of programming by remote control

```
DELOSSTBL 3,5      /*To delete Nos. 3 to 5 of the common cable loss  
list*/  
DELOSSTBL          /*To delete all of the common cable loss list*/
```

6.4.5 Editing Common Cable Loss List

The following gives an explanation about how to edit the values of the common cable loss.

Example:

To edit the registered common cable loss list, “2500.0000 , 30.00,15.00,-10.00”, to the value of “2600.000000, 30.00, -25.00, -10.00”:

[Procedure]

1. Turn the rotary control to move the cursor to the list that you want to edit.
2. Press **F3** “Edit Loss of List” to open the Edit Loss of List menu.
3. Press **BS** to delete already entered characters.
4. Press the numeric keypad to enter 2600.000000.
5. Press **>** to move the cursor to the UL (Main).
6. Press **BS** to delete already entered characters.
7. Press the numeric keypad to enter -25.00.
8. Press **Set** to fix the value.

If the same value as the already registered Frequency is set, the overwrite confirmation pop-up window opens. However, for remote control, it is overwritten without condition.

6.4.6 Saving Common Cable Loss List

The following gives an explanation about how to save the common cable loss list on a memory card by specifying any file name.

Up to 500 files can be saved onto one memory card. An attempt made to save 501 or more files causes an error.

Note:

During saving, do not remove a memory card or not turn the power off.

Example:

To save the common cable loss list with a file named “SAMPLE.LSS”:

[Procedure]

1. Insert a memory card into the memory card slot on the front panel of the MT8815B/MT8820B.
2. Press **F6** "Save List" to open the Save List menu.
3. Turn the rotary control to move the cursor to "S" on the character pallet.
4. Press the rotary control to enter "S" in the "File Name" column.
5. Also, enter "A", "M", "P", "L", and "E" in the "File Name" column in the same way.
6. Press **Set** to save the file.

If a file of the same name exists, the overwrite confirmation pop-up window opens. To overwrite, press "OK." To change the file name, place the cursor onto "Cancel" and press the rotary control.

Note:

During remote control, overwrite-confirmation and other operations are not performed. To prevent important data from being overwritten, be careful about file management for remote control.

■ Example of programming by remote control

SVLOSSTBL sample

6.4.7 Recalling Common Cable Loss List

The following gives an explanation about how to recall the common cable loss list from the memory card by specifying any file name.

Note:

During saving, do not remove a memory card or not turn the power off.

Example:

To recall the common cable loss list with a file named "SAMPLE.LSS":

[Procedure]

1. Insert a memory card into the memory card slot on the front panel of the MT8815B/MT8820B.
2. Press **F7** "Load List" to open the Load List menu.
3. Turn the rotary control to select "SAMPLE"
4. Press **Set** to load the file.

Note:

The common cable loss list can be also loaded for a user-created file in csv format of separation by "," (comma).

Example:

When it is created with data of "2500.000000, 30.00, 15.00, -10.00" and "2600.000000, 30.00, -25.00, -10.00", remake data in a text file as shown below, and save it as the extension of ".lss."

1,2500.000000,30.00,15.00,-10.00
2,2600.000000,30.00,-25.00,-10.00

■ Example of programming by remote control

RLLOSSTBL sample

6.4.8 Opening Common cable Loss Graph

[Procedure]

1. Open the Common External Loss screen.
2. Press **Focus** to activate the Ext. Loss View.

6.4.9 Viewing Common Cable Loss Graph window

The Common Cable Loss window enables you to confirm the entire loss value simply by graphing the common cable loss list. When the common cable loss is not registered, the initial value becomes 0 dB.




Fig. 6.4.9-1 Ext. Loss View screen

Notes:

1. The dashed line on the horizontal axis is always divided into 10 sections and the values are displayed on the both sides and center.
2. The common cable loss value between the setting frequencies is compensated in linearity.

Example:

When 20 dB is set at a frequency of 1000 MHz and 40 dB at 2000 MHz for the DL (Main) respectively, 30 dB is automatically compensated at 1500 MHz. In addition, 20 dB is set at 1000 MHz or less, and 40 dB at 2000 MHz or more. It is also set for UL (Main) and DL (AUX) in the same way.

Function menu


(1) The first page

The menu on the first page is the selection menu of all the common cable loss graph window. Pressing the function key displays the corresponding menu, activating the tag.

Loss View	
Start Frequency	F1 Opens the Start Frequency menu.
Stop Frequency	F2 Opens the Stop Frequency menu.
	F3 None
	F4 None
	F5 None
Save List	F6 Opens the Save List menu.
Load List	F7 Opens the Load List menu.
1 2	This indicates that the first page is open. To open the second page, press Next .

(2) The second page

For the menu on the second page, the vertical axis scale of the common cable loss graph menu can be set.



F1

A key to set the vertical axis scale on the graph of the common cable loss graph window to ± 60 dB and display an additional line in 10-dB steps.

F2

A key to set the vertical axis scale on the graph of the common cable loss graph window to ± 50 dB and display an additional line in 10-dB steps.

F3

A key to set the vertical axis scale on the graph of the common cable loss graph window to ± 40 dB and display an additional line in 10-dB steps.

F4

A key to set the vertical axis scale on the graph of the common cable loss graph window to ± 30 dB and display an additional line in 10-dB steps.

F5

A key to set the vertical axis scale on the graph of the common cable loss graph window to ± 20 dB and display an additional line in 5-dB steps.

F6

A key to set the vertical axis scale on the graph of the common cable loss graph window to ± 10 dB and display an additional line in 5-dB steps.

F7

None

This indicates that the second page is open.

To open the first page, press **Next**.

6.4.10 Setting the start frequency of Common Cable Loss Graph

The following gives an explanation about how to set the start frequency on the horizontal axis.

Example:

To set the start frequency of the common cable loss graph to “100.0 MHz.”

[Procedure]

1. Press **F1** “Start Frequency” to open the Start Frequency menu.
2. Press the numeric keypad to enter 100.0.
3. Press **MHz** unit key to fix the value.

Start Frequency

- Range 0.4 to 2700.0 MHz
- Setting unit Hz/kHz/MHz/GHz
- Initial value 0.4 MHz
- Resolution 0.1 MHz

Note:

Cannot set the value larger than the value of the Stop Frequency.

■ Example of programming by remote control

```
LOSSVIEW_STAFREQ 100.0MHz
```

6.4.11 Setting the stop frequency of Common Cable Loss Graph

The following gives an explanation about how to set the stop frequency on the horizontal axis.

Example:

To set the stop frequency of the common cable loss graph to “2500.0 MHz.”

[Procedure]

1. Press **F2** “Stop Frequency” to open the Stop Frequency menu.
2. Press the numeric keypad to enter 2500.0.
3. Press **MHz** unit key to fix the value.

Stop Frequency

- Range 0.4 to 2700.0 MHz
- Setting unit Hz/kHz/MHz/GHz
- Initial value 0.4 MHz
- Resolution 0.1 MHz

Note:

Cannot set the value smaller than the value of the Start Frequency.

■ Example of programming by remote control

LOSSVIEW_STPFREQ 2500.0MHz

6.4.12 Setting the scale on the vertical axis of Common Cable Loss Graph

The following gives an explanation about how to set the scale of the vertical axis.

Example:

To set the scale of the vertical axis to ± 30 dB:

[Procedure]

1. Press **Next** to switch the function menu.
2. Press **F4** “Vertical Scale 30 dB.”

Vertical Scale

- Range 10, 20, 30, 40, 50, 60
- Initial value 50 dB

■ Example of programming by remote control

LOSSVIEW_VSCALE 30

6.5 Saving Parameters

6.5.1 Parameter saving function

Parameter saving function can save the set value for measurement parameter as a parameter file. Measurement parameters that can be saved are all the measurement parameters for the activated measurement software (used for the phone under measurement).

Saved parameter files can be recalled by the parameter recalling function. By recalling the parameter file, set value for the measurement parameter can be returned the status when the file is saved.

By using parameter saving and recalling function, parameter setting operation can be complete by only one recalling and no repetition is required for every measurement. Preparing several parameter setting files eliminates the need for setting parameters again and can increase the efficiency of operation and measurement.

6.5.2 Saving destination of parameter file

Parameter file is saved in the directory of the memory card. Directory path for the saving destination is specific for each measurement software.

Up to 1000 files can be saved onto one memory card. An attempt made to save 1001 or more files causes an error.

Notes:

1. Check that the memory card is correctly inserted in the memory card slot on the front panel before saving a parameter file.
2. Do not exit the memory card during the parameter saving. Doing so may cause not only the interruption for saving but also destruction of other files in the memory card.
3. Take a back-up data for a file saved in the memory card to other media. Anritsu is not liable for the data loss of a memory card.

6.5.3 Parameter saving method

Parameters saving methods are described below.

- (1) Quick saving
Saves the parameter in any screen. Only a file number to identify a file can be specified.
- (2) Saving on the Parameter Save screen
Saves on the Parameter Save screen. Any file name can be specified.

6.5.4 Quick saving

Quick saving means that any screen other than the Parameter Save screen is used to save a parameter setting file. The file can be saved with easily without opening the Parameter Save screen.

For quick saving, file name is made up of WCAPR and a file number. Only a file number that identifies each file can be specified. The smallest unused number will be used as the file number.

[Procedure]

1. Press + to display the entry area. the smallest unused number is displayed in the entry area.



Fig. 6.5.4-1 Entry area for the Quick saving

2. Press to start saving.

■ Example of programming by remote control

PRMSAVE

Note:

Quick saving can be used on the CommonExternal Loss screen or the Standard Load screen.

6.5.5 Quick saving with specified number

Any number can be specified for a file number in quick saving.

Example:

To save parameter file with file number 005.

[Procedure]

1. Press + to display the entry area. the smallest unused number is displayed in the entry area.
2. Press .
3. Press to start saving.

■ Example of programming by remote control

PRMSAVE 5

If a file of the same name exists, the overwrite confirmation pop-up window opens. To overwrite, press “OK.” To change the file name, move the cursor onto “Cancel” and press the rotary control.

Note:

During remote control, overwrite confirmation and other operations are not performed. To prevent important data from being overwritten, use the default file name for saving under remote control.

6.5.6 Opening Parameter Save screen

Use the Parameter Save screen to save the parameter setting by specifying any file name.

Method for opening the Parameter Save screen is as follows.

[Procedure]

1. Press to open the Screen Select pop-up window.
2. Turn the rotary control to move the cursor onto “Parameter Save.”
3. Press the rotary control to open the Parameter Save screen.

Instead of the above procedure, the screen switch function from the user menu can be used to open the Parameter Save screen.

6.5.7 Viewing Parameter Save screen




Fig. 6.5.7-1 The Parameter Save screen

(1) Media Information

1. Media
Storage media type for the parameter file saving destination.
2. Volume Label
Volume label for a storage medium.
3. Unused Area
Unused area capacity of a storage medium is displayed in the byte unit.

(2) File List

File List displays directory contents for parameter file saving in a storage medium. A directory path for parameter saving is specified for each measurement software.

4. Directory
Directory path for parameter saving.
5. File Name
File name in the directory for parameter saving.
6. Date, Time
Last update date/time of a file.

7. Create New File

Move the cursor and press the rotary control or Set to open the pop-up window for newly saving the parameter file.

Note:

To display the parameter file on the Parameter Save screen, parameter file must be in the default directory (specific for each measurement software). To display a parameter file saved in other media, move the file to the default directory in the medium using external devices such as computer.

User menu

User		
Back To GSM	U1	Returns to the measurement screen displayed before switching to the common function screen. The display varies depending on the measurement software.
System Config. Screen	U2	Opens the System Configuration screen.
Standard Load Screen	U3	Opens the Standard Load screen.
System Information Screen	U4	Opens the System Information screen.
External Loss Screen	U5	Opens the Common External Loss screen.
	U6	None
Parameter Recall Screen	U7	Opens the Parameter Recall Screen.
1		

Function menu

Operation		
	F1	None
	F2	None
	F3	None
	F4	None
	F5	None
Reload Media Information	F6	Reloads the storage media information to update the display.
	F7	None
1		

6.5.8 Saving file with specified file name

Use the Parameter Save screen to save the parameter setting by specifying any file name.

Example:

To save parameter information to the new file named “Example”:

[Procedure]

1. Press to open the Screen Select pop-up window
2. Turn the rotary control to move the cursor onto “Parameter Save.”
3. Press the rotary control to open the Parameter Save screen.
4. Turn the rotary control to move the cursor in the file list onto “Create New File.”
5. Press the rotary control to open the pop-up window for entering a new file name.
6. Turn the rotary control to move the cursor onto “E.”
7. Press the rotary control to enter “E” in the “File Name” column.
8. Also, enter “x”, “a”, “m”, “p”, “l”, and “e” in the same way.
9. Press to start saving.

■ Example of programming by remote control

```
PRMSAVENAME "Example"
```

If a file of the same name exists, the overwrite confirmation pop-up window opens. To overwrite, press “OK.” To change the file name, place the cursor onto “Cancel” and press the rotary control.

Note:

During remote control, overwrite confirmation and other operations are not performed. To prevent important data from being overwritten, use the default file name for saving under remote control.

6.5.9 Overwrite saving

A setting file can be overwritten to an existing file. The overwrite saving methods are as follows:

- (1) Specify the number of the name of the file to be overwritten by quick saving, and select “OK” from the overwrite saving confirmation pop-up window.
- (2) Place the cursor to the name of the file to be overwritten on the Parameter Save screen to execute saving, and select “OK” from the overwrite saving confirmation pop-up window.

The procedure for saving the file by placing the cursor onto the file name to be overwritten on the Parameter Save screen for is shown below:

[Procedure]

1. Press Screen to open the Screen Select pop-up window.
2. Turn the rotary control to move the cursor onto “Parameter Save.”
3. Press the rotary control to open the Parameter Save screen. In the file list, the already saved setting files appear.
4. Turn the rotary control to move the cursor onto the name of the file to be overwritten.
5. Press the rotary control to open the pop-up window for entering a new file name.
6. Press Set to open the overwrite confirmation pop-up window.
7. Turn the rotary control to move the cursor onto “OK.”
8. Press the rotary control to start saving.

6.5.10 Updating media information

“File List” on the Parameter Save list displays file list of saving destination for parameter files. To update media information that is displayed in the file list on the Parameter Save screen, execute Reload Media Information from the function menu.

[Procedure]

Press F6 “Reload Media Information” on the Parameter Save screen.

6.6 Recalling Parameters

6.6.1 Parameter recalling function

Parameter recalling function can recall a parameter file saved in parameter saving function and return all the parameters of activated measurement software to the status when it is saved.

6.6.2 Parameter recalling destination

A parameter file is recalled from the fixed directory. The directory path for the recalling destination is specific for each measurement software.

Notes:

1. Check that the memory card is correctly inserted in the memory card slot before recalling a parameter file.
2. Do not exit the memory card during the parameter saving. Doing so may cause not only the interruption for saving but also destruction of other files in the memory card.

6.6.3 Parameter recalling method

The procedure for parameter recalling is shown below.

- (1) Quick recalling
Recalls on any screen. Only the number that identifies a file can be specified.
- (2) Recalling with a file name specified
Recalling on the Parameter Recall screen. Any file name can be specified.

6.6.4 Quick recalling

Quick recalling means that any screen other than the Parameter Recall screen is used to recall a parameter setting file. The file can be saved by an easy operation without opening the Parameter Recall screen. For quick recalling, file name is made up of WCAPR and a file number. Only a file number that identifies each file can be specified. It is therefore impossible to recall files saved with an optional name.

Example:

To recall the file of the file number 001

[Procedure]

1. Press **Recall** to display the entry area in the lower part of the screen. In the entry area, a file number appears.
2. Press **1** on the numeric keypad to enter the file number.
3. Press the rotary control to open the pop-up window for confirmation.
4. Turn the rotary control to move the cursor onto "OK."
5. Press the rotary control to recall the file.

■ Example of programming by remote control

PRMRECALL 001

Note:

Quick recalling cannot be used on the CommonExternal Loss screen or the Standard Load screen.

6.6.5 Opening Parameter Recall screen

When the Parameter Save screen has been used to save a parameter settings with any file name, the Parameter Recall screen is used to recall the file.

The procedures for opening the Parameter Recall screen are shown below.

[Procedure]

1. Press **Screen** to open the screen selection window.
2. Turn the rotary control to move the cursor onto "Parameter Recall."
3. Press the rotary control to open the Parameter Recall screen.

Instead of the above procedure, the screen switch function from the user menu can be used to open the Parameter Recall screen.

6.6.6 Viewing Parameter Recall screen




Fig. 6.6.6-1 The Parameter Recall screen

- (1) Media Information
 1. Media
Storage media type for the parameter file recalling destination.
 2. Volume Label
Volume label for a storage medium.
 3. Unused Area
Unused area capacity of a storage medium is displayed in the byte unit.
- (2) File List
File List displays directory contents for parameter file recalling in a storage medium. A directory path for parameter recalling is specified for each measurement software.
 4. Directory
Directory path for parameter recalling.
 5. File Name
File name in the directory for parameter recalling.
 6. Date, Time
Last update date/time of a file.

User menu

User		
Back To GSM	U1	Returns to the measurement screen displayed before switching to the common function screen. The display varies depending on the measurement software.
System Config. Screen	U2	Opens the System Configuration screen.
Standard Load Screen	U3	Opens the Standard Load screen.
System Information Screen	U4	Opens the System Information screen.
External Loss Screen	U5	Opens the Common External Loss screen.
Parameter Save Screen	U6	Opens the Parameter Save screen.
	U7	None
1		

Function menu

Operation		
	F1	None
	F2	None
	F3	None
	F4	None
	F5	None
Reload Media Information	F6	Reloads the storage media information to update the display.
	F7	None
1		

6.6.7 Recalling with file name specified

When the Parameter Save screen has been used to save a parameter settings with any file name, the Parameter Recall screen is used to recall the file.

Example:

To recall the parameter setting file named “Example”:

[Procedure]

1. Press **Screen** to open the screen selection window.
2. Turn the rotary control to move the cursor onto “Parameter Recall.”
3. Press the rotary control to open the Parameter Recall screen. In the file list, the saved setting files appear.
4. Turn the rotary control to move the cursor onto the file name to be recalled.
5. Press the rotary control to open the execution confirmation pop-up window.
6. Turn the rotary control to move the cursor onto “OK.”
7. Press the rotary control to recall the file.

■ Example of programming by remote control

```
PRMRECALLNAME "Example"
```

6.6.8 Reloading media information

To reload media information that is displayed in the file list, execute Reload Media Information on the function menu.

[Procedure]

On the Parameter Recall screen, press **F6** “Reload Media Information.”

Chapter 7 Remote Control Using PC

This chapter describes setting up the remote control and control method of the MT8815B/MT8820B using a command.

7.1	Remote Control.....	7-3
7.1.1	What remote control can do	7-3
7.1.2	Operation in remote control mode.....	7-3
7.1.3	Operation in manual operation mode	7-3
7.1.4	Interface.....	7-4
7.1.5	Difference between manual operation and remote control.....	7-4
7.1.6	Switching between control modes.....	7-6
7.2	GPIO Interface	7-7
7.2.1	Setup of GPIO.....	7-7
7.2.2	Network configuration.....	7-8
7.2.3	Conditions for network configuration	7-9
7.3	Serial Interface.....	7-10
7.3.1	Setup of Serial(RS-232C).....	7-10
7.3.2	Serial (RS-232C) standards	7-11
7.4	Ethernet (100Base-TX/10Base-T) Interface	7-12
7.4.1	Setup of Ethernet (100Base-TX/10Base-T) ..	7-12
7.4.2	Network Configuration	7-14
7.5	Command Syntax	7-15
7.5.1	Command notations in this manual	7-15
7.5.2	Elements of command syntax	7-16
7.5.3	Setting parameters with unit specified.....	7-18
7.5.4	Response unit.....	7-19
7.6	Command Programming Guide	7-20
7.7	Status Report	7-21
7.7.1	Standard status model.....	7-22
7.7.2	Standard event status register.....	7-23
7.7.3	Standard event status enable register.....	7-25
7.7.4	Status byte register.....	7-26
7.7.5	Service request enable register.....	7-28
7.7.6	END event status register	7-29
7.7.7	END event status enable register.....	7-32
7.7.8	ERR event status register	7-33
7.7.9	ERR event status enable register.....	7-36

7.8	Establishing Synchronization.....	7-37
7.8.1	Difference of synchronization depending on measurement start command.....	7-37
7.8.2	Establishing synchronization with *OPC? query	7-37
7.8.3	Establishing synchronization corresponding to status register status	7-37

7.1 Remote Control

Remote control refers to controlling the MT8815B/MT8820B with a PC connected. Most of the functions of the MT8815B/MT8820B can be controlled from computer, except some functions such as the power switch.

7.1.1 What remote control can do

The following operation can be performed by remote control.

- (1) Computer-based operation implements automatic measurement and automatic analysis of measurement data.
- (2) A measurement system can be configured in combination with a computer and other measuring instruments.

7.1.2 Operation in remote control mode

While the Remote lamp on the front panel is on, MT8815B/MT8820B is operating in the remote control mode. All the panel keys except for the power switch and **Local** are disabled.



Fig. 7.1.2-1 Remote lamp on

Note:

When the Parallelphone Measurement Software is installed in MT8820B, the display for Phone-1 and Phone-2 can be switched by pressing **Shift** + **Screen** even if the MT8820B is operating in the remote control mode.

7.1.3 Operation in manual operation mode

While the Remote lamp on the front panel is Off, MT8815B/MT8820B is operating in the manual operation (local control) mode. In the manual operation mode, MT8815B/MT8820B is operated by pressing keys arranged on the front/rear panels.



Fig. 7.1.3-1 Remote lamp Off

7.1.4 Interface

MT8815B/MT8820B uses the IEEE488.2-compliant GPIB interface and Ethernet (100Base-TX/10Base-T) for remote control. A Serial (RS-232C) interface can be used only with the MT8815B. However, GPIB, Serial, and Ethernet (100Base-TX/10Base-T) cannot be used at the same time.






When using the GPIB interface, variety of measurement systems may be configured by using other GPIB devices in combination. The GPIB connectors are located on the rear panel of the MT8815B/MT8820B. Furthermore, even when using Ethernet (100Base-TX/10Base-T), multiple measurement systems can be set when connecting multiple devices and the computer via network hubs.

Note:

Refer to Section 6.1.2 (2) (b) “Interface” for switching between GPIB and Serial on the MT8815B.

7.1.5 Difference between manual operation and remote control

Differences between manual operation (local control) and remote control are described below.

- (1) Single functions of the following panel keys cannot be used in the remote control mode:
 - Power switch
 - Cursor keys
 - Rotary control
 - 
 - 
 - 
 - 
 - 

- (2) While parameters to be set are selected using the rotary control to start changing the parameters in the local control mode, commands are sent to directly change the parameters in the remote control mode.
- (3) To read set values and measurement results on the screen, a query command is sent and read the responded value.
- (4) Cursor movement, screen scroll, page expansion of menu, etc. are available only in the local control mode.
- (5) Setting and reading of GPIB address, IP address, and gateway of Ethernet (100Base-TX/10Base-T) are available only in the local control mode.
- (6) Setting of the interface (settings of status byte, IEEE488.2, etc.) is available only in the remote control mode.
- (7) Displayed unit on the screen may differ from the response unit for remote control. In the remote control mode, a value is always returned in a predetermined remote control unit.

7.1.6 Switching between control modes

- (1) Switching from the remote control mode to the local control mode

To switch MT8815B/MT8820B from the remote control mode to the local control mode, press on the front panel. Pressing turns the Remote lamp Off, and switches MT8815B/MT8820B into the local control mode. Send the GTL command for the Remote control.

Note:

When the Parallelphone Measurement Software is installed, pressing switches only the displayed Phone into the local control mode. For Remote control, sending a GTL command to GPIB-1 changes Phone-1 into the local control mode, and sending a GTL command to GPIB-2 changes Phone-2 into the local control mode.

- (2) Switching from the local control mode to the remote control mode

To switch MT8815B/MT8820B from the local control mode to the remote control mode, send a remote control command via GPIB or Serial interface. Sending a command turns the Remote lamp On and switches MT8815B/MT8820B into the remote control mode.

Note:

When the Parallelphone Measurement Software is installed, sending a remote control command to GPIB-1 turns the Remote lamp On while Phone-1 is displayed. Sending a remote control command to GPIB-2 turns the Remote lamp On while Phone-2 is displayed.

7.2 GPIB Interface

The GPIB is an interface standardized by IEEE488.1 and IEEE488.2 that is in widespread use to control measuring instruments and peripherals by computer.

7.2.1 Setup of GPIB

This section describes how to set up the GPIB for remote control. The setup procedures are as follows:

[Procedure]

1. Set up the computer and GPIB board.
Refer to the manual for your GPIB board and computer.
2. Connect MT8815B/MT8820B to the computer by using GPIB cable
Refer to Section 2.3.4 “Connecting GPIB cable.”
3. Set the GPIB address of MT8815B/MT8820B.
Select the System Configuration screen and set GPIB Address for the Phone-1 (or Phone-2) tag. Refer to Section 6.1.11 “Setting GPIB address.”
4. Set the remote controller.
Select the System Configuration screen to set the [Connect to Controller] in the Phone-1(2) tag to [GPIB]. For more information, refer to 6.1.15 “Setting remote controller”.
5. Activate the GPIB communication program of the computer and set GPIB address in conformance with the MT8815B/MT8820B.

Refer to the operation manual for your measurement software.

7.2.2 Network configuration

Devices connected with the GPIB interface may have the network configuration of serial connection or star connection as shown in the figure below.




Fig. 7.2.2-1 Serial connection




Fig. 7.2.2-2 Star connection

7.2.3 Conditions for network configuration

The GPIB interface has the following restrictions in order to secure the inter-device communications. Configure the network within these restrictions.

- (1) Length of a cable between devices shall be 4 m or shorter. Average distance between devices connected to the bus shall be 2 m or shorter.
- (2) The entire length of the cables shall be 20 m or shorter. Number of devices that can be connected to a bus is 15 or below, two thirds or above of which shall be powered on.

7.3 Serial Interface

The Serial interface is compliant with RS-232C standards. It is widely used to control measuring instruments from computer.

Note:

The remote control using the serial interface functions for only the MT8815B.

It cannot be used for the MT8820B.

7.3.1 Setup of Serial(RS-232C)

This section describes how to set up the Serial interface for remote control. The setup procedure are as follows:

[Procedure]

1. Connect MT8815B/MT8820B to the computer by using RS-232C cable. Be sure to connect the RS-232C cable, before turning on the MT8815B/MT8820B.,

2. Set the Band rate, Parity, Data bit, and Stop bit of MT8815B/MT8820B.

Select the System Configuration screen and set Baud rate, Parity, Data bit, and Stop bit for the Phone-1 (or Phone-2) tag. Refer to Section 6.1.17 “Setting Baud Rate for RS-232C (Serial)”, 6.1.18 “Setting Parity for RS-232C (Serial)”, 6.1.19 “Setting Data Bit for RS-232C (Serial)”, and 6.1.20 “Setting Stop Bit for RS-232C (Serial)”.

3. Set the remote controller.

Select the System Configuration screen to set the [Connect to Controller] in the Phone-1(2) tag to [Serial(RS-232C)]. For more information, refer to 6.1.15 “Setting remote controller”.

4. Activate the Serial communication program of the computer and set Serial interface in conformance with the MT8815B/MT8820B.

Refer to the operation manual for your measurement software.

7.3.2 Serial (RS-232C) standards

The standards for the Serial port (RS-232C) on the MT8815B are shown in Table 7.4.1-1.

Table 7.3.1-1 Standards

Item	Standard value
Function	Control from an external controller (except power switch)
Communication method	Asynchronous (start-stop sync.), half duplex
Communication control method	None
Baud rate	4800
Data bit	8 bits
Parity	None (NON)
Start bit	1 bit
Stop bit	1 bit
Flow control	Xon/Xoff
Connector	D-Sub 9-pin, male

7.4 Ethernet (100Base-TX/10Base-T) Interface

Ethernet (100Base-TX/10Base-T) is compliant with IEEE802.3 standards. The Ethernet interface can be used to set multiple measurement systems when connecting multiple devices and the computer via network hubs.

7.4.1 Setup of Ethernet (100Base-TX/10Base-T)

This section describes how to set up Ethernet (100Base-TX/10Base-T) for remote control. The setup procedures are as follows:

[Procedure]

1. Connect MT8815B/MT8820B to the computer or network hub by using LAN crossover cable.
The connector for the LAN crossover cable is attached to the rear panel. Connect the LAN crossover cable before turning on MT8815B/MT8820B.
2. Set the IP address and subnet mask of MT8815B/MT8820B.
Select the System Configuration screen and set IP Address and subnet mask. For more information, refer to Section 6.1.12 “Setting IP address and subnet mask for 100Base-TX/10Base-T”.
3. Set the gateway of Ethernet (100Base-TX/10Base-T) in the MT8815B/MT8820B.
Set the gateway of MT8815B/MT8820B.
Select the System Configuration screen and set Gateway. Refer to section 6.1.13 “Setting 100Base-TX/10Base-T default gateway”.
4. Set the remote controller.
Select the System Configuration screen to set [Connect to Controller], which is in the Phone-1(2) tag, to [100BTX/10BT]. For more information, refer to Section 6.1.15 “Setting remote controller”.
5. Start the Ethernet communication program and set the IP address, subnet mask, gateway, and port number.

The communication with MT8815B/MT8820B is data communication via the TCP connection. For communication, creating a communication program (socket client) at the remote control computer side is required. For the socket interface used for communication, see the operation manuals of the computer performing remote control, the network interface board installed, and the driver software.

Notes:

1. IP address

In a network using TCP/IP, devices connected to the network are identified by IP addresses. An IP address must therefore be assigned to each device. An IP address is a 32-bit number, and expressed as four 8-bit portions separated by dots (called dot notation).

IP addresses include network information in addition to the device (host) information. The data lengths of the network part and host part of an IP address is defined depending on the network class. Class C has 24-bit network part and 8-bit host part, and up to 254 hosts can be connected. Classes A through E are available; however, only Classes A through C are normally used.

Table 7.4.1-2 IP address

Class	Network part length	Host part length	Number of hosts that can be assigned
A	8 bits	24 bits	16,777,214 units
B	16 bits	16 bits	65,534 units
C	24 bits	8 bits	254 units

2. Subnet mask

The subnet mask is used to indicate the network part in the IP address when the network is divided into subnets. The network part of the IP address above (including the extended subnet part) is indicated by "1", and the host part is defined by "0". If this setting is wrong, IP packets cannot be transmitted or received correctly to or from the connected network that uses subnets.

3. Gateway

A device called a gateway is used to connect networks. Gateways include dedicated devices such as routers. In a TCP/IP network, IP packets can be directly exchanged within the same network. To exchange IP packets among different networks (i.e., terminals that have IP addresses with different network parts), however, communication with a device connecting to other network connected to the gateway via the gateway is required.

4. Port number

The TCP/ IP port number is 56001 for Phone-1 and 5602 for Phone-2 respectively. Each value is fixed.

7.4.2 Network Configuration

Devices connected with the Ethernet interface may have the network configuration of serial connection or star connection as shown in the figure below.

Use LAN crossover cable to connect the MT8815B/MT8820B and an external device. Use a network hub when connecting to multiple external devices.

Remote controller (PC)




Fig. 7.4.2-1 Direct connection (Ex: MT8820B)




Fig.7.4.2-2 Star connection (Ex: MT8820B)

Note:

External devices may experience difficulty in communicating with the MT8815B/MT8820B, depending on the status of communications between them. A LAN crossover-cable connection is recommended to ensure communication stability.

7.5 Command Syntax

7.5.1 Command notations in this manual

This operation manual classifies the device messages used for the MT8815B/MT8820B into three categories, shown below:

(1) Command

A command executes a specific MT8815B/MT8820B function or changes the setting.


(2) Query

A query makes an inquiry about the setting of MT8815B/MT8820B or information on the MT8815B/MT8820B status.

(3) Response

On receiving a query, MT8815B/MT8820B returns the specified information as a response to the computer.

Relationship between command types and notations in this manual are shown in Fig. 7.5.1-1.



Terms closed with parenthesis are notations in this manual

Fig. 7.5.1-1 Command types and notations in this manual

7.5.2 Elements of command syntax

The command is a character string composed of alphabets, numeric values and symbols, which include a header and a parameter as character strings to determine command function, and syntax elements of command such as a question mark (?) and a space.

- Header
- Parameter
- ? (question mark)
- , (comma)
- □ (space)
- ; (semi-colon)
- * (asterisk)
- " (double quotation mark)
- ' (quotation mark)

Note:

Parameter values that can be used in the MT8815B/MT8820B are integer number (NR1) and fixed decimal point (NR2). For alphabets, both capitals and lower cases are available.

(1) Header

Name of a command that is always placed at the beginning of a command. The header may function by itself. A question mark (?) at the end indicates that the command is a query. An asterisk (*) at the beginning indicates that the command is an IEEE488.2 common command.

Example:

```
SNGLS
FREQ?
*RST
```

(2) Parameter

Indicates the set value or query conditions on the header. Arranged following the header with a space in between, substitutes alphabets and numeric values.

Plural arguments can be specified by using a comma (,) as a delimiter. Some arguments can be omitted.

Example:

```
FREQ 1920HZ
TXPWR? WATT
DATE 2001,07,23
```

- (3) ? (question mark)

Appending “?” (question mark) to the end of a command creates a command (query) that queries the device status.

- (4) , (comma)

Delimits multiple parameters.

- (5) □ (space)

Divides the header from a parameter.

- (6) ; (semi-colon)

Connects two commands to process them as a single command.

Example:

```
SCRSEL SYSCFG;DATEMODE DMY
```

- (7) * (asterisk)

Indicates that the command is an *IEEE488.2 common command.

Example:

```
*IDN?
```

- (8) " (double quotation mark), ' (quotation mark)

Appended at the beginning and the end of a character string when the character string is specified as a parameter.

Example:

```
TITLE 'TOTAL TEST'
```

7.5.3 Setting parameters with unit specified

To specify the unit of parameter in a command, append a character string called a “suffix code” at the end of a parameter. The suffix code may be omitted. If omitted, setting is made in the predetermined response unit.

Example:

Setting the frequency to 1922 MHz (by a command from W-CDMA measurement software)

TFREQ 1922MHZ /*with suffix code (set in MHz)* /

TFREQ 1922000000 /*without suffix code (set in Hz)* /

Table 7.5.3-1 shows suffix codes available for the MT8815B/MT8820B:

Table 7.5.3-1 Suffix code list

Classification	Unit	Suffix code
Frequency	GHz	GHZ
		GZ
	MHz	MHZ
		MZ
	kHz	KHZ
		KZ
	Hz	HZ
		None
Time	second	S
	msecond	MS
	μsecond	US
	Command-specific	None
Level (dB)	dB	DB
	dBm	DBM
		DM
	dBc	DBC
	dBμ	DBU
	Pre-specified unit	None
Level (W)	W	W
	mW	MW
	μW	UW
		None
	nW	NW
Level (V)	V	V
		None
	mV	MV
	μV	UV

7.5.4 Response unit

When a response is read by a query, the response unit may differ from the value of unit displayed on the MT8815B/MT8820B. This is because the grade of the response unit is determined by the unit system, not by the display unit. Care should be taken in command programming.

The following table shows response units for the MT8815B/MT8820B:

Table 7.5.4-1 Response unit

Classification	Display unit	Response unit
Frequency	GHz, MHz, kHz, Hz	Hz
Time	s, ms, μ s	Command-specific
Level (dB)	dB	dB
	dBm	dBm
	dBc	dBc
	dB μ	dB μ
Level (W)	W, mW, μ W, nW	W
Level (V)	V, mV, μ V	V

Example:

When display is 1922 MHz: (the command is fictional)

```
Query      FREQ?
Response   1922000000
```

A frequency is always read in Hz unit.

Note:

Response unit is the same unit as that when the suffix code is not specified.

7.6 Command Programming Guide

To write an efficient measurement program, pay attention to the following points:

(1) Initialization

To avoid influence by the previous setting, initialize MT8815B/MT8820B before starting measurement. Select an initialization level according to the measurement.

(2) Use manual operation procedure as a reference for command transmission order

Take care of the command sending order when creating a remote control program. Command sending order is basically the same as that in the manual operation procedure. Thus understand the operation flow of the program to be created by manual operation. Especially in case measurement results are read after measurement, no commands other than query commands should be sent until all the results are read out.

(3) Pay attention to the command syntax

Avoid interruption of a command caused by a command syntax error. Especially, pay attention to the presence/absence of a space as well as comma and parameter setting method.

(4) Pay attention to the response unit

When reading measurement results during remote control, the response unit is always returned in pre-specified unit. Note that the response unit differs from the unit of displayed notation.

(5) To enhance measurement throughput

To enhance measurement throughput, the following methods are available:

- Understand the initial value and change the required parameters only.
- Avoid sending commands not directly related to measurement.
- Make the number of screen switchovers to the minimum.
- Turn the Screen Off (send the SCREEN OFF command).

Note:

When executing queries consecutively while the Parallelphone Measurement Software is installed, the operation of the other Phone may be slow. To prevent this, insert a wait with several ms between queries.

7.7 Status Report

The IEEE488.2 provides common commands available to all the GPIB devices. Some of them can also be used with the Serial interface and Ethernet interface (some commands are not supported). The common commands are classified as device message, and report the device status.

Informing a device status is called a status report. Status model is also standardized in IEEE488.2 and referred to as a standard status model. That is, the status of any IEEE488.2-compliant device can be read by using a common command, regardless of the kind of devices.

7.7.1 Standard status model

Standard status models specified in IEEE488.2 are as follows:




Fig. 7.7.1-1 Standard status model

Note:

Bit 3 (ERR) and bit 2 (END) of the status byte register are event summary bits specific to the MT8815B/MT8820B.

7.7.2 Standard event status register

SESR: Standard Event Status Register is a register consisting of eight bits. Each bit is respectively assigned to a standard event. When the MT8815B/MT8820B enters a standard event status, the corresponding bit becomes 1 (true).




Fig. 7.7.2-1 Standard event status register

Table 7.7.2-1 Description of each bit of standard event status register

Bit	Name	Description
7	PON	Power On Indicates that the power is turned on.
6	URQ	User Request Not used in the MT8815B/MT8820B. Always 0.
5	CME	Command Error Indicates that an error has occurred during analysis of a command or a query received by the MT8815B/MT8820B.
4	EXE	Execution Error Indicates that an error has occurred during execution of a command or a query by the MT8815B/MT8820B.
3	DDE	Device Dependent Error Indicates that a device specific error has occurred.
2	QYE	Query Error Indicates that the data in the output queue is absent or data is lost. Cannot be used with the Serial interface or Ethernet (100Base-TX/10Base-T). Always 0.
1	RQC	Request Control Not used in the MT8815B/MT8820B. Always 0.
0	OPC	Operation Complete Indicates that all the outstanding operations have been completed. This bit is set only by the *OPC command.

■ Query

Query the standard event status using the *ESR? query. Response is the decimal number converted from the sum of the value obtained by binary-weighting the bit number of the occurrence event. When readout is successful, the contents of the register are cleared.

Example :

```

Query          *ESR?
Response       32
(32 = 25      A bit 5 command error has occurred.)

```

■ Clear The following methods are available to clear the standard event status register:

- Transmit the *CLS command
- Read the status register by using the *ESR? query

That is, when any status specified by the standard event status enable register has occurred, bit 5 of the status byte register becomes 1 (true).

Set the standard event status enable register by using the *ESE command. The parameter is the decimal number converted from the sum of the values obtained by binary-weighting the specified bits.

Setting bit 5 of the status byte register to 1 (true) for command error (bit 5) and execution error (bit 4):

Query using the *ESE? query. Response is the decimal number converted from the sum of the values obtained by binary-weighting the specified bits.

The following methods are available to clear the standard event status enable register:

- 7-25

7.7.4 Status byte register

SBR (Status Byte Register) is an eight-bit register representing a service request, an event status bit etc. When the MT8815B/MT8820B enters the status set for each bit, the corresponding bit becomes 1 (true).




Fig. 7.7.4-1 Status byte register

Table 7.7.4-1 Description of each bit of status byte register

Bit	Name	Description
7	---	Not used
6	MSS	Master Summary Status Indicates that ESB (bit 5), MAV (bit 4), ERR (bit 3) or END (bit 2) of the status byte register is set. Read using the *STB? query.
	RQS	Service Request Indicates that the device is requesting a service to the controller. Read by serial polling. Cannot be used with Serial interface and Ethernet interface. Always 0.
5	ESB	Event Status Bit Indicates that a standard event specified by the standard event status enable register has occurred.
4	MAV	Message Available Indicates that data is present in the output queue. When data is present, 1 is set. When data is absent, 0 is set. Cannot be used with Serial interface and Ethernet (100Base-TX/10Base-T). Always 0.
3	ERR	Error Event Status (specific to the MT8815B/MT8820B) Indicates that an event (error) specified by the ERR event status enable register has occurred.
2	END	End Event Status (specific to the MT8815B/MT8820B) Indicates that an event (operation completed) specified by the END event status enable register has occurred.
1	---	Not used
0	---	Not used

■ Query

The status byte register can be read using the *STB? query or by serial poll. Reading by serial poll causes bit 6 to be the RQS (service request) bit. Reading with the *STB? query causes bit 6 to be the MSS (Master Status Summary) bit. Response is the decimal number converted from the sum of the values obtained by binary-weighting the events that has occurred.

- Send the *SRE 0 command
- Turn the power On

7.7.6 END event status register

The END event status register is an extended event status register specific to the MT8815B/MT8820B for detecting an event concerning completion of operation. When the MT8815B/MT8820B enters the status set for each bit, the corresponding bit becomes 1 (true).




Fig. 7.7.6-1 END event status register

Table 7.7.6-1 Description of each bit of END event status register
When using W-CDMA, TD-SCDMA or GSM measurement software

Bit	Description
7	Not used
6	Not used
5	Not used
4	Indicates that Audio measurements have been completed.
3	Indicates that transmission measurements on the Fundamental Measurement screen have been completed.
2	Indicates that reception measurements on the Fundamental Measurement screen have been completed.
1	Not used
0	Measurement/Sweep Completed Occurs when measurement or sweep has been completed.

**Table 7.7.6-2 Description of each bit of END event status register
When using CDMA2000 or 1xEV-DO measurement software**

Bit	Description
7	Not used
6	Not used
5	Not used
4	Indicates that Audio measurement has been completed.
3	Indicates that transmission measurements on the Fundamental Measurement screen have been completed, except for Access Probe Power.
2	Indicates that reception measurements on the Fundamental Measurement screen have been completed.
1	Indicates that the measurement for Access Probe Power on the Fundamental Measurement screen has been completed. Indicates that the measurement on the Access Probe Measurement screen has been completed.
0	Indicates that measurements for all selected items Power on the Fundamental Measurement screen have been completed. Indicates that the measurement on the Access Probe Measurement screen has been completed. Indicates that the measurement on the Open Loop Time Response screen has been completed. Indicates that the measurement on the Multi Power Measurement screen has been completed.

**Table 7.7.6-4 Description of each bit of END event status register
When using PHS measurement software**

Bit	Description
7	Indicates that synchronization has been established by entering the external trigger.
6	Indicates that output level settings have been completed.
5	Indicates that calibration has been completed.
4	Not used
3	Indicates that transmission measurements on the Fundamental Measurement screen have been completed.
2	Indicates that reception measurements on the Fundamental Measurement screen have been completed.
1	Not used
0	Measurement/Sweep Completed Occurs when measurement or sweep has been completed.

■ Query

Read using the ESR2? query. When readout is successful, the contents of the register are cleared.

Example:

```

Query          ESR2?
Response       1
(1 = 20      bit0: Measurement/sweep is completed)

```

■ Clear

The following methods are available to clear the END status register.

- Read the status using the ESR2? query
- Send the *CLS command
- Turn the power On.

7.7.7 END event status enable register

Each bit of the END event status enable register corresponds to each bit of the END status register. Logical OR of the bits is output to bit 2 of the status byte register.

That is, when any status specified by the END event status enable register has occurred, bit 2 of the status byte register becomes 1 (true).

■ Setting

Set the END event status enable register by using the ESE2 command. The parameter is the decimal number converted from the sum of the values obtained by binary-weighting the specified bits.

Example:

To set bit 2 of the status byte register to 1 when measurement has been completed:

```
ESE2 1          /*Measurement completion is bit 0, so  $2^0 = 1$  is set.*/
```

■ Query

Read using the ESE2? query. Response is the decimal number converted from the sum of the values obtained by binary-weighting the specified bits.

■ Clear

The following methods are available to clear the END event status enable register:

- Send the ESE2 0 command

7.7.8 ERR event status register

The ERR (error) Event Status Register is an extended event status register specific to the MT8815B/MT8820B for detecting an event concerning errors. When the MT8815B/MT8820B enters the status set for each bit, the corresponding bit becomes 1 (true).




Fig. 7.7.8-1 ERR event status register

Table 7.7.8-1 Description of each bit of ERR event status register when using W-CDMA, TD-SCDMA, GSM or PHS measurement software

Bit	Description
7	Not used
6	Call Drop Error Occurs when the MT8815B/MT8820B cannot demodulate signal of phone.
5	Not used
4	Call Processing Error Indicates that an error has occurred during call processing.
3	Reception Measurement Error Indicates that an error has occurred during reception measurement.
2	Transmission Measurement Error Indicates that an error has occurred during transmission measurement.
1	Not used
0	Sync Loss (Bit Error Rate Measurement) Indicates that synchronization is lost during bit error rate measurement.

Table 7.7.8-2 Description of each bit of ERR event status register when using CDMA2000 or 1xEV-DO measurement software

Bit	Description
7	Not used
6	Call Drop Error Occurs when the MT8815B/MT8820B cannot demodulate signal of phone.
5	Not used
4	Call Processing Error Indicates that an error has occurred during call processing.
3	Reception Measurement Error Indicates that an error has occurred during reception measurement.
2	Transmission Measurement Error Indicates that an error has occurred during transmission measurement, except for Access Probe Power.
1	Access Probe Power Measurement Error Indicates that an error has occurred during measurement for Access Probe Power on the Fundamental Measurement screen. Access Probe Measurement Error Indicates that an error has occurred during measurement on the Access Probe Measurement screen.

**Table 7.7.8-2 Description of each bit of ERR event status register
When using CDMA2000 or 1xEV-DO measurement software
(Cont'd)**

0	Open Loop Time Response Error Indicates that an error has occurred during measurement on the Open Loop Time Response screen. Multi Power Measurement Error Indicates that an error has occurred during measurement on the Multi Power Measurement screen.
---	--

■ Query

Read using the ESR3? query. When readout is successful, the contents of the register are cleared.

Example:

Query	ESR3?
Response	80

($80 = 2^4 + 2^6$: bit 4 and bit 6 errors have occurred)

■ Clear

The following methods are available to clear the ERR status register:

- Read the status using the ESR3? query
- Send the *CLS command
- Turn the power On

7.7.9 ERR event status enable register

The ERR event status enable register is a register consisting of eight bits.

Each bit of the ERR event status enable register corresponds to that of the ERR status register. Logical OR of the bits is output to bit 3 of the status byte register.

That is, when any status specified by the ERR event status enable register has occurred, bit 3 of the status byte register becomes 1 (true).

■ Setting

Set the ERR event status enable register by using the ESE3 command. The parameter is the decimal number converted from the sum of the values obtained by binary-weighting the specified bits.

Example:

To set bit 3 of the status byte register to 1 when both the sending measurement error and receiving measurement error have occurred:

```
ESE3 12 /*Errors correspond to bit 2 and bit 3, so  $2^2 + 2^3 = 12$ 
        is set.*/
```

■ Query

Read using the ESE3? query. Response is the decimal number converted from the sum of the values obtained by binary-weighting the specified bits.

■ Clear

The following methods are available to clear the ERR event status enable register:

- Send the ESE3 0 command

7.8 Establishing Synchronization

This section describes how to establish synchronization between commands transmitted from the computer with the operation of the MT8815B/MT8820B.

7.8.1 Difference of synchronization depending on measurement start command

When measurement is started using the `SNGLS` command, command processing is assumed to have been completed even when the actual measurement has not yet. That is, next command is executed even if measurement is being executed. The `SNGLS` command is effective when a measured value during measurement is read, and effective in measurement where measurement is endless, such as bit error rate measurement.

In most measurements, it is necessary to read the measurement results after the measurement has been completed. In this case, use `SWP` as a measurement start command. Starting measurement using the `SWP` command puts the next command in wait status until current measurement has been completed. Thus it is not necessary to provide special processing for waiting for current measurement to be completed.

7.8.2 Establishing synchronization with `*OPC?` query

Sending the `*OPC?` query to MT8815B/MT8820B provides synchronization, as below.

When the response to `*OPC?` is 1, it indicates that the immediately preceding command was completed.

7.8.3 Establishing synchronization corresponding to status register status

Sending the `*STB?`, `*ESR?`, `ESR2?` or `ESR3?` to MT8815B/MT8820B provides synchronization. Thus, synchronization is established by waiting for the response to be the expected value. Event status register must be reset just before occurring the expected register. In addition, the `*OPC` command must be sent before sending the target command when using the `*ESR?` query.

Chapter 8 Remote Control Commands

This chapter describes the remote control commands related to the common functions and the IEEE488.2 common commands. All commands described in this chapter can be executed in all measurement software operating on MT8815B/MT8820B.

8.1	Command List by Function	8-2
8.1.1	IEEE488.2 common commands	8-3
8.1.2	Extended event status commands	8-4
8.1.3	Initialization commands	8-4
8.1.4	Measurement software selection commands	8-5
8.1.5	Screen selection commands	8-6
8.1.6	Measurement commands	8-7
8.1.7	Calibration execution commands	8-7
8.1.8	System screen tab selecting commands	8-8
8.1.9	System setting commands	8-9
8.1.10	System information query commands	8-11
8.1.11	Common cable loss setting commands	8-14
8.1.12	Parameter save commands	8-15
8.1.13	Parameter read commands	8-15
8.1.14	Special commands	8-16
8.2	Command Specifications in Alphabetical Order	8-17

8.1 Command List by Function

The following list classifies the commands executable in all the measurement software operating on MT8815B/MT8820B by function. For details of individual commands, refer to Section 8.2 “Command Specifications in Alphabetical Order.” For the commands to execute the functions of measurement software, refer to the operation manual of each measurement software.

Note:

When the Parallelphone Measurement Software is installed in MT8820B, send a remote control command to GPIB-1 or GPIB-2 to remotely control Phone-1 or Phone-2, respectively (except for some common parameters). Furthermore, when performing the remote control via Ethernet (100Base-TX/10Base-T), send the remote control command to the port number 56001 for the Phone-1 and the port number 56002 for the Phone-2, respectively.

8.1.1 IEEE488.2 common commands

The common commands defined in IEEE488.2 available in the MT8815B/MT8820B are listed in the table below. The commands are available on all screens.

Table 8.1.1-1 IEEE488.2 common commands

Function	Command	Query	Response	Remarks
System Data				
Identification Query	-----	*IDN?	MT8815B: ANRITSU,MT8815B, serial,firm MT8820B: ANRITSU,MT8820B, serial,firm,phone	serial Serial Number firm Firmware Version phone Phone Number
Internal Operations				
Reset (Instrument Initial)	*RST	-----	-----	
Self-Test Query	-----	*TST?	test_result	
Synchronization				
Operation Complete Command	*OPC	-----	-----	
Operation Complete Query	-----	*OPC?	operation	
Wait-to-Continue Command	*WAI	-----	-----	
Status & Event				
Clear Status Command	*CLS	-----	-----	
Standard Event Status Enable Command	*ESE register	-----	-----	
Standard Event Status Enable Query	-----	*ESE?	register	
Standard Event Status Register Query	-----	*ESR?	register	
Service Request Enable Command	*SRE register	-----	-----	
Service Request Enable Query	-----	*SRE?	register	
Status Byte Query	-----	*STB?	register	
Trigger				
Trigger Command	*TRG	-----	-----	

8.1.2 Extended event status commands

The status report commands specific to MT8815B/MT8820B are listed in the table below. The commands are available on all screens.

Table 8.1.2-1 Extended event status commands

Function	Command	Query	Response	Remarks
End Event Status Enable Register Command	ESE2 register	-----	-----	
End Event Status Enable Register Query	-----	ESE2?	register	
End Event Status Register Query	-----	ESR2?	register	
Error Event Status Enable Register Command	ESE3 register	-----	-----	
Error Event Status Enable Register Query	-----	ESE3?	register	
Error Event Status Register Query	-----	ESR3?	register	

8.1.3 Initialization commands

The commands for initializing MT8815B/MT8820B are listed in the table below. The commands are available on all the screens except for the Standard Load screen. The *RST command is, however, available on the Standard Load screen.

Table 8.1.3-1 Initialization commands

Function	Command	Query	Response	Remarks
Preset	PRESET	-----	-----	
	*RST	-----	-----	
	PRE	-----	-----	
	IP	-----	-----	
	INI	-----	-----	

8.1.4 Measurement software selection commands

Table 8.1.4-1 Measurement software selection commands

Function		Command	Query	Response	Remarks
Measurement Software	W-CDMA	STDSEL WCDMA	STDSEL?	WCDMA	
	TD-SCDMA	STDSEL TDSCDMA		TDSCDMA	
	GSM	STDSEL GSM		GSM	
	CDMA2000/1xEV-DO	STDSEL CDMA2K		CDMA2K	
	PHS	STDSEL PHS		PHS	
Load Software	W-CDMA	STDLOAD n,WCDMA	-----	-----	n = Standard number (1 to 3)
	TD-SCDMA	STDLOAD n,TDSCDMA			
	GSM	STDLOAD n,GSM		-----	
	CDMA2000/1xEV-DO	STDLOAD n,CDMA2K		-----	
	PHS	STDLOAD n,PHS		-----	
Unload Software		STDUNLOAD n	-----	-----	n = Standard number (1 to 3)

8.1.5 Screen selection commands

The commands for selecting common function screens of Common External Loss screen, Parameter Save screen, Parameter Recall screen, etc. are listed in the table below.

Table 8.1.5-1 Screen selection commands

Function		Command	Query	Response	Remarks
Select Screen	Parameter Save	SCRSEL PRMSAVE	SCRSEL?	PRMSAVE	
	Parameter Recall	SCRSEL PRMRCL		PRMRCL	
	System Configuration	SCRSEL SYSCFG		SYSCFG	
	System Information	SCRSEL SYSINFO		SYSINFO	
	Common External Loss	SCRSEL CEXTLOSS		CEXTLOSS	
	Standard Load	SCRSEL STDLOAD		STDLOAD	
Active Window	Ext. Loss List	SCRACT LOSSLIST	SCRACT?	LOSSLIST	
	Ext. Loss View	SCRACT LOSSVIEW		LOSSVIEW	
	Standard Load	SCRACT STDLOAD		STDLOAD	
	Softlist	SCRACT SOFTLIST		SOFTLIST	
Window Size	100%	WINSIZE 100	WINSIZE?	100	
	70%	WINSIZE 70		70	
	50%	WINSIZE 50		50	
	30%	WINSIZE 30		30	

8.1.6 Measurement commands

The commands for starting and stopping measurement are listed in the table below. Measurement cannot be started from common function screens.

Table 8.1.6-1 Measurement commands

Function	Command	Query	Response	Remarks
Single	SNGLS	-----	-----	
	S2	-----	-----	
Single (Sync)	SWP	-----	-----	
	TS	-----	-----	
Continuous	CONTS	-----	-----	
	S1	-----	-----	
Current Status	-----	SWP?	status	status 0: Done 1: Measuring
Stop Measure	MEASSTOP	-----	-----	

8.1.7 Calibration execution commands

The commands for executing calibration before starting measurement are listed in the table below. The commands are available on all measurement screens.

Table 8.1.7-1 Calibration execution commands

Function	Command	Query	Response	Remarks
Full Calibration	FULLCAL	-----	-----	
Band Calibration	BANDCAL	-----	-----	
Band Calibration (Auto)	BANDCAL_TEMP temperature			Temperature = 1.0 to 50.0

8.1.8 System screen tag selecting commands

The commands for selecting a tag on the system screen are listed in the table below. The commands are available on the screens in which the corresponding tag is displayed.

Table 8.1.8-1 Tag selecting commands

Function		Command	Query	Response	Remarks
Select Tag					
System Configuration	Common	TAGSEL SYSCFG,COMMON	TAGSEL? SYSCFG	COMMON	Only for MT8820B
	Phone-1	TAGSEL SYSCFG,PHONE1		PHONE1	
	Phone-2	TAGSEL SYSCFG,PHONE2		PHONE2	
System Information	Maintenance Information	TAGSEL SYSINFO,MAINTE	TAGSEL? SYSINFO	MAINTE	
	Software Version	TAGSEL SYSINFO,SOFT		SOFT	
	Software Option	TAGSEL SYSINFO,OPTION		OPTION	
	Hardware Revision	TAGSEL SYSINFO,HARD		HARD	

8.1.9 System setting commands

The commands for setting the MT8815B/MT8820B systems and interfaces on the System Configuration screen are listed in the table below. The commands are available on all screens.

Table 8.1.9-1 System setting commands

Function		Command	Query	Response	Remarks
Frequency					
Reference Frequency *	Internal 10MHz	REF 10MHZINT	REF?	10MHZINT	
	External 10MHz	REF 10MHZEXT		10MHZEXT	
	External 13MHz	REF 13MHZEXT		13MHZEXT	
External Reference		-----	EXTREF?	INT	
				VALID	
				INVALID	
Display					
Display Title *	User Define	TTL USER	TTL?	USER	
	Date / Time	TTL DATE		DATE	
	Off	TTL OFF		OFF	
Title *		TITLE title	TITLE?	title	
Date Format *	YYYY / MM / DD	DATEMODE YMD	DATEMODE?	YMD	
	MM / DD / YYYY	DATEMODE MDY		MDY	
	DD / MM / YYYY	DATEMODE DMY		DMY	
Date (Year/Month/Day) *		DATE year, month, day	DATE?	year, month, day	year = 2001 to 2030 month = 1 to 12 day = 1 to 31
Time (Hour:Minute:Second) *		TIME hour, min, sec	TIME?	hour, min, sec	hour = 0 to 23 min = 0 to 59 sec = 0 to 59
Key input					
Encoder	Up/Down	ENCODER UPDOWN	ENCODER?	UPDOWN	
	Left/Right	ENCODER LEFTRIGHT		LEFTRIGHT	

Table 8.1.9-1 System setting commands (cont.)

Function		Command	Query	Response	Remarks
Beep sound *	On	ALARM ON	ALARM?	ON	
		BEP 1	-----	-----	
		BEP ON	-----	-----	
	Off	ALARM OFF	ALARM?	OFF	
		BEP 0	-----	-----	
		BEP OFF	-----	-----	
Band Calibration	Warning Range	CALCHK_RANGE temperature	CALCHK_RANGE ?	temperature	temperature = 1 to 10
Sound Buzzer		BZR	-----	-----	
RF Output	Main	RFOUT MAIN	RFOUT?	MAIN	
	AUX	RFOUT AUX		AUX	
Baud Rate	38400 bps	BAUD 38400	BAUD?	38400	Only for MT8815B
	19200 bps	BAUD 19200		19200	
	9600 bps	BAUD 9600		9600	
	4800 bps	BAUD 4800		4800	
	2400 bps	BAUD 2400		2400	
	1200 bps	BAUD 1200		1200	
Parity Bit	EVEN	PRTY EVEN	PRTY?	EVEN	Only for MT8815B
	ODD	PRTY ODD		ODD	
	OFF	PRTY OFF		OFF	
Data Bit	7 Bit	DTAB 7	DTAB?	7	Only for MT8815B
	8 Bit	DTAB 8		8	
Stop Bit	1 Bit	STPB 1	STPB?	1	Only for MT8815B
	2 Bit	STPB 2		2	
10Base-T-1 (10Base-T-2)	IP Address	PSETIPADDR n1,n2,n3,n4	PSETIPADDR?	n1,n2,n3,n4	n1,n2,n3,n4 = 0 to 255
	Subnet Mask	PSETSNM n1,n2,n3,n4	PSETSNM?	n1,n2,n3,n4	n1,n2,n3,n4 = 0 to 255
	Default Gateway	PSETDEFGTWY n1,n2,n3,n4	PSETDEFGTWY?	n1,n2,n3,n4	n1,n2,n3,n4 = 0 to 255

*: When the Parallelphone Measurement Software is installed in the MT8820B, setting via either the GPIB-1 or GPIB-2 connector or the Ethernet (100Base-TX/10Base-T) applies a common setting value to both Phone-1 and Phone-2.

8.1.10 System information query commands

The commands for reading the system information (displayed in the System Information screen) of the hardware and software, which configure the MT8815B/MT8820B, are listed in the table below. The commands are available on all screens.

Table 8.1.10-1 System information query commands

Function	Command	Query	Response	Remarks
Maintenance Information				
Serial Number	-----	SERIAL?	serial_number	
Power On Time	-----	TMCNT?	time	Unit = min
Full Cal Time	-----	FULLCAL_TM?	year,month,day,hour, min	year = 2001 to month = 1 to 12 day = 1 to 31 hour = 0 to 23 min = 0 to 59
CF Type	-----	MCCF?	a,b	a = CF Type b = CF Unused Area
Load Software Version	-----	MCMSV? n	std,version	n = Standard Number std = Standard Name
Software Version				
Firmware Version	-----	MCIV?	version	version = IPL version
	-----	MCOV?	version	version = OS version
	-----	MCFV?	version	version = Firmware version

Table 8.1.10-1 System information query commands (cont.)

Function	Command	Query	Response	Remarks
Hardware Revision *	-----	MCHV?	maid, marev, mafpga, tdid1, tdrev1, tdfpga1, cdid1, cdrev1, cdfpga1, evid1, evrev1, evfpga1, wcid1, wcrev1, wcfpga1, mdid1, mdrev1, mdfpga1, daid, darev, dafpga, tdid2, tdrev2, tdfpga2, cdid2, cdrev2, cdfpga2, evid2, evrev2, evfpga2, wcid2, wcrev2, wcfpga2, mdid2, mdrev2, mdfpga2, auid, aurev, aufpga	maid: Main CPU ID marev: Main CPU Rev. mafpga: Main CPU FPGA tdid1: TDMA COM1 ID tdrev1: TDMA COM1 Rev. tdfpga1: TDMA COM1 FPGA cdid1: CDMA2000 COM1 ID cdrev1: CDMA2000 COM1 Rev. cdfpga1: CDMA2000 COM1 FPGA evid1: 1xEV-DO COM1 ID evrev1: 1xEV-DO COM1 Rev. evfpga1: 1xEV-DO COM1 FPGA wcid1: W-CDMA COM1 ID wcrev1: W-CDMA COM1 Rev. wcfpga1: W-CDMA COM1 FPGA mdid1: Measure DSP1 ID mdrev1: Measure DSP1 Rev. mdfpga1: Measure DSP1 FPGA daid: DAC/ADC ID darev: DAC/ADC Rev. dafpga: DAC/ADC FPGA tdid2: TDMA COM2 ID tdrev2: TDMA COM2 Rev. tdfpga2: TDMA COM2 FPGA cdid2: CDMA2000 COM2 ID cdrev2: CDMA2000 COM2 Rev. cdfpga2: CDMA2000 COM2 FPGA evid2: 1xEV-DO COM2 ID evrev2: 1xEV-DO COM2 Rev. evfpga2: 1xEV-DO COM2 FPGA wcid2: W-CDMA COM2 ID wcrev2: W-CDMA COM2 Rev. wcfpga2: W-CDMA COM2 FPGA mdid2: Measure DSP2 ID mdrev2: Measure DSP2 Rev. mdfpga2: Measure DSP2 FPGA

Table 8.1.10-1 System information query commands (cont.)

Function	Command	Query	Response	Remarks
Hardware Revision *				auid: Audio ID aurev: Audio Rev. aufpga: Audio FPGA
Option Number	-----	MCOPT? a	n,n1,n2,...	a = Type Name of Option n = Count n1,n2... = Option Number
Type Name of Option	-----	MCSOPT?	n,a1,a2,...	n = Count a1,a2... = Type Name of Option
Version Information of Option Module Software	-----	MCSV? a	version	a = Type Name of Option
Information Save	SYSINFOSAVE	-----	-----	File name: SysInfo.txt

*: Responses for Phone-2 are displayed when the Parallelphone Measurement Software is installed in the MT8820B.

8.1.11 Common cable loss setting commands

The commands that can be set on the Common External Loss screen are listed in the table below.

Table 8.1.11-1 Common cable loss setting commands

Function	Command	Query	Response	Remarks
Regist Loss into List	LOSSTBLVAL f,11,12,13	LOSSTBLVAL? n	f,11,12,13	n = 1 to 100 f = 0.4 to 2700.0 [MHz] 11 = -55.00 to 55.00 [dB] 12 = -55.00 to 55.00 [dB] 13 = -55.00 to 55.00 [dB]
Number of External Loss Common Table	-----	LOSSTBLSAMPLE?	n	n = 0 to 100
Delete Loss From List	DELLOSSTBL a,b	-----	-----	a,b = Specifies the deleted range. If not specified, all is deleted.
Save List	SVLOSSTBL file	-----	-----	file Save File Name
Load List	RLLOSSTBL file	-----	-----	file Recall File Name
Start Frequency	LOSSVIEW_STAFREQ f	LOSSVIEW_STAFREQ?	f	f = 0.4 to 2700.0 [MHz]
Stop Frequency	LOSSVIEW_STPFREQ f	LOSSVIEW_STPFREQ?	f	f = 0.4 to 2700.0 [MHz]
Vertical Scale	LOSSVIEW_VSCALE mode	LOSSVIEW_VSCALE?	mode	mode = 10, 20, 30, 40, 50, 60

8.1.12 Parameter save commands

The commands for saving parameter settings are listed in the table below. The measurement screen of an activated phone can be saved. This command is available on all screens.

Table 8.1.12-1 Parameter save commands

Function		Command	Query	Response	Remarks
Directory Path		-----	SVCD?	dir_path	
File List		-----	SVFLIST?	num,a1,name1,a2,name 2,...,a(num),name(nu m)	num File Number a Attribute 0: No File 1: Archive or 2: Read Only name Object Name
Save Parameter	Default Name	PRMSAVE	-----	-----	
	File Name	PRMSAVENAME fname	-----	-----	fname File Name
	File Number	PRMSAVE fnumber	-----	-----	fnumber File Number
Default File Name Query		-----	SVDEFFILE?	fname	fname File Name

8.1.13 Parameter read commands

The commands for reading files saved with parameter save commands are listed in the table below. This command is available on all screens.

Table 8.1.13-1 Parameter read commands

Function		Command	Query	Response	Remarks
Directory Path		-----	RLCD?	dir_path	
File List		-----	RLFLIST?	num,a1,name1,a2,name 2,...,a(num),name(nu m)	num File Number a Attribute 1: Archive or 2: Read Only name Object Name
Recall Parameter	File Name	PRMRECALLNAME fname	-----	-----	fname File Name
	File Number	PRMRECALL fnumber	-----	-----	fnumber File Number

8.1.14 Special commands

The commands for performance test and functions executable only in the remote control. The commands are available on all screens.

Table 8.1.14-1 Special commands

Function		Command	Query	Response	Remarks
Drawing	On	SCREEN ON	-----	-----	
	Off	SCREEN OFF		-----	
Panel Display Power *	On	DISPL ON	DISPL?	ON	
	Off	DISPL OFF		OFF	
Modulation for the performance test	Modulation (Normal)	MOD ON	MOD?	ON	
	Non Modulation (Test Mode)	MOD OFF		OFF	
Remote Control Display Mode	Normal	REMDISP NORMAL	REMDISP?	NORMAL	
	Remain	REMDISP REMAIN		REMAIN	
	Stop	REMDISP STOP		STOP	
Go to local		GTL	-----	-----	
Delimiter	LF	DELM 0	DELM?	0	
	CR/LF	DELM 1		1	
Terminator	LF	TRM 0	TRM?	0	
	CR/LF	TRM 1		1	

*: When the Parallelphone Measurement Software is installed to MT8820B, setting via either the GPIB-1 or GPIB-2 connector or the Ethernet (100Base-TX/10Base-T) applies a common setting value to both the Phone-1 and Phone-2.

8.2 Command Specifications in Alphabetical Order

This section describes executable commands in all the measurement software operating on MT8815B/MT8820B in alphabetical order. For the commands to execute the functions of measurement software, refer to the separate operation manual of each measurement software.

■ How to view the command list

EX Command name (header)

Example Command function name

Explains how to view the command specifications
..... Function outline

Function..... Command function

Command Programming command syntax

Query Query syntax

Response Response syntax

Parameters Parameter definition

Description..... Command restriction item, etc

Sample programming..... Example for command use

Related command..... Introduction for related command

***CLS**

Clear Status Command

Clearing status

Function

Clears the standard event status register and the status byte register (except the output queue and MAV bits)

Command

*CLS

Query

None

Response

None

Description

Sending *CLS command after a program message terminator or before a query message unit causes all status byte registers to be cleared.

Sample programming

To clear the standard event status register and the status byte register (except the output queue and MAV bits):

*CLS

*ESE

Standard Event Status Enable Command

Setting standard event status enable register

Function

Sets the standard event status enable register. When the set event occurs, the end summary bit (ESB, bit 5) of the status byte register becomes “1” (true).

Command

*ESE register

Query

*ESE?

Response

register

Parameters

register Standard event status enable register

Value = bit0 + bit1 + ... + bit7

bit0 = $2^0 = 1$: Operation complete

bit1 = $2^1 = 2$: Request control

bit2 = $2^2 = 4$: Query error

bit3 = $2^3 = 8$: Device error

bit4 = $2^4 = 16$: Execution error

bit5 = $2^5 = 32$: Command error

bit6 = $2^6 = 64$: User request

bit7 = $2^7 = 128$: Power On

Description

From among the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the standard event status enable register; the sum of values of bits to be enabled becomes the parameter.

Sample programming

To enable the execution error event:

*ESE 16

*ESR?

Standard Event Status Register Query

Querying the standard event status register

Function

Queries the standard event status register. The event that occurred can be identified depending on the read value.

Command

None

Query

*ESR?

Response

register

Parameters

register Standard event status register

Value = bit0 + bit1 + ... + bit7

bit0 = $2^0 = 1$: Operation complete

bit1 = $2^1 = 2$: Request control

bit2 = $2^2 = 4$: Query error

bit3 = $2^3 = 8$: Device error

bit4 = $2^4 = 16$: Execution error

bit5 = $2^5 = 32$: Command error

bit6 = $2^6 = 64$: User request

bit7 = $2^7 = 128$: Power On

Description

The parameter is the sum of the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the standard event status register. When the response is read, the standard event status register is cleared.

Sample programming

To read the standard event status register:

*ESR?

*IDN?

Identification Query

Querying identification information

Function

Inquires the identification information of the device on the GPIB bus.

Command

None

Query

*IDN?

Response

ANRITSU,MT8815B,serial,firm (for MT8815B)

ANRITSU,MT8820B,serial,firm,phone (for MT8820B)

Parameters

ANRITSU : Company name (Anritsu Corporation)

MT8820B : Model name of device (varies depending on the model)

serial : Serial number (unique to each MT8815B/MT8820B unit)

firm : Firmware revision

phone : Phone number (1 for Phone-1, and 2 for Phone-2)

(Phone number is omitted for the MT8815B because it is for single phone measurement)

Sample programming

To query the identification information of MT8815B/MT8820B:

*IDN?

*OPC

Operation Complete

Setting the operation complete flag

Function

Sending the *OPC command sets bit 0 (operation complete) of the standard event status register when all of the selected pending device operations have been completed.

When all of the selected pending operations have been completed, the *OPC? command sets “1” in the output queue and waits until MAV occurs.

Command

*OPC

Query

*OPC?

Response

operation

Parameters

operation	Operation complete flag
1	: Operation complete

Sample programming

To query operation completion:
*OPC?

***RST**

Preset

Executing initialization (level: Instrument Initial)

Function

Executes initialization.

Command

*RST

Query

None

Response

None

Sample programming

To initialize at the Instrument Initial level:
*RST

Related commands

PRESET	Same function as *RST
PRE	Same function as *RST
IP	Same function as *RST
INI	Same function as *RST

Description

Initialization cannot be executed on the Standard Load screen. When an initialization command other than *RST is executed on the Standard Load screen, an error occurs.

Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

*SRE

Service Request Enable Command
Setting service request enable register

Function

Sets the service request enable register. When the event set in the service request enable register occurs, the MSS bit (bit 6) of the status byte register becomes “1” (true).

Command

*SRE register

Query

*SRE?

Response

register

Parameters

register Service request enable register

Value = bit0 + bit1 + ... + bit7

bit0 = $2^0 = 1$: Not used
bit1 = $2^1 = 2$: Not used
bit2 = $2^2 = 4$: END event status register
bit3 = $2^3 = 8$: ERR event status register
bit4 = $2^4 = 16$: MAV
bit5 = $2^5 = 32$: ESB
bit6 = $2^6 = 64$: Not used
bit7 = $2^7 = 128$: Not used

Description

From among the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the service request enable register; the sum of values of bits desired to be enabled becomes the parameter.

Sample programming

To set MSS bit to “1” (true) when an end event occurs:

*SRE 4

*STB?

Status Byte Register

Querying the status byte register

Function

Queries the status byte register value. Bit 6 of the status byte register is read out as MSS (master summary status).

Command

None

Query

*STB?

Response

register

Parameters

register Status byte register

Value = bit0 + bit1 + ... + bit7

bit0 = $2^0 = 1$: Not used
bit1 = $2^1 = 2$: Not used
bit2 = $2^2 = 4$: END event status register
bit3 = $2^3 = 8$: ERR event status register
bit4 = $2^4 = 16$: MAV
bit5 = $2^5 = 32$: ESB
bit6 = $2^6 = 64$: MSS
bit7 = $2^7 = 128$: Not used

Sample programming

To read the status byte register value:

*STB?

***TRG**

Trigger

Triggering

Function

None

Command

*TRG

Query

None

Response

None

***TST?**

Self Test

Querying the self test result

Function

Queries the self-diagnosis result.

Command

None

Query

*TST?

Response

test_result

Parameters

test_result Self-diagnosis result
 0 : Normal end

Sample programming

To query the self-diagnosis result:
*TST?

***WAI**

Wait to Continue

Waiting for command execution

Function

During command execution, puts the next command in waiting status.

Command

*WAI

Query

None

Response

None

Description

The *WAI command executes overlapped commands as sequential commands. This command is meaningless because MT8815B/MT8820B does not support overlapped commands.

Sample programming

To put the next command in waiting status:
*WAI

ALARM

Beep Sound

Setting beep sound

Function

Sets whether or not to sound the beep when an error occurs or for other conditions.

Command

ALARM on_off

Query

ALARM?

Response

on_off

Parameters

on_off Sets the beep sound.
 ON : Sounds the beep.
 OFF : Does not sound the beep.
 Initial value : ON (not initialized by Preset)

Sample programming

To set not to sound the beep:
 ALARM OFF

Related Command

BEP : Same function as ALARM (no query function)

BANDCAL

Band Calibration

Executing calibration within all bands of communication system supported by measurement software

Function

Executes calibration within all the bands of the communication system supported by the measurement software.

Command

BANDCAL

Query

None

Response

None

Parameters

None

Sample programming

To execute calibration within all the bands of the communication system supported by the measurement software:
BANDCAL

BANDCAL_TEMP

Band Calibration temperature

Executing calibration if the internal temperature changes by the specified temperature after performing calibration

Function

Executes calibration if the internal temperature changes by the specified temperature after performing calibration.

Command

BANDCAL_TEMP temperature

Query

None

Response

None

Parameters

temperature	temperature
Range	1.0 to 50.0°C
Resolution	0.1°C

Sample programming

To perform calibration if the internal temperature changes by 2°C:
BANDCAL_TEMP 2

BAUD

Baud Rate

Setting communication speed of the RS-232C communication port

Function

Sets the communication speed of the communication port used for RS-232C.

Command

BAUD baud

Query

BAUD?

Response

baud

Parameters

baud Communication speed (baud rate)

Range = 38400, 19200, 9600, 4800, 2400, 1200

Initial value: 4800

Description

Available only for MT8815B GPIB control. The query “BAUD?”, however, is available for serial (RS-232C) communication.

Sample programming

To set the communication speed to 9600 bps:

BAUD 9600

BEP

Beep Sound

Setting beep sound

Function

Sets whether or not to sound the beep when an error occurs or for other conditions.

Command

BEP on_off

Query

None

Response

None

Parameters

on_off Setting the beep sound.
 ON : Sounds the beep.
 OFF : Does not sound the beep.
 1 : Sounds the beep.
 0 : Does not sound the beep.
 Initial value : ON (not initialized by Preset)

Description

The beep sound setting can be inquired using the ALARM? query.

Sample programming

To set not to sound the beep:
 BEP 0

Related commands

ALARM : Same function as BEP (with query function).

BZR

Sound Buzzer

Sounding the buzzer

Function

Sounds the buzzer.

Command

BZR

Query

None

Response

None

Description

This function is available only for remote control.

Sample programming

To sound the buzzer:

BZR

CALCHK_RANGE

Band Calibration - Warning Range
Setting temperature range for warning display after Band Calibration

Function	Sets the temperature range for warning display after Band Calibration.	
Command	CALCHK_RANGE temperature	
Query	CALCHK_RANGE?	
Response	temperature	
Parameters	temperature	temperature
	Range	1 to 10 [°C]
	Initial value	2 [°C]
	Resolution	1 °C
Sample programming	To set the temperature range for which a warning is displayed to 2°C: CALCHK_RANGE 2	

CONTS

Continuous Measure

Starting measurement in continuous mode

Function

Starts measurement in continuous mode, that is, performs another measurement when one has completed.

Command

CONTS

Query

None

Response

None

Description

When MT8815B/MT8820B receives the next command during measurement started with the CONTS command, the measurement stops and processing for that command starts. When command processing is completed, the measurement restarts.

Sample programming

To start measurement in continuous mode:
CONTS

Related commands

S1 : Same function as CONTS

DATE

Date

Setting the date

Function

Sets the date. Query inquires the current date.

Command

DATE year,month,day

Query

DATE?

Response

year,month,day

Parameters

year Year
 Range = 2001 to 2030

month Month
 Range = 1 to 12

day Day
 Range = 1 to 31

Sample programming

To set the date to December 1, 2003:
DATE 2003,12,01

DATEMODE

Date Format

Setting the date format

Function

Sets the display format for the date.

Command

DATEMODE format

Query

DATEMODE?

Response

format

Parameters

format	Display format for the date
YMD	yyyy / mm / dd
MDY	mm / dd / yyyy
DMY	dd / mm / yyyy
Initial value	YMD (not initialized by Preset)
Where, yyyy: year, mm: month, dd: day.	

Sample programming

To display the date in dd/mm/yyyy format:
DATEMODE DMY

DELLOSSTBL

Delete Loss From List

Deleting the value from the Common Cable Loss List

Function

Deletes the value from the common cable loss list.

Command

DELLOSSTBL a,b

Query

None

Response

None

Parameters

a,b Specifies the deleted range.
Sets the range to be deleted: corresponding to No. of the registered common cable loss.

Description

If No. is not specified, the values of the common cable loss list are all deleted.

Sample programming

```
DELLOSSTBL 3,5 /*To delete Nos. 3 to 5 of the common cable loss
list*/
DELLOSSTBL      /*To delete all the values of the common cable loss
list*/
```

DELM

Delimiter

Setting delimiter type added to RS-232C messages or Ethernet messages

Function

Sets the type of delimiter to be added to RS-232C messages or Ethernet messages.

Command

DELM delimiter

Query

DELM?

Response

delimiter

Parameters

delimiter	Delimiter type
0	LF
1	CR/LF

Initial value 0 (not initialized by Preset)

Description

This function is only for remote control.

Sample programming

To set the delimiter to LF:
DELM 0

DISPL

Panel Display Power

Setting the power switch of the LCD panel

Function

Sets the power switch on the LCD panel to On/Off. Under full remote control, setting the LCD panel power to Off enables power-saving operation.

Command

`DISPL on_off`

Query

`DISPL?`

Response

`on_off`

Parameters

<code>on_off</code>	LCD panel power
ON	: LCD panel power On (normal display)
OFF	: LCD panel power Off
At power-on	: ON (not initialized by Preset)

Description

This function is available only for remote control.

Sample programming

To set the LCD panel power to Off:

```
DISPL OFF
```

DTAB

Data Bit

Setting bit length of the RS-232C communication port

Function

Sets the bit length of the communication port used for RS-232C.

Command

DTAB data

Query

DTAB?

Response

data

Parameters

data	Bit length
Range	7, 8
Initial value	8 bits

Description

Available only for MT8815B GPIB control. The query “DTAB?”, however, is available for serial (RS-232C) communication.

Sample programming

To set the bit length to 7 bits:
DTAB 7

ENCODER

ENCODER

Setting advancement direction for using rotary control to move cursor

Function

Sets the advancement direction for using rotary control to move cursor.

Command

ENCODER direction

Query

ENCODER

Response

direction

Parameters

direction	Advancement direction for using the rotary control to move the cursor
UPDOWN	Up/Down
LEFTRIGHT	Left/Right
Initial value	UPDOWN (not initialized by Preset)

Sample programming

To set the advancement direction for using the rotary control to move the cursor to left/right:
ENCODER LEFTRIGHT

ESE2

END Event Status Enable Register

Setting end event status enable register

Function

Sets the end event status enable register. When the set end-event occurs, the end summary bit (ESB, bit 2) of the status byte register becomes "1" (true).

Command

ESE2 register

Query

ESE2?

Response

register

Parameters

register End event status enable register

Value = bit0 + bit1 + ... + bit7

When using W-CDMA,TD-SCDMA or GSM measurement software

bit0 = $2^0 = 1$: Measurement/sweep complete

bit1 = $2^1 = 2$: Not used

bit2 = $2^2 = 4$: Reception measurement complete

bit3 = $2^3 = 8$: Transmission measurement complete

bit4 = $2^4 = 16$: Audio measurement complete

bit5 = $2^5 = 32$: Not used

bit6 = $2^6 = 64$: Not used

bit7 = $2^7 = 128$: Not used

When using CDMA2000 or 1xEV-DO measurement software

bit0 = $2^0 = 1$: All measurements complete
(on the Fundamental Measurement screen)
Measurement complete

(on the Access Probe Measurement screen, the
Open Loop Time Response screen, or the Multi
Power Measurement screen)

bit1 = $2^1 = 2$: Access Probe Power measurement complete
(on the Fundamental Measurement screen)
Measurement complete

(on the Access Probe Measurement screen)

bit2 = $2^2 = 4$: Reception measurement complete

bit3 = $2^3 = 8$: Transmission measurement complete (excepting Access Probe Power)
bit4 = $2^4 = 16$: Audio measurement complete
bit5 = $2^5 = 32$: Not used
bit6 = $2^6 = 64$: Not used
bit7 = $2^7 = 128$: Not used
When using PHS measurement software	
bit0 = $2^0 = 1$: Measurement/sweep complete
bit1 = $2^1 = 2$: Not used
bit2 = $2^2 = 4$: Reception measurement complete
bit3 = $2^3 = 8$: Transmission measurement complete
bit4 = $2^4 = 16$: Not used
bit5 = $2^5 = 32$: Calibration complete
bit6 = $2^6 = 64$: Output level setting complete
bit7 = $2^7 = 128$: External trigger synchronization complete

Description

From among the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the end event status enable register; the sum of values of bits desired to be enabled becomes the parameter.

Sample programming

To enable the measurement/sweep end event:

```
ESE2 1      /*20 = 1*/
```

ESE3

ERR Event Status Enable Register

Setting error event status enable register

Function

Sets the error event status enable register. When the set error-event occurs, the end summary bit (ESB, bit 3) of the status byte register becomes "1" (true).

Command

ESE3 register

Query

ESE3?

Response

register

Parameters

register Error event status enable register

Value = bit0 + bit1 + ... + bit7

When using W-CDMA, TD-SCDMA, GSM or PHS measurement software

bit0 = $2^0 = 1$: Synchronization loss (bit error rate measurement)
bit1 = $2^1 = 2$: Not used
bit2 = $2^2 = 4$: Transmission measurement error
bit3 = $2^3 = 8$: Reception measurement error
bit4 = $2^4 = 16$: Call processing error
bit5 = $2^5 = 32$: Not used
bit6 = $2^6 = 64$: Call drop error
bit7 = $2^7 = 128$: Not used

When using CDMA2000 or 1xEV-DO measurement software

bit0 = $2^0 = 1$: Open Loop Time Response error (on the Open Loop Time Response screen) Multi Power Measurement error (on the Multi Power Measurement screen)
bit1 = $2^1 = 2$: Access Probe Power measurement error (on the Fundamental Measurement screen) Access Probe Measurement error (on the Access Probe Measurement screen)
bit2 = $2^2 = 4$: Transmission measurement error (excepting Access Probe Power)

8.2 Command Specifications in Alphabetical Order

bit3 = $2^3 = 8$: Reception measurement error
bit4 = $2^4 = 16$: Call processing error
bit5 = $2^5 = 32$: Not used
bit6 = $2^6 = 64$: Call drop error
bit7 = $2^7 = 128$: Not used

Description

From among the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the error event status enable register; the sum of values of bits desired to be enabled becomes the parameter.

Sample programming

To enable transmission measurement error and reception measurement error events:

```
ESE3 12      /*Transmission error ( $2^2 = 4$ ) + reception error ( $2^3 = 8$ )* /
```

ESR2?

END Event Status Register Query

Reading end event status register

Function

Reads the end event status register. The event that occurred can be identified with the read value.

Command

None

Query

ESR2?

Response

register

Parameters

register End event status register

Value = bit0 + bit1 + ... + bit7

When using W-CDMA, TD-SCDMA or GSM measurement software

bit0 = $2^0 = 1$: Measurement/sweep complete

bit1 = $2^1 = 2$: Not used

bit2 = $2^2 = 4$: Reception measurement complete

bit3 = $2^3 = 8$: Transmission measurement complete

bit4 = $2^4 = 16$: Audio measurement complete

bit5 = $2^5 = 32$: Not used

bit6 = $2^6 = 64$: Not used

bit7 = $2^7 = 128$: Not used

When using CDMA2000 or 1xEV-DO measurement software

bit0 = $2^0 = 1$: Measurement of all selected items complete
(on the Fundamental Measurement screen)
Measurement complete

(on the Access Probe Measurement screen, the
Open Loop Time Response screen, or the Multi
Power Measurement screen)

bit1 = $2^1 = 2$: Access Probe Power measurement complete
(on the Fundamental Measurement screen)
Measurement complete

(on the Access Probe Measurement screen)

bit2 = $2^2 = 4$: Reception measurement complete

bit3 = $2^3 = 8$: Transmission measurement complete (excepting
Access Probe Power)

bit4 = $2^4 = 16$: Audio measurement complete
bit5 = $2^5 = 32$: Not used
bit6 = $2^6 = 64$: Not used
bit7 = $2^7 = 128$: Not used

When using PHS measurement software

bit0 = $2^0 = 1$: Measurement/sweep complete
bit1 = $2^1 = 2$: Not used
bit2 = $2^2 = 4$: Reception measurement complete
bit3 = $2^3 = 8$: Transmission measurement complete
bit4 = $2^4 = 16$: Not used
bit5 = $2^5 = 32$: Calibration complete
bit6 = $2^6 = 64$: Output level setting complete
bit7 = $2^7 = 128$: External trigger synchronization complete

Description

The parameter is the sum of the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the end event status enable register. When the response is read, the end event status register is cleared.

Sample programming

To read end event status register:
ESR2?

ESR3?

Standard Event Status Register Query
Reading the error event status register

Function

Reads the error event status register. The event that occurred can be identified with the read value.

Command

None

Query

ESR3?

Response

register

Parameters

register Error event status register

Value = bit0 + bit1 + ... + bit7

When using W-CDMA, TD-SCDMA GSM or PHS measurement software

bit0 = $2^0 = 1$: Synchronization loss (bit error rate measurement)
 bit1 = $2^1 = 2$: Not used
 bit2 = $2^2 = 4$: Transmission measurement error
 bit3 = $2^3 = 8$: Reception measurement error
 bit4 = $2^4 = 16$: Call processing error
 bit5 = $2^5 = 32$: Not used
 bit6 = $2^6 = 64$: Call drop error
 bit7 = $2^7 = 128$: Not used

When using CDMA2000 or 1xEV-DO measurement software

bit0 = $2^0 = 1$: Open Loop Time Response error
 (on the Open Loop Time Response screen)
 Multi Power Measurement error
 (on the Multi Power Measurement screen)
 bit1 = $2^1 = 2$: Access Probe Power measurement error
 (on the Fundamental Measurement screen)
 Access Probe Measurement error
 (on the Access Probe Measurement screen)
 bit2 = $2^2 = 4$: Transmission measurement error (excepting
 Access Probe Power)
 bit3 = $2^3 = 8$: Reception measurement error

bit4 = $2^4 = 16$: Call processing error
bit5 = $2^5 = 32$: Not used
bit6 = $2^6 = 64$: Call drop error
bit7 = $2^7 = 128$: Not used

Description

The parameter is the sum of the values $2^0 = 1$, $2^1 = 2$, $2^2 = 4$, $2^3 = 8$, $2^4 = 16$, $2^5 = 32$, $2^6 = 64$, and $2^7 = 128$, which correspond to bits 1, 2, 3, 4, 5, 6 and 7 of the error event status enable register. When the Response is read, the error event status register is cleared.

Sample programming

To read the error event status register:
ESR3?

EXTREF?

External Reference

Setting and Reading status of reference frequency

Function

Queries the setting of Ref. Frequency on the System Configuration Window, and the status of input reference signal supported by the setting.

Command

None

Query

EXTREF?

Response

ref_status

Parameters

ref_status	Ref. Frequency
INT	Setting of Ref. Frequency is 10 MHz(INT)
VALID	When setting of Ref. Frequency is 10 MHz(EXT) or 13 MHz(EXT), and detected synchronous of input reference signal
INVALID	When setting of Ref. Frequency is 10 MHz(EXT) or 13 MHz(EXT), and does not detect synchronous of input reference signal

Sample programming

To query the status of input reference signal supported by the setting of Ref. Frequency:
EXTREF?

FULLCAL

Full Calibration

Executing calibration for all input/output bands of MT8815B/MT8820B

Function

Executes calibration for all the input/output bands of the MT8815B/MT8820B.

Command

FULLCAL

Query

None

Response

None

Parameters

None

Sample programming

To execute calibration for all the input/output bands of the MT8815B/MT8820B:
FULLCAL

FULLCAL_TM?

Full Cal Time
Querying the time for the last Full Calibration

Function
Queries the time for the last Full Calibration.

Command
None

Query
FULLCAL_TM?

Response
year , month , day , hour , min

Parameters

year	year	(2001 to
month	month	(1 to 12)
day	day	(1 to 31)
hour	hour	(0 to 23)
min	minutes	(0 to 59)

Sample programming

To query the time for the last Full Calibration:
FULLCAL_TM?

GTL

Go to Local

Changing to the local control

Function

Changes the remote control to the local control.

Command

GTL

Query

None

Response

None

Parameters

None

Sample programming

To return to local control during remote control:

GTL

INI

Preset
Executing initialization

Function

Executes initialization.

Command

INI

Query

None

Response

None

Description

Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

Sample programming

To execute initialization:
INI

Related commands

*RST	Same function as INI
PRESET	Same function as INI
PRE	Same function as INI
IP	Same function as INI

IP

Preset

Executing initialization

Function

Executes initialization.

Command

IP

Query

None

Response

None

Description

Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

Sample programming

To execute initialization:

IP

Related commands

*RST	Same function as IP
PRESET	Same function as IP
PRE	Same function as IP
INI	Same function as IP

LOSSTBLSAMPLE?

Number of External Loss Common Table	
Recalling the number of the lists that are set in the Common Cable Loss List	
Function	Recalls the number of the lists that are set in the common cable loss list.
Command	None
Query	LOSSTBLSAMPLE?
Response	n
Parameter	n Number of lists Range = 0 to 100
Sample programming	To recall the number of the lists that are set to the common cable loss list: LOSSTBLSAMPLE?

LOSSTBLVAL

Regist Loss into List

Setting the value in the Common Cable List

Function

Sets the value in the common cable loss list. If the same frequency exists in the table, it is overwritten.

Command

LOSSTBLVAL f,l1,l2,l3

Query

LOSSTBLVAL? n

Response

f,l1,l2,l3

Parameters

- n Table position
Range = 1 to 100
- f Frequency
Range = 0.4 to 2700.0 [MHz]
Resolution 10 Hz
- 11 External Loss value of DL (Main)
Range = -55.00 to 55.00 [dB]
Resolution 0.01 dB
- 12 External Loss value of UL (Main)
Range = -55.00 to 55.00 [dB]
Resolution 0.01 dB
- 13 External Loss value of DL (AUX)
Range = -55.00 to 55.00 [dB]
Resolution 0.01 dB

Sample programming

To set the common cable loss list to 2500.000000 MHz, 30.00 dB, 15.00 dB, -10.00 dB:

LOSSTBLVAL 2500000000,30.00,15.00,-10.00

LOSSVIEW_STAFREQ

Start Frequency

Setting the start frequency of the Common Cable Loss Graph

Function

Sets the start frequency on the horizontal axis of the common cable loss graph.

Command

LOSSVIEW_STAFREQ f

Query

LOSSVIEW_STAFREQ?

Response

f

Parameters

f Frequency
 Range = 0.4 to 2700.0 [MHz]
 Initial value 0.4 [MHz]
 Resolution 0.1 MHz

Description

The upper limit of parameters cannot be set to the value larger than the value of the Stop Frequency.

Sample programming

To set 100.0 MHz for the start frequency on the horizontal axis of the common cable loss graph:
 LOSSVIEW_STAFREQ 100.0MHz

Related commands

LOSSVIEW_STPFREQ Sets the stop frequency of the common cable loss.

LOSSVIEW_STPFREQ

Stop Frequency

Setting the stop frequency of the common cable loss graph

Function

Sets the stop frequency on the horizontal axis of the common cable loss graph.

Command

LOSSVIEW_STPFREQ f

Query

LOSSVIEW_STPFREQ?

Response

f

Parameters

f Frequency
 Range = 0.4 to 2700 [MHz]
 Initial value 2700 [MHz]
 Resolution 0.1 MHz

Description

The lower limit of parameters cannot be set to the value smaller than the value of the Start Frequency.

Sample programming

To set 2500.0 MHz for the stop frequency on the horizontal axis of the common cable loss graph:
LOSSVIEW_STPFREQ 2500.0MHz

Related commands

LOSSVIEW_STAFREQ Sets the start frequency of the common cable loss.

LOSSVIEW_VSCALE

Vertical Scale

Setting the scale of the Common Cable Loss Graph

Function

Sets the scale on the horizontal axis of the common cable loss graph.

Command

LOSSVIEW_VSCALE mode

Query

LOSSVIEW_VSCALE?

Response

mode

Parameters

mode	Scale
	Range = 10, 20, 30, 40, 50, 60
	Initial value 50

Sample programming

To set ± 30 dB for the vertical axis on the common cable loss graph:
LOSSVIEW_VSCALE 30

MCCF?

Compact Flash

Querying the Compact Flash size and unused area

Function

Queries the size and unused area of Compact Flash inside the MT8815B/MT8820B.

Command

None

Query

MCCF?

Response

a,b

Parameters

a CF Type

b CF Unused Area

Unit MB,kbyte

Sample programming

To query the CF size and unused area:

MCCF?

MCFV?

Firmware Version

Querying the firmware version

Function

Queries the firmware version used on MT8815B/MT8820B.

Command

None

Query

MCFV?

Response

version

Parameters

version Firmware version

Sample programming

To query the version of the main firmware:
MCFV?

MCHV?

Hardware Revision

Querying the revision number of the hardware installed in the MT8815B/8820B

Function

Queries the revision number of the hardware installed in the MT8815B/MT8820B.

Command

None

Query

MCHV?

Response

maid,marev,mafpga,tdid1,tdrev1,tdfpga1,cdid1,cdrev1,
cdfpga1,evid1,evrev1,evfpga1,wcid1,wcrev1,wcfpga1,mdid1,
mdrev1,mdfpga1,daid,darev,dafpga,tdid2,tdrev2,tdfpga2,
cdid2,cdrev2,cdfpga2,evid2,evrev2,evfpga2,wcid2,wcrev2,
wcfpga2,mdid2,mdrev2,mdfpga2,auid,aurev,aufpga

Parameters

Main CPU

maid	Main CPU ID number
marev	Main CPU hardware revision number
mafpga	Main CPU CoreFPGA version number

TDMA COM1

tdid1	TDMA COM1 ID number
tdrev1	TDMA COM1 hardware revision number
tdfpga1	TDMA COM1 CoreFPGA version number

CDMA2000 COM1

cdid1	CDMA2000 COM1 ID number
cdrev1	CDMA2000 COM1 hardware revision number
cdfpga1	CDMA2000 COM1 CoreFPGA version number

1xEV-DO COM1

evid1	1xEV-DO COM1 ID number
evrev1	1xEV-DO COM1 hardware revision number
evfpga1	1xEV-DO COM1 CoreFPGA version number

W-CDMA COM1

wcid1	W-CDMA COM1 ID number
wcrev1	W-CDMA COM1 hardware revision number
wcfpga1	W-CDMA COM1 CoreFPGA version number

8.2 Command Specifications in Alphabetical Order

Measure DSP1	
mdid1	Measure DSP1 ID number
mdrev1	Measure DSP1 hardware revision number
mdfpga1	Measure DSP1 CoreFPGA version number
DAC/ADC	
daid	DAC/ADC ID number
darev	DAC/ADC hardware revision number
dafpga	DAC/ADC CoreFPGA version number
TDMA COM2	
tdid2	TDMA COM2 ID number
tdrev2	TDMA COM2 hardware revision number
tdfpga2	TDMA COM2 CoreFPGA version number
CDMA2000 COM2	
cdid2	CDMA2000 COM2 ID number
cdrev2	CDMA2000 COM2 hardware revision number
cdfpga2	CDMA2000 COM2 CoreFPGA version number
1xEV-DO COM2	
evid2	1xEV-DO COM2 ID number
evrev2	1xEV-DO COM2 hardware revision number
evfpga2	1xEV-DO COM2 CoreFPGA version number
W-CDMA COM2	
wcid2	W-CDMA COM2 ID number
wcrev2	W-CDMA COM2 hardware revision number
wcfpga2	W-CDMA COM2 CoreFPGA version number
Measure DSP2	
mdid2	Measure DSP2 ID number
mdrev2	Measure DSP2 hardware revision number
mdfpga2	Measure DSP2 CoreFPGA version number
Audio	
auid	Audio ID number
aurev	Audio hardware revision number
aufpga	Audio CoreFPGA version number

Description

Responses for Phone-2 are displayed when the Parallelphone Measurement Software is installed in the MT8820B.

Sample programming

To query the version of the hardware installed in the MT8815B/MT8820B:
MCHV?

MCIV?

IPL Version

Querying the IPL version

Function

Queries the version of the IPL used on the MT8815B/MT8820B.

Command

None

Query

MCIV?

Response

version

Parameters

version Version

Sample programming

To query the version of the IPL:
MCIV?

MCMSV?

Software Version

Querying the software version

Function

Queries the version of the software that is used on the MT8815B/MT8820B and is loaded.

Command

None

Query

MCMSV? n

Response

std,version

Parameters

n Standard number
 1 through 3

std	Measurement software (Standard)
WCDMA	MX882000C or MX882030C W-CDMA Measurement Software/ W-CDMA Measurement Software Lite
GSM	MX882001C or MX882031C GSM Measurement Software/ GSM Measurement Software Lite
CDMA2K	MX882002C/MX882003C or MX882006C CDMA2000 Measurement Software/1xEV-DO Measurement Software
PHS	MX882005C PHS Measurement Software
TDSCDMA	MX882007C TD-SCDMA Measurement Software
version	Software version

Description

When parameter n is omitted, the versions of all the software registered to Standard 1 through 3 are queried.

Sample programming

To query the software version of the Standard1:
MCMSV? 1

MCOPT?

Option Number

Querying the software option number

Function

Queries the software option number.

Command

None

Query

MCOPT? a

Response

n,n1,n2,...

Parameters

a	Option name
n	count
n1,n2,...	Option number

Description

The option number is the number following the hyphen (-) in the model name. For example, in MX882001C-002, “002” is the option number.

The option number indicates the function of that option.

Example)

1: GSM voice codec

2: GSM external packet data

... and so on

Sample programming

To query the option number of the installed option (software) MX882001C:

MCOPT? MX882001C

Response example)

When the GSM measurement software, GSM voice codec (MX882001C-001) and GSM external packet data (MX882001C-002) have been installed:

2,1,2

MCOV?

OS Version
Querying the OS version

Function	Queries the version of the OS used on the MT8815B/MT8820B.	
Command	None	
Query	MCOV?	
Response	version	
Parameters	version	Version
Sample programming	To query the version of the OS: MCOV?	

MCSOPT?

Type Name of Option

Querying the type name of the installed option

Function

Queries the type name of the installed option.

Command

None

Query

MCSOPT?

Response

n,a1,a2,a3,...

Parameters

n The number of installed options
a1,a2,a3,... Type name of option

Sample programming

To query the type name of the installed option:
MCSOPT?

Response example)

When the W-CDMA, FOMA Scenario, GSM and CDMA2000 have been installed:

4, MX882000C,MX882051C,MX882001C,MX882002C

MCSV?

Version Information of Option module Software

Querying the software option version

Function

Queries the version of the software option.

Command

None

Query

MCSV? a

Response

version

Parameters

a	Option name
version	Version data

Sample programming

To query the version of the W-CDMA measurement software:
MCSV? MX882000C

Response example)

When the version is 3.10 #001:
V3.10 #001

MEASSTOP

Measure Stop

Stopping measurement

Function

Stops the measurement currently being performed.

Command

MEASSTOP

Query

None

Response

None

Description

Measurement started with the SWP or TS command cannot be stopped until measurement is completed, and thus this MEASSTOP command is not effective. To stop the measurement halfway, measurement must have been started with the SNGLS, S2 or CONTS, S1 command.

Sample programming

To stop measurement halfway:

SNGLS / *Starts measurement* /

MEASSTOP / *Stops measurement* /

MOD

Modulation On/Off

Setting modulation/non-modulation for output signals

Function

Sets modulation/non-modulation for output signals.

Command

MOD on_off

Query

MOD?

Response

on_off	Sets modulation/non-modulation
ON	Outputs modulation signals.
OFF	Outputs non-modulation signals.
Initial value	ON

Description

Sets modulation/non-modulation for RF signals output from the MT8815B/MT8820B.

Sample programming

To set non-modulation for output signals:
MOD OFF /*Non-modulation*/

PRE

Preset

Executing initialization

Function

Executes initialization.

Command

PRE

Query

None

Response

None

Description

Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

Sample programming

To execute initialization:

PRE

Related commands

*RST	Same function as PRE
PRESET	Same function as PRE
IP	Same function as PRE
INI	Same function as PRE

PRESET

Preset
Executing initialization

Function

Executes initialization.

Command

PRESET

Query

None

Response

None

Parameters

None

Description

Initialization may not be performed depending on the connection status with the mobile terminal. For details, refer to the description concerning initialization in the operation manual of each measurement software.

Sample programming

To execute initialization:
PRESET

Related commands

*RST	: Same function as PRESET
PRE	: Same function as PRESET
IP	: Same function as PRESET
INI	: Same function as PRESET

PRMRECALL

Recall Parameter

Reading settings (file number specified)

Function

Reads the parameter file and reflects the settings at MT8815B/MT8820B.

Command

PRMRECALL fnumber

Query

None

Response

None

Parameters

fnumber File number
Range = 0 to 999

Description

This command can only read a file whose saved file name is in the format of “default file name + file number.” The default file name varies depending on the measurement software.

Sample programming

To read settings of parameter file number 10:
PRMRECALL 10

Related commands

PRMRECALLNAME : Reading the file of a specified file name

PRMRECALLNAME

Recall Parameter

Reading settings (name specified)

Function

Reads the parameter file and reflects the settings at MT8815B/MT8820B.

Command

PRMRECALLNAME fname

Query

None

Response

None

Parameters

fname File name (up to 8 characters)

Sample programming

To read settings of parameter file name TEST:
PRMRECALLNAME "TEST"

Related Command

PRMRECALL : Reading the file of a specified file number

PRMSAVE

Save Parameter

Saving parameter settings (file number specified)

Function

Saves parameter settings as a file.

Command

PRMSAVE fnumber

Query

None

Response

None

Parameters

fnumber File number (optional)

Range = 0 to 999

When omitted, the file is saved with the smallest number of those unused.

Description

The file saved with this command is assigned a name in the format of “default file name + file number.” The default file name varies depending on the measurement software.

Sample programming

To save a file with parameter file number 12:

PRMSAVE 12

PRMSAVENAME

Save Parameter

Saving parameter settings (name specified)

Function

Saves the parameter settings as a file.

Command

PRMSAVENAME fname

Query

None

Response

None

Parameters

fname File name (maximum 8 characters)
 Available characters A to Z, 0 to 9, #, -, _

Sample programming

To save the settings with parameter file name "TEST":
PRMSAVENAME "TEST"

PRTY

Parity Bit

Setting parity check of RS-232C communication port

Function

Sets parity check in the communication port used for RS-232C.

Command

PRTY parity

Query

PRTY?

Response

parity

Parameters

parity	Parity
EVEN	Even parity
ODD	Odd parity
OFF	No parity
Initial value	OFF

Description

Available only for MT8815B GPIB control. The query “PRTY?”, however, is available for serial (RS-232C) communication.

Sample programming

To set even parity:
PRTY EVEN

PSETDEFGTWY

10BaseT - Default Gateway
Setting default gateway

Function

Sets the default gateway for the 10Base-T port on the MT8815B/MT8820B.

Command

PSETDEFGTWY n1,n2,n3,n4

Query

PSETDEFGTWY?

Response

n1,n2,n3,n4

Parameters

n1,n2,n3,n4	Default Gateway
Range = 0,0,0,0 to 255,255,255,255	
Resolution	1
Suffix code	None
Initial value	192,168,20,1 (not initialized by Preset)

Sample programming.

To set the default gateway for the 10Base-T port on the MT8815B/MT8820B to 192.168.0.1:
PSETDEFGTWY 192,168,0,1

PSETIPADDR

10BaseT - IP Address

Setting IP Address

Function

Sets the IP Address for the 10Base-T port on the MT8815B/MT8820B.

Command

PSETIPADDR n1,n2,n3,n4

Query

PSETIPADDR?

Response

n1,n2,n3,n4

Parameters

n1,n2,n3,n4	IP address
Range	= 0,0,0,0 to 255,255,255,255
Resolution	1
Suffix code	None
Initial value	192,168,20,2 (not initialized by Preset)

Sample programming

To set the IP Address for the 10Base-T port on the MT8815B/MT8820B to 192.168.0.55:

PSETIPADDR 192,168,0,55

PSETSNM

10BaseT - Subnet Mask
Setting subnet mask

Function

Sets the subnet mask for the 10Base-T port on the MT8815B/MT8820B.

Command

PSETSNM n1,n2,n3,n4

Query

PSETSNM?

Response

n1,n2,n3,n4

Parameters

n1,n2,n3,n4	Subnet Mask
	Range = 0,0,0,0 to 255,255,255,255
Resolution	1
Suffix code	none
Initial value	255,255,255,0 (not initialized by Preset)

Sample programming

To set the subnet mask for the 10Base-T port on the MT8815B/MT8820B to 255.255.255.1:
PSETSNM 255,255,255,1

REF

Reference Frequency

Setting reference frequency

Function

Sets the reference frequency.

Command

REF ref_freq

Query

REF?

Response

ref_freq

Parameters

ref_freq	Reference frequency
10MHZINT	: Internal reference frequency oscillator: 10 MHz
10MHZEXT	: External input reference frequency: 10 MHz
13MHZEXT	: External input reference frequency: 13 MHz
Initial value	: 10MHZINT

Sample programming

To set external input reference frequency (13MHz) as the reference frequency to be used:

REF 13MHZEXT

REMDISP

Remote Control Display Mode
Setting error processing

Function

Sets error* processing mode during remote control.

* Indicates the errors that are displayed in the pop-up window. Measurement errors and call processing errors are not included.

Command

REMDISP mode

Query

REMDISP?

Response

mode

Parameter

mode	Error processing mode during remote control
NORMAL	Normal mode When an error occurs, it ignores it and continues the subsequent command processing. The pop-up window for the error is displayed when the error occurs, it then disappears when the subsequent command is processed.
REMAIN	Error remain mode Displays the pop-up window for an error until another error occurs. When an error occurs by processing the subsequent command, a pop-up window for the error is displayed.
STOP	Stop mode When an error occurs, it displays a pop-up window for it and stops processing the subsequent command.
Initial value	NORMAL (not initialized by Preset)

Description

This function is available only for remote control.

Sample programming

To stop processing when an error occurs during remote control:
REMDISP STOP

RFOUT

RF Output

Setting the RF signal output connector

Function

Sets the RF signal output connector.

Command

RFOUT out

Query

RFOUT?

Response

out

Parameters

out	RF signal output connector
MAIN	: Main input/output connector
AUX	: Auxiliary output connector
Initial value	: MAIN (not initialized by Preset)

Sample programming

To set the auxiliary output connector as the output destination for Phone:
RFOUT AUX

RLCD?

Directory Pass

Querying a path to the reading directory

Function

Queries the absolute path to the directory in which the parameter set file to be read. If the memory card is not inserted, an error message will be displayed.

Command

None

Query

RLCD?

Response

dir_path

Parameters

dir_path Path to the reading directory

Sample programming

To query the path to the reading directory:
RLCD?

RLFLIST?

File List

Reading out the file stored in reading directory

Function

In reading the parameter file, queries the name and attribute of the file saved in the reading directory of the memory card. If there are no files, an error will be displayed.

Command

None

Query

RLFLIST?

Response

num, a1, name1, a2, name2, . . . , a(num), name(num)

Parameters

num Total number of files (including directory)

a(x) Attribute of x'th file

1 : Archive file (including files with no attribute)

2 : Read-only file

name(x) Parameter setting file name (maximum 255 characters)

Sample programming

To query a list of parameter setting files in the reading directory:

RLFLIST?

RLLOSSTBL

Load List

Recalling the Common Cable Loss List from the memory card

Function

Recalls the common cable loss list from the memory card.

Command

RLLOSSTBL file

Query

None

Response

None

Parameters

file File name

Sample programming

To recall the common cable loss list from the memory card using the file named SAMPLE:

RLLOSSTBL SAMPLE

S1

Measure - Continuous

Starting measurement in continuous mode

Function

Starts measurement in continuous mode, that is, performs another measurement when one has completed.

Command

S1

Query

None

Response

None

Description

When MT8815B/MT8820B receives the next command during measurement started with the S1 command, the measurement stops and processing for that command starts. When command processing is completed, the measurement restarts.

Sample programming

To start measurement in continuous mode:
S1

Related commands

CONTS Same function as S1.

S2

Measure - Single

Starting measurement in single mode

Function

Starts measurement in single mode.

Command

S2

Query

None

Response

None

Description

When MT8815B/MT8820B receives the next command during measurement (started with the S2 command), the measurement stops and processing for the next command starts. To allow processing for the next command after measurement is over; use the SWP command, instead of S2 command.

Sample programming

To start measurement in single mode:

S2

Related commands

SNGLS	: Same function as S2
SWP	: Starting measurement in synchronous single mode
TS	: Starting measurement in synchronous single mode

SCRACT

Change Active Window
Changing active window

Function

Switches the active window. To use this command, the screen that the window belongs must be opened.

Command

SCRACT window

Query

SCRACT?

Response

window

Parameters

window	Window name
LOSSLIST:	Ext. Loss List window (common cable loss list window)
LOSSVIEW:	Ext. Loss View window (common cable loss graph window)
STDLOAD:	Standard Load window (setup window)
SOFTLIST:	Software List window (list display window)

Description

In the remote control mode, it is not necessary to change the window active when performing an operation for items on that window. For example, when setting the measurement application on the Standard Load screen, the setup is performed directly by the remote control command even if the Software list window is active.

Refer to the separate manual of each measurement software for selecting a window on a measurement screen.

Sample programming

To make the Standard Load window on the Standard Load screen active:

```
SCRSEL STDLOAD /*Opens the Standard Load screen*/  
SCRACT STDLOAD /*Makes the Standard Load window active*/
```


SCREEN

Drawing

Setting drawing operation

Function

Sets whether or not to perform drawing on the screen. In a remote control mode, setting SCREEN OFF improves the measurement throughput. If drawing is set to Off, the screen displays “Screen Off.”

Command

SCREEN on_off

Query

None

Response

on_off

Parameters

on_off	Drawing on screen
ON	: Draw (normal display)
OFF	: Does not draw (normal display)
At power-on	: ON (not initialized by Preset)

Description

This command is available only for remote control.

Sample programming

To set drawing to Off:
SCREEN OFF

SCRSEL

Select Screen

Selecting a screen

Function

Selects a screen.

Command

SCRSEL screen

Query

SCRSEL?

Response

screen

Parameters

screen	Screen name
PRMSAVE	Parameter Save screen
PRMRCL	Parameter Recall screen
SYSCFG	System Configuration screen
SYSINFO	System Information screen
CEXTLOSS	Common External Loss screen
STDLOAD	Standard Load screen

Description

For selecting the measurement screen, refer to the separate operation manual for the measurement software.

Sample programming

To select the System Configuration screen:
SCRSEL SYSCFG

SERIAL?

Serial Number

Querying a serial Number

Function

Inquires the serial number specific to MT8815B/MT8820B.

Command

None

Query

SERIAL?

Response

serial_number

Parameters

serial_number Serial number

Sample programming

To query the serial number:

SERIAL?

SNGLS

Measure - Single

Starting a measurement in the single mode

Function

Starts a measurement in the single mode.

Command

SNGLS

Query

None

Response

None

Description

When the measurement is started with the SNGLS command and MT8815B/MT8820B receives the next command during measurement, the measurement stops and processing for the next command starts. Pressing during measurement changes the mode to local control. To allow processing the next command after measurement is over; use the SWP command.

Sample programming

To start measurement in the single mode:
SNGLS

Related commands

S2	Same function as SNGLS
SWP	Starting measurement in synchronous single mode
TS	Starting measurement in synchronous single mode

STDLOAD

Load Standard

Loading measurement software

Function

Activates measurement software. Each measurement software is optional. To use this command, measurement software must be installed in advance.

Command

STDLOAD n,std

Query

None

Response

None

Parameters

n	Standard number 1 through 3
std	Measurement software (Standard)
WCDMA	MX882000C or MX882030C W-CDMA Measurement Software/ W-CDMA Measurement Software Lite
GSM	MX882001C or MX882031C GSM Measurement Software/ GSM Measurement Software Lite
CDMA2K	MX882002C/MX882003C or MX882006C CDMA2000 Measurement Software/1xEV-DO Measurement Software
PHS	MX882005C PHS Measurement Software
TDSCDMA	MX882007C TD-SCDMA Measurement Software

Description

This command is valid only on the Standard Load screen. An error occurs if the software to be loaded to MT8815B/MT8820B has already been loaded in the target Phone.

Sample programming

To load GSM measurement software to the Standard1:
STDLOAD 1,GSM

STDSEL

Select Standard

Selecting the measurement software

Function

Selects the measurement software. Measurement software is optional. To use this command, measurement software must be loaded in advance.

Command

STDSEL std

Query

STDSEL?

Response

std

Parameters

std	Measurement software (Standard)
WCDMA	MX882000C or MX882030C W-CDMA Measurement Software/ W-CDMA Measurement Software Lite
GSM	MX882001C or MX882031C GSM Measurement Software/ GSM Measurement Software Lite
CDMA2K	MX882002C/MX882003C or MX882006C CDMA2000 Measurement Software/1xEV-DO Measurement Software
PHS	MX882005C PHS Measurement Software
TDSCDMA	MX882007C TD-SCDMA Measurement Software

Sample programming

To select GSM for the measurement software to be used:

STDSEL GSM

STDUNLOAD

Unload Standard

Unloading measurement software

Function

Unloads measurement software.

Command

STDUNLOAD n

Query

None

Response

None

Parameters

n Standard number
 1 through 3

Description

This command is valid only on the Standard Load screen.

Sample programming

To unload the measurement software applied to the Standard1:
STDUNLOAD 1

STPB

Stop Bit

Setting stop bit of RS-232C communication port

Function

Sets the stop bit of the communication port used for RS-232C.

Command

STPB stp

Query

STPB?

Response

stp

Parameters

stp	Stop bit
Range	1, 2
Initial value	1 bit

Description

Available only for MT8815B GPIB control. The query “STPB?”, however, is available for serial (RS-232C) communication.

Sample programming

To set the stop bit to bit 2:
STPB 2

SVCD?

Save Directory Path

Querying the path to the parameter save directory

Function

Queries the path to the directory where the parameter file is saved. If the memory card is not inserted, an error message will be displayed.

Command

None

Query

SVCD?

Response

dir_path

Parameter

dir_path Path to the save directory

Sample program

To read the path to the save directory:
SVCD?

SVDEFFILE?

Default File Name

Querying the default name for parameter file

Function

Queries the file name to be automatically created when saving the setting parameters.

Command

None

Query

SVDEFFILE?

Response

fname

Parameters

fname Saving file name

Sample programming

To query the default name for saving file:
SVDEFFILE?

SVFLIST?

File List

Querying the file stored in the parameter saving directory

Function

Queries the name and attribute of the file saved in the directory where the memory card parameter is saved.

Command

None

Query

SVFLIST?

Response

num,a1,name1,a2,name2,...,a(num),name(num)

Parameters

num Total number of files (including the directory)

a(x) File attribute

0 : No file

1 : Archive file (including files without attributes)

2 : Read-only file

name(x) Parameter file name (maximum of 255 characters)

Sample programming

To query a list of parameter files:

SVFLIST?

SVLOSSTBL

Save List

Saving the Common Cable Loss List on the memory card

Function

Saves the common cable loss list on the memory card.

Command

SVLOSSTBL file

Query

None

Response

None

Parameters

file File name (maximum 8 characters)
 Available characters A to Z, 0 to 9, #, -, _

Sample programming

To save the common cable loss list on the memory card:
SVLOSSTBL sample

SWP

Measure - Single (Synchronization)

Starting a measurement in the synchronous single mode

Function

Starts a measurement in the single mode. Processing for the next command does not start before completion of the measurement, allowing synchronization between MT8815B/MT8820B and controller.

Query inquires whether or not the measurement has been completed.

Command

SWP

Query

SWP?

Response

status

Parameters

status	Measurement status
0	: Measurement completed
1	: Measurement being performed

Description

When measurement is performed by the SWP command, pressing stops the measurement.

Sample programming

To start measurement in synchronous single mode:
SWP

Related commands

TS	: Same function as SWP (no query)
SNGLS	: Starting measurement in the single mode
S2	: Starting measurement in the single mode

SYSINFOSAVE

Information Save

Outputting (saving) the parameters displayed on the System Information screen to a memory card

Function

Outputs the parameters displayed on the System Information screen to a memory card in a text-formatted file.

Command

SYSINFOSAVE

Query

None

Response

None

Description

The parameters are saved in a text-formatted file with the fixed file name “SysInfo.txt.” If this file already exists when saving, it is overwritten.

For the MT8820B, the file output destination is “/MT8820B” in the memory card.

Sample programming

To output the parameters displayed on the System Information screen to a memory card:

SYSINFOSAVE

TAGSEL

Select TAG

Selecting a tag

Function

Selects and turns a tag to be activated and displays it at the top of the window.

Command

TAGSEL screen,tag

Query

TAGSEL? screen

Response

tag

Parameters

screen	Screen name
SYSCFG	System Configuration screen
SYSINFO	System Information screen
tag	Tag
When screen is SYSCFG	
COMMON	Common tag
PHONE1	Phone-1 tag (for Phone-1)
PHONE2	Phone-2 tag (for Phone-2)
When screen is SYSINFO	
MAINTE	Maintenance Information tag
SOFT	Software Version tag
OPTION	Software Option tag
HARD	Hardware Revision tag

Description

For measurement screens, refer to the separated operation manual for the measurement software. Using the Phone-2 tag with the MT8815B results in an error.

Sample programming

To display the Phone-1 tag at the top of the System Configuration screen:
TAGSEL SYSCFG,PHONE1

To display the Software Version tag at the top of the System Information screen:
TAGSEL SYSINFO,SOFT

TIME

Time

Setting the time

Function

Sets the time. Query inquires the current time.

Command

`TIME hour,minute,second`

Query

`TIME?`

Response

`hour,minute,second`

Parameters

hour Hour
 Range = 0 to 23
minute Minute
 Range = 0 to 59
second Second
 Range = 0 to 59

Sample programming

To set the time to 14:00:00:
`TIME 14,00,00`

TITLE

Title

Setting a user-defined character string displayed in the title

Function

Sets the user-defined character string displayed in the title section.

Command

`TITLE title`

Query

`TITLE?`

Response

`title`

Parameters

`title` User-defined character string (maximum 25 characters)

 Initial value : "ANRITSU" (not initialized by Preset)

Sample programming

To display "FIRST TEST":

`TITLE "FIRST TEST" /*Setting character string*/`

`TTL USER /*Displaying user-defined character string*/`

TMCNT?

Power On Time

Querying the accumulated power-On time

Function

Queries the accumulated power-on time.

Command

None

Query

TMCNT?

Response

time

Parameters

time Accumulated time
 Response unit : min (minute)
 Resolution :10

Sample programming

To query the accumulated time:
TMCNT?

TRM

GPIB Terminator

Setting the GPIB terminator

Function

Sets the code to be added at the end of a response message.

Command

TRM terminator

Query

TRM?

Response

terminator

Parameters

terminator	GPIB terminator
0	LF
1	CR/LF
Initial value	: 0 (not initialized by Preset)

Description

This function is available only for remote control.

Sample programming

To set the GPIB terminator for Phone to CR/LF:
TRM 1

TS

Measure - Single (Synchronization)

Starting a measurement in the synchronous single mode

Function

Starts a measurement in the synchronous single mode. Processing for the next command does not start before completion of the measurement, allowing synchronization between MT8815B/MT8820B and controller.

Command

TS

Query

None

Response

None

Description

When measurement is performed by the TS command, pressing stops the measurement.

Sample programming

To start measurement in synchronous single mode:
TS

Related commands

SWP : Same function as TS (with query)
SNGLS : Starting measurement in single mode
S2 : Starting measurement in single mode

TTL

Display Title

Setting the title display type

Function

Sets the type of information to be displayed in the title display field.

Command

TTL title_type

Query

TTL?

Response

title_type

Parameters

title_type	Title display type
USER	: User-defined character string
DATE	: Date and time
OFF	: No display
Initial value	: DATE (not initialized by Preset)

Sample programming

To display a user-defined character string in the title display field:

TTL USER

WINSIZE

Window Size

Changing window size

Function

Change the active window size.

Command

WINSIZE ratio

Query

WINSIZE?

Response

ratio

Parameters

ratio	Window size
100	Full window
70	70%
50	50%
30	30%

Sample programming

To set the active window size to 50%:

```
WINSIZE 50          /*Setting the active window size to 50%*/
```

Chapter 9 Maintenance

This chapter describes the maintenance procedures such as cleaning. Keeping the MT8815B/MT8820B in optimum conditions assures accurate measurements.

9.1	Performance Test	9-2
9.1.1	Purpose and implementation timing	9-2
9.1.2	Performance test items.....	9-2
9.1.3	Required measurement equipment.....	9-2
9.1.4	Frequency stability for reference oscillator....	9-4
9.1.5	VSWR value for Main input/output connector	9-7
9.1.6	VSWR value for AUX output connector.....	9-9
9.1.7	Output frequency of the RF signal generator	9-11
9.1.8	Output level accuracy of RF signal generator	9-13
9.1.9	Non-harmonic spurious	9-16
9.1.10	Harmonics	9-18
9.1.11	Example of performance test result record sheet	9-19
9.2	Calibration.....	9-26
9.2.1	Purpose and implementation timing	9-26
9.2.2	Required measurement device	9-26
9.2.3	Calibration of reference oscillator frequency.	9-27
9.3	Cleaning.....	9-29
9.3.1	Cleaning the cabinet.....	9-29
9.3.2	Cleaning others	9-29
9.4	Storage and Transportation	9-30
9.4.1	Packing.....	9-30
9.4.2	Precautions on storage and transportation ...	9-30
9.5	Troubleshooting	9-32

9.1 Performance Test

9.1.1 Purpose and implementation timing

Implement the performance test to check the performance after reception testing, periodical testing or repair, or to maintain the performance of MT8815B/MT8820B within the specification through periodical test. It is recommended to perform the performance test once or twice a year. If any items are found to be outside of the specifications, contact the Anritsu service department.

9.1.2 Performance test items

This manual describes the following test items.

- (1) Frequency stability for reference oscillator
- (2) VSWR value for Main input/output connector
- (3) VSWR value for AUX output connector
- (4) Output frequency for RF signal generator
- (5) Output level accuracy for RF signal generator
- (6) Non-harmonic spurious
- (7) Harmonics

Note:

When the Parallelphone Measurement Software is installed, perform a similar test for Main 2 and Aux 2. Since the procedures and setup figures in this section are provided for Phone-1, read Phone-1 as Phone-2 when performing a test for Phone-2.

9.1.3 Required measurement equipment

Measurement equipment necessary for a performance test is listed in Table 9.1.3-1.

CAUTION

Warm-up the equipment to be measured and measurement equipment for at least 30 minutes unless specifically mentioned and wait until it become stable enough before starting the performance test. To demonstrate the highest measurement accuracy, implementation of the test is required at room temperature, little change in AC power voltage, and no trouble with noise, oscillation, dust or humidity.

Table 9.1.3-1 Device List for Performance Test

Performance test item	Recommended device name (Anritsu model name)	Performance required for device*
Frequency stability for reference oscillator	Frequency counter (MF2412C)	30 MHz to 2.7 GHz Resolution: 0.1 Hz External reference input (10 MHz)
	Frequency standard device	Frequency: 10 MHz Stability: $\pm 1 \times 10^{-8}$ or less
VSWR value for Main input/output connector	Network analyzer (MS4642A)	30 MHz to 2.7 GHz
	50 Ω , N-type calibration kit (3753)	DC to 3 GHz
VSWR value for AUX output connector	Network analyzer (MS4642A)	30 MHz to 2.7 GHz
	50 Ω , N-type calibration kit (3750)	DC to 2.7 GHz
Output frequency for RF signal generator	Frequency counter (MF2412C)	30 MHz to 2.7 GHz Resolution: 0.1 Hz External reference input (10 MHz)
Output level accuracy for RF signal generator	Receiver for calibration (ML2530A)	Frequency range: 30 MHz to 2.7 GHz Resolution: 1 Hz Measured electricity range: -140 to +20 dBm Measurement accuracy: ± 0.05 dB External reference input (10 MHz)
	Power meter (ML2437A)	Main unit accuracy: ± 0.02 dB Frequency range: 30 MHz to 2.7 GHz Resolution: 0.01 dB
	Power sensor (MA2472D)	Frequency range: 30 MHz to 2.7 GHz Measured electricity range: -30 to +20 dBm
Signal purity Non-harmonic spurious/harmonic	Spectrum analyzer (MS2683A)	100 kHz to 2.7 GHz

*: Some performances that cover the measurement range of test items are extracted.

9.1.4 Frequency stability for reference oscillator

This section describes test method for frequency stability of the 10 MHz crystal oscillator the reference oscillator of MT8815B/MT8820B. For frequency stability, measure the frequency change at 24 hours after turning the power On and at the ambient temperatures of 0°C and 50°C.

(1) Test object specifications

Table 9.1.4-1 Specifications for reference oscillator

Item	Specifications
Frequency	10 MHz
Activation characteristics	$\leq 5 \times 10^{-8}$ (At 10 minutes after power-On, references the 24 hours after power-On)
Aging rate	$\leq 2 \times 10^{-8}/\text{day}$ (Referencing the 24 hours after power-on)
Temperature stability	$\leq 5 \times 10^{-8}$ (0 to 50°C, referencing 25°C)

(2) Setup

Connect the equipment as shown in the figure below. Connect 10 MHz Buff Out to 10 MHz reference input connector of frequency counter on the MT8815B/MT8820B rear panel.




Fig. 9.1.4-1 Setting up the frequency stability test for reference oscillator

(3) Activation characteristics test

Note:

Perform this test on a location where the ambient temperature change is within $\pm 2^{\circ}\text{C}$ and no oscillation occurs.

[Procedure]

1. Set the frequency counter to use the external frequency standard device.
2. When 24 hours have passed after turning the MT8815B/MT8820B On, measure output frequency from the 10 MHz Buff Out of MT8815B/MT8820B using the frequency counter. The value is read to the 0.1 Hz digit (hereafter, read the value in the same manner).
3. Turn the power Off after 12 hours, and restart MT8815B/MT8820B.
4. After 10 minutes, measure the output frequency from 10 MHz Buff Out of MT8815B/MT8820B using the frequency counter.
5. Calculate the stability with the following formula.

$$\text{Frequency stability} = \frac{(\text{Second frequency counter value}) - (\text{First frequency counter value})}{(\text{First frequency counter value})}$$

(4) Aging rate test

Note:

Perform this test on a location where the ambient temperature change is within $\pm 2^{\circ}\text{C}$ and no oscillation occurs.

[Procedure]

1. Set the frequency counter to use the external frequency standard device.
2. When 24 hours have passed MT8815B/MT8820B On, measure output frequency from the 10 MHz Buff Out of MT8815B/MT8820B using the frequency counter. The value is read to the 0.1 Hz digit (hereafter, read the value in the same manner).
3. After 24 hours, measure the output frequency from 10 MHz Buff Out of MT8815B/MT8820B using the frequency counter again.
4. Calculate the stability with the following formula.

$$\text{Frequency stability} = \frac{(\text{Second frequency counter value}) - (\text{First frequency counter value})}{(\text{First frequency counter value})}$$

(5) Temperature stability test

Note:

Use a thermostat with no oscillation to perform this test.

[Procedure]

1. In the connection diagram, Fig. 9.1.4-1, install MT8815B/MT8820B in the thermostat and set its temperature at 25°C.
2. Turn MT8815B/MT8820B On and wait until internal temperature, become stable (it takes about 1.5 hours after internal temperature of the thermostat become stable).
3. After internal temperature is stable, measure the output frequency from 10 MHz Buff Out of MT8815B/MT8820B using the frequency counter. The value is read to the 0.1 Hz digit (hereafter, read the value in the same manner).
4. Set the internal temperature of the thermostat to 50°C.
5. After the internal temperatures of the thermostat and MT8815B/MT8820B are stable, measure the output frequency from 10 MHz Buff Out of MT8815B/MT8820B.
6. Calculate the stability with the following formula.

$$\text{Frequency stability} = \frac{(\text{Frequency counter value at } 50^{\circ}\text{C}) - (\text{Frequency counter value at } 25^{\circ}\text{C})}{(\text{Frequency counter value at } 25^{\circ}\text{C})}$$

7. Set the internal temperature of the thermostat to 0°C.
8. After the internal temperatures of the thermostat and MT8815B/MT8820B are stable, measure the output frequency from 10 MHz Buff Out of MT8815B/MT8820B.
9. Calculate the stability with the following formula.

$$\text{Frequency stability} = \frac{(\text{Frequency counter value at } 0^{\circ}\text{C}) - (\text{Frequency counter value at } 25^{\circ}\text{C})}{(\text{Frequency counter value at } 25^{\circ}\text{C})}$$

9.1.5 VSWR value for Main input/output connector

The test on VSWR value for Main input/output connector is described here.

(1) Test object specifications

Table 9.1.5-1 Specification of VSWR value for Main input/output connector

Item	Specification
VSWR	≤ 1.2 (Frequency ≤ 1.6 GHz)
	≤ 1.25 ($1.6 \text{ GHz} \leq \text{frequency} \leq 2.2 \text{ GHz}$)
	≤ 1.3 (Frequency > 2.2 GHz)

(2) Setup

Connect the equipment as shown in Fig. 9.1.5-1.

Note:

Confirm that the MT8815B/MT8820B RF signal output connector is set to the Main input/output connector. Settings for RF signal output connector can be checked in RF Output on the System Configuration screen.




Fig. 9.1.5-1 Main input/output connector setup for VSWR value test

(3) Test method

[Procedure]

1. Connect the N-type cable to the network analyzer for connecting with the MT8815B/MT8820B.
2. Set the start frequency of the network analyzer to 30 MHz and stop frequency to 3 GHz.
3. At the top of N-type cable, perform calibration using Open, Short and Load termination.
4. Connect N-type cable to the Main1 Input/Output of MT8815B/MT8820B.
5. Set the MT8815B/MT8820B reference level (input level) to -65 dBm. To set the reference level, refer to the operation manual for the measurement software.
6. Perform VSWR measurement, then check if the specification is satisfied.

9.1.6 VSWR value for AUX output connector

The test on VSWR value for AUX output connector is described here.

(1) Test object specifications

Table 9.1.6-1 Specification of VSWR value for AUX output connector Main input/output connector

Item	Specification
VSWR	≤ 1.3 (at SG output level ≤ -10 dBm)

(2) Setup

Connect the equipment as shown in Fig. 9.1.6-1.




Fig. 9.1.6-1 Setting up for VSWR value test of AUX output connector

Note:

Confirm that MT8815B/MT8820B RF signal output connector is set to the AUX auxiliary output connector. Setting for RF signal output connector can be checked in RF Output on the System Configuration screen.

(3) Test method

[Procedure]

1. Connect the N-SMA cable to network analyzer for connecting with MT8815B/MT8820B.
2. Set the start frequency of the network analyzer to 30 MHz and stop frequency to 3 GHz.
3. At the top of N-SMA cable, perform calibration using Open, Short and Load termination.
4. Connect SMA type cable to the AUX Output of MT8815B/MT8820B.
5. Set the MT8815B/MT8820B output level to -10 dBm to reach a state where all the internal attenuators are off. In addition, set the output frequency at 0.4 MHz, outside the band. To set the output level and output frequency, refer to the operation manual for the measurement software.
6. Perform VSWR measurement, then check if the specification is satisfied.

9.1.7 Output frequency of the RF signal generator

The test on output frequency of RF signal generator is described here. This item is a function test.

(1) Test object specification

Table 9.1.7-1 Output frequency range

Item	Specification
Output frequency range	30 to 2700 MHz

(2) Setup

Connect as shown in Fig. 9.1.7-1. Setup the PC to enable to control MT8815B/MT8820B via GPIB interface.

Note:

Confirm that MT8815B/MT8820B reference signal is set to 10 MHz of the external output. Settings for reference signal can be checked in Ref.Frequency on the System Configuration screen.




Fig. 9.1.7-1 Setting up for the output frequency test

(3) Test method

[Procedure]

1. Connect 10 MHz Buff Out of MT8815B/MT8820B to Ref Input of frequency counter.
2. Set the measurement resolution of frequency counter to 100 MHz.
3. Transmit GPIB command from PC to set the MT8815B/MT8820B output level to -10 dBm (refer to the operation manual of the measurement software for command), non-modulation CW output (command: MOD OFF).
4. Set MT8815B/MT8820B output frequency to 30 MHz.
5. Measure the MT8815B/MT8820B output frequency using the frequency counter and check if the result is 30 MHz.
6. In the same operation with the steps 4. and 5., set the output frequency at any value within the setting range. Then repeat the measurement. Refer to the Example of the performance test result record sheet for the frequency to be set.

Notes:

1. Frequency counter input connector may differ depending on the set frequency.
2. Indication of the frequency counter contains ± 1 count error .

9.1.8 Output level accuracy of RF signal generator

The test on the frequency characteristics and output level accuracy of RF signal generator is described here.

(1) Test object specification

Table 9.1.8-1 Specification of output level accuracy for RF signal generator

Item	Specification
Main1 Level accuracy	± 1.0 dB (–120 to –10 dBm, after Cal)
AUX1 Level accuracy	± 1.0 dB (–110 to 0 dBm, after Cal)
Output frequency range	30 to 2700 MHz
Main1 output level range	–140 to –10 dBm
AUX1 output level range	–130 to 0 dBm

(2) Setup

Setup differs depending on the test contents. Fig. 9.1.8-1 is a setup example for the frequency characteristics test.




Fig. 9.1.8-1 Setting up the frequency characteristics test for RF signal generator




Fig. 9.1.8-2 Setting up for the level accuracy test of RF signal generator

Fig. 9.1.8-2 shows a setup example for the output level accuracy test. Setup the PC to enable control of the MT8815B/MT8820B via GPIB interface.

Notes:

1. Confirm that the MT8815B/MT8820B RF signal output connector (Main or AUX) of measuring object. Setting for RF signal output connector can be checked in RF Output on the System Configuration screen.
2. Perform the tests (3) and (4) at the same temperature setting.

(3) Frequency characteristics test

[Procedure]

1. Setup the equipment as shown in Fig. 9.1.8-1.
2. Set MT8815B/MT8820B to the non-modulation CW output (command: MOD OFF) through GPIB control from PC.
3. Perform sensor calibration (for zero point and sensitivity) of the power sensor.
4. Execute Full Calibration of MT8815B/MT8820B.
5. Connect the power sensor directly to the MT8815B/MT8820B Main1 Input/Output.

6. Set MT8815B/MT8820B output level to -10 dBm.
7. Set the frequency for MT8815B/MT8820B to 30 MHz and the power sensor correction coefficient in the measurement frequency for the power meter.
8. Measure the output level using power meter and record the result.
9. Change the frequency and repeat the operations in steps 7. and 8.

(4) Output level accuracy test

[Procedure]

1. Setup the equipment as shown in Fig. 9.1.8-2.
2. Connect MT8815B/MT8820B 10 MHz Buff Out to the external reference input of receiver for calibration and perform the frequency synchronization.
3. Set the resolution band width of the receiver for calibration to 1 Hz and perform the calibration (error between the ranges) for receiver on each measurement frequency beforehand.
4. Set the frequency of MT8815B/MT8820B and receiver for calibration to 30 MHz.
5. Set the MT8815B/MT8820B output level to -10 dBm and measure the level using the measurement device for calibration.
6. Add the variation with level measurement value when output level of MT8815B/MT8820B is -10 dBm to the value recorded in the output level frequency characteristics test.
$$[\text{Level error}] = [\text{Level measurement value}] - [\text{Level measurement value at } -10 \text{ dBm}] + [\text{Recorded value in the above-mentioned output level frequency characteristics test at identical frequency}]$$
7. Change the output level and repeat the operations in steps 5. to 6.
8. Change the frequency and repeat the operations in steps 3. to 6.

Note:

On the performance test for AUX1; change the connection destination to AUX1, and RF Output of MT8815B/MT8820B to AUX using System Config. Then, perform the frequency characteristics measurement, and output level accuracy measurement. At that time, set the initial value of MT8815B/MT8820B output level to 0 dBm.

Calculation formula is as follows:

$$[\text{Level error}] = [\text{Level measurement value}] - [\text{Level measurement value at } 0 \text{ dBm}] + [\text{Recorded value of output level frequency characteristics test at identical frequency}]$$

9.1.9 Non-harmonic spurious

The test for non-harmonic spurious is described here.

- (1) Test object specification

Table 9.1.9-1 Specification for non-harmonic spurious

Item	Specification
Non-harmonic spurious	≤ -50 dBc

- (2) Setup

Connect the equipment as shown in Table 9.1.9-1. Setup the PC to enable control of MT8815B/MT8820B via GPIB interface.

Note:

Confirm that the MT8815B/MT8820B RF signal output connector is set to the Main input/output connector. Settings for RF signal output connector can be checked in RF Output on the System Configuration screen.





Fig. 9.1.9-1 Setting up the non-harmonic spurious test

(3) Test method

[Procedure]

1. Set MT8815B/MT8820B to the non-modulation CW output (command: MOD OFF) through GPIB control from PC.
2. Set the output level for fundamental wave and the measurement frequency to MT8815B/MT8820B.
3. Adjust the reference level to the fundamental wave as shown in the figure below.

**Fig. 9.1.9-2 Fundamental wave level**

4. Set the spectrum analyzer to the delta marker mode and move the current marker to the highest-level non-harmonics over 100 kHz of the offset frequency and perform pass/fail evaluation with the level difference.

9.1.10 Harmonics

The test for harmonics is described here.

(1) Test object specification

Table 9.1.10-1 Specification of the Harmonics

Item	Specification
Harmonics	≤ -25 dBc

(2) Setup

Connect the equipment as shown in Table 9.1.9-1. Setup the PC to enable control of MT8815B/MT8820B via GPIB interface.

(3) Test method

[Procedure]

1. Connect MT8815B/MT8820B to the non-modulation CW output (command: MOD OFF) through GPIB control from PC.
2. Set the output level for fundamental wave and the measurement frequency to MT8815B/MT8820B.
3. Set the frequency range of the spectrum analyzer from 0Hz to the value of measurement frequency $\times 3.5$.
4. Adjust the reference level to the fundamental wave as shown in Fig. 9.1.10-1.
5. Measure the level variation of the 2nd harmonics and 3rd harmonics to the fundamental wave and perform pass/fail evaluation.
6. Repeat the operations in steps 2. to 5. in the range up to 2700 MHz of measurement frequency.




Fig. 9.1.10-1 Harmonics

9.1.11 Example of performance test result record sheet

An example of the sheet to record and summarize the performance test result is provided here. Copy and use this sheet when executing the performance test.

Test location _____ Report NO. _____
 _____ Date _____
 _____ Person-in-charge _____

Device name: MT8815B/MT8820B Radio communication analyzer

Product NO. _____ Ambient temperature _____ °C
 Power frequency _____ Hz Relative humidity _____ %

Remarks _____

■ Reference oscillator frequency stability

Item	Valid lower limit	Stability	Valid upper limit	Measurement uncertainty
Activation characteristics	-5.0×10^{-8}		$+5.0 \times 10^{-8}$	$\pm 1 \times 10^{-9}$
Aging rate	-2.0×10^{-8}		$+2.0 \times 10^{-8}$	
Temperature stability (50°C)	-5.0×10^{-8}		$+5.0 \times 10^{-8}$	
Temperature stability (0°C)				

■ VSWR value for Main1 input/output connector

Connector	Frequency	VSWR measurement value	Specified max. value	Measurement uncertainty
Main1	Frequency ≤ 1.6 GHz		1.2	0.02
	$1.6 \text{ GHz} \leq \text{frequency} \leq 2.2 \text{ GHz}$		1.25	0.03
	Frequency > 2.2 GHz		1.3	0.02

■ VSWR value for AUX1 connector

Connector	VSWR measurement value	Specified max. value	Measurement uncertainty
AUX1		1.3	0.02

■ Output frequency of RF signal generator

Setting	Result	
30 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
100 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
300 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
600 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
1000 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
1500 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
2000 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
2500 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
2700 MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
Optional setting value _____MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
Optional setting value _____MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG
Optional setting value _____MHz	<input type="checkbox"/> OK	<input type="checkbox"/> NG

■ Output level accuracy of RF signal generator (Main1)

Output level frequency characteristics

Setting		Result	Measurement uncertainty
Frequency	Output level		
30 MHz	-10 dBm		±0.12 dB
1000 MHz			
2000 MHz			
2700 MHz			

Output level	Specified min. value	Result				Specified max. value	Measure-ment un-certainty
		30 MHz		1000 MHz			
		Level meas-urement	Level error	Level meas-urement	Level error		
−10 dBm	−1.0 dB					+1.0 dB	±0.3 dB
−15 dBm							
−20 dBm							
−25 dBm							
−30 dBm							
−35 dBm							
−40 dBm							
−45 dBm							
−50 dBm							
−55 dBm							
−60 dBm							
−65 dBm							
−70 dBm							
−75 dBm							
−80 dBm							
−85 dBm							
−90 dBm							
−95 dBm							
−100 dBm							
−105 dBm							
−110 dBm							
−115 dBm							
−120 dBm							

Output level	Specified min. value	Result				Specified max. value	Measurement uncertainty
		2000 MHz		2700 MHz			
		Level measurement	Level error	Level measurement	Level error		
−10 dBm	−1.0 dB					+1.0 dB	±0.3 dB
−15 dBm							
−20 dBm							
−25 dBm							
−30 dBm							
−35 dBm							
−40 dBm							
−45 dBm							
−50 dBm							
−55 dBm							
−60 dBm							
−65 dBm							
−70 dBm							
−75 dBm							
−80 dBm							
−85 dBm							
−90 dBm							
−95 dBm							
−100 dBm							
−105 dBm							
−110 dBm							
−115 dBm							
−120 dBm							

$$[\text{Level error}] = [\text{Level measurement value}] - [\text{Level measurement value at } -10 \text{ dBm}]$$

$$+ [\text{Recorded value of output level frequency characteristics test at identical frequency}]$$

■ Output level accuracy of RF signal generator (AUX1)

Output level frequency characteristics

Setting		Result	Measurement uncertainty
Frequency	Output level		
30 MHz	0 dBm		±0.12 dB
1000 MHz			
2000 MHz			
2700 MHz			

Output level	Specified min. value	Result				Specified max. value	Measurement uncertainty
		30 MHz		1000 MHz			
		Level measurement	Level error	Level measurement	Level error		
0 dBm	−1.0 dB					+1.0 dB	±0.3 dB
−5 dBm							
−10 dBm							
−15 dBm							
−20 dBm							
−25 dBm							
−30 dBm							
−35 dBm							
−40 dBm							
−45 dBm							
−50 dBm							
−55 dBm							
−60 dBm							
−65 dBm							
−70 dBm							
−75 dBm							
−80 dBm							
−85 dBm							
−90 dBm							
−95 dBm							
−100 dBm							
−105 dBm							
−110 dBm							

Output level	Specified min. value	Result				Specified max. value	Measurement uncertainty
		2000 MHz		2700 MHz			
		Level measurement	Level error	Level measurement	Level error		
0 dBm	−1.0 dB					+1.0 dB	±0.3 dB
−5 dBm							
−10 dBm							
−15 dBm							
−20 dBm							
−25 dBm							
−30 dBm							
−35 dBm							
−40 dBm							
−45 dBm							
−50 dBm							
−55 dBm							
−60 dBm							
−65 dBm							
−70 dBm							
−75 dBm							
−80 dBm							
−85 dBm							
−90 dBm							
−95 dBm							
−100 dBm							
−105 dBm							
−110 dBm							

$$[\text{Level error}] = [\text{Level measurement value}] - [\text{Level measurement value at 0 dBm}]$$

$$+ [\text{Recorded value of output level frequency characteristics test at identical frequency}]$$

■ Non-harmonics spurious

Setting		Result	Specified max. value	Measurement inaccuracy
Frequency	Fundamental wave output level	Non-harmonics		
30 MHz	_____dBm		≤ -50 dBc	± 3.0 dB
100 MHz				
300 MHz				
600 MHz				
1000 MHz				
1500 MHz				
2000 MHz				
2500 MHz				
2700 MHz				

■ Harmonics

Setting		Result		Specified max. value	Measurement uncertainty
Frequency	Fundamental wave output level	2nd harmonics	3rd harmonics		
30 MHz	_____dBm			-25 dBc	± 5.0 dB
100 MHz					
300 MHz					
600 MHz					
1000 MHz					
1350 MHz			-----		

9.2 Calibration

9.2.1 Purpose and implementation timing

Perform calibration periodically to prevent MT8815B/MT8820B from deteriorating. Perform calibration once or twice a year. If the specifications are not satisfied even after the calibration, contact the Anritsu service department.

9.2.2 Required measurement device

Measurement devices required for the performance test are shown in Table 9.2.2-1.

CAUTION

Warm-up the equipment to be measured and measurement equipment for at least 30 minutes unless specifically mentioned and wait until it become stable enough before starting the performance test. To demonstrate the highest measurement accuracy, implementation of the test is required at room temperature, little change in AC power voltage, and no troubles with noise, oscillation, dust or humidity.

Table 9.2.2-1 Device list for calibration

Calibration item	Recommended device name (Anritsu model name)	Performance required for device*
Calibration for reference oscillator frequency	Frequency counter (MF2412C)	Set range: 100 kHz to 3 GHz Resolution: 0.1 Hz External reference input: 10 MHz
	Frequency standard device	Frequency: 10 MHz Stability: $\pm 1 \times 10^{-9}$ or less
	PC	Ability for controlling GPIB command

*: Some parts of the performance covering the measurement range of the calibration items are extracted.

9.2.3 Calibration of reference oscillator frequency

The calibration method of the reference oscillator frequency using the frequency counter is described. 10 MHz reference oscillator stability of MT8815B/MT8820B is 2×10^{-8} /day. As a frequency standard device, use a standard signal generator that receives standard radio waves or sub-carrier (signal locked to the rubidium atom standard device) of higher stability and generates a signal locked to the radio waves or sub-carrier.

(1) Calibration specification

Table 9.2.3-1 Specifications for reference oscillator

Item	Specification
Frequency	10 MHz
Activation characteristics	$\leq 5 \times 10^{-8}$ (At 10 minutes after power-On, references the 24 hours after power-On)
Aging rate	$\leq 2 \times 10^{-8}$ /day (References the 24 hours after power-On)
Temperature stability	$\leq 5 \times 10^{-8}$ (0 to 50°C, references 25°C)

(2) Setup

Connect the equipment as shown in Table 9.2.3-1. Setup the PC to enable control of MT8815B/MT8820B via GPIB interface.




Fig. 9.2.3-1 Setting up for reference oscillator calibration

(3) Calibration method

[Procedure]

1. Warm up the reference oscillator by setting the MT8815B/MT8820B to the standby status for 24 hours.
2. After 24 hours, turn MT8815B/MT8820B On.
3. Input the standard frequency to the external reference input of the frequency counter.
4. Set MT8815B/MT8820B to the reference oscillator frequency calibration mode with GPIB control.
5. Set MT8815B/MT8820B as in the following table

Item	Specification
Signal generator frequency	1000.000000 MHz
Output level	-10 dBm
Modulation	Off

6. Adjust the trimmer for calibration (Freq Adjust on the MT8815B/MT8820B rear panel) so that frequency counter indicates the value 1000.000000 MHz \pm 10 Hz.

9.3 Cleaning

Before starting to clean the MT8815B/MT8820B, be sure to turn the main power switch on the rear panel Off and disconnect the power plug from the power source.

9.3.1 Cleaning the cabinet

Clean the cabinet surface, as follows:

- (1) Wipe the cabinet surface with a clean, soft, dry cloth.
- (2) When the cabinet is severely stained with dust or particles or is to be stored for a long time, wipe its surface with a cloth moistened with thinned neutral detergent and then wipe with a clean, soft, dry cloth.
- (3) If any screws anchoring the components are loosened, tighten them using the specified tool (s).

CAUTION

For cabinet cleaning, do not use benzene, thinner, or alcohol. They may damage the cabinet painting or cause cabinet deformation or discoloration.

9.3.2 Cleaning others

Avoid dust or particles from accumulating on the MT8815B/MT8820B and its surroundings. If water drops, etc. from on the power plug or connector, turn the main power switch (on rear panel) Off and wipe the power plug or connector with a dry cloth.

WARNING

1. **Remove dust, etc. accumulated on the outlet periodically. Accumulated dust on the electrodes may cause tracking phenomena resulting in fire.**
 2. **Remove dust, etc. around the fan so as not to obstruct ventilation holes. Obstructed ventilation holes may cause the internal temperature to rise, resulting in fire.**
-

9.4 Storage and Transportation

9.4.1 Packing

When packing the MT8815B/MT8820B, use of the original packing materials at shipment. If you use any other cushioning materials, perform the following steps:

[Procedures]

1. Wrap MT8815B/MT8820B in a plastic bag.
2. Prepare a corrugated cardboard box, wooden box or aluminum case large enough to put the cushioning materials on each side of MT8815B/MT8820B.
3. Put the cushioning materials around MT8815B/MT8820B. Check that MT8815B/MT8820B is horizontally positioned with no space to move inside the box.
4. Anchor the box with packing rope, adhesive tape, or belt, etc.

9.4.2 Precautions on storage and transportation

When storing or transporting the MT8815B/MT8820B, satisfy the following environmental conditions:

- Little vibration
- Temperature: 0 to 30°C
- Humidity: 40 to 80%
- Little temperature/humidity changes throughout the day

Avoid storing or transporting the MT8815B/MT8820B in any of the following environmental conditions:

- × Where it is exposed to strong vibration
- × Where it is exposed to direct sunlight
- × Where it is exposed to dust
- × Where the temperature falls out of the -20 to +60°C range
- × Where the humidity is 85% or more
- × Where condensation may occur due to high humidity
- × Where it is exposed to active gases
- × Where the components may be oxidized

Note:

Store the MT8815B/MT8820B after cleaning the dust, finger prints, stains and other accumulated dirt.

CAUTION

1. Do not move the MT8815B/MT8820B with the power turned On. This may damage the internal circuits and result in fire, electric shock and/or failure.
 2. Carry the MT8815B/MT8820B with the grips provided on both sides of it, and keep it in a horizontal position while you are transporting it. Carrying the MT8815B/MT8820B with only one of the grips while inclining it, may cause excessive force on the internal precision parts, which may be damaged as a result.
 3. The MT8815B/MT8820B should be carried by two or more persons or placed on a cart. The MT8815B/MT8820B is too heavy for one person to carry. Doing so burdens the waist, and may result in an injury. Avoid strong vibrations when loading the MT8815B/MT8820B onto a cart.
-

9.5 Troubleshooting

Refer to this section if the MT8815B/MT8820B does not work properly. When your trouble is not described in this section or not solved even if an action is taken, contact Anritsu Service and Sales offices at the address at the end of paper-edition manual or the separate file of CD-edition manual. For measurement, refer to the operation manual for the measurement software or optional device.

Phenomenon	Probable cause	Action
The power is not turned on.	The power cord is not connected properly, or pulled out of the plug or inlet.	Connect the power cord correctly.
	The main power switch on the rear panel is not On.	Press the main power switch to turn On.
	The power switch is not pressed properly.	Press the power switch for more than one second.
When 2 minutes or more lapsed after the power was turned On, the initialization screen does not change.		Turn the power Off once and turn it On again. If the same error recurs, turn the power Off and contact an Anritsu service center.
Nothing is displayed on the LCD.	A command to turn Off the LCD power is transmitted by the remote control.	Transmit a command to turn LCD power On.
A parameter cannot be set.	The setting window is not activated.	Press Focus to activate the setting window.
	Outside of the parameter setting range.	Specify the value within the parameter setting range.
	The setting conditions are not satisfied.	Check the parameter setting range.
A window is not displayed.	A window is not activated.	Press Focus to activate the window to be displayed.
	A common screen is displayed.	A window is not displayed on the common screen.
A function menu cannot be found.	A function menu is displayed on other menu page.	Switch the page by pressing Next .
	The displayed screen or window is not correct.	Open a screen or window that can display a menu.

Phenomenon	Probable cause	Action
<ul style="list-style-type: none"> • A parameter file cannot be saved or read out. • Hard copy cannot be taken. • Software cannot be Installed. 	A memory card is not inserted or wrongly inserted.	Correctly insert the memory card to the memory card slot.
	The memory card is not formatted.	Format a memory card to MS-DOS format at PC or other devices beforehand to use.
	A file to be overwritten is a read-only file.	Release read-only attribute of the file to be overwritten at PC or other devices.
	1000 files already exist in the directory of save destination.	Delete unnecessary files at PC or other devices.
	The attached memory card is not used.	Please use an attached memory card.
A saved parameter file is not displayed on the screen.		Execute F6 "Reload Media Information" in the function menu.
A call cannot be connected.	RF signal output connector is wrong.	Check if the setting of RF Output on the System Configuration screen is in conformance with the connector being used.
	The parameter setting for MT8815B/MT8820B is wrong.	Refer to the operation manual of the measurement software.
	A phone is not ready.	Refer to the operation manual of the phone for connection.
The panel key is not operated.	MT8815B/MT8820B is in the remote control mode.	Press Local to return to the manual control mode.
A message, "Out of range" is displayed when attempting to set a parameter.	The parameter is out of specified range.	Set the parameter to the value within the range.
A message, "Prohibited when <i>Parameter</i> is <i>X</i> " is displayed when attempting to set a parameter.	The Parameter cannot be set when the value is <i>X</i> .	Check the setting condition and set the Parameter value to other than <i>X</i> .
A message, "Call has dropped" is displayed.	The status does not allow demodulation a signal of the phone.	Check the parameter setting or measurement signal status.

Phenomenon	Probable cause	Action
Remote control mode cannot be set.	GPIB address is wrong.	Perform the same setting for GPIB Address on the System Configuration screen and the controller.
	GPIB cable or serial cable is not correctly connected.	Connect the cable correctly based on the network conditions.
	GPIB board for PC is not correctly set up.	Refer to the operation manual of the GPIB board being used.
	The remote interface is wrong (MT8815B only).	Check if the setting of Connect to Controller on the System Configuration screen is in conformance with the remote interface being used.
The displayed value is different from the response value.	Response unit is different from the display unit.	Check the response unit.
A message, "Undefined command" is displayed and an error occurs for transmitted command.	The transmitted command is undefined.	Check if the character string of the command header part is correct.
A message, "Invalid numeric data" is displayed and an error occurs for transmitted command.	A character string is assigned to the parameter for a numeric value to be assigned.	Assign correct numeric values in the parameter.
A message, "Invalid string data" is displayed and an error occurs for transmitted command.	Undefined numeric value or character string is assigned to the parameter for a reserved word to be assigned.	Assign a corrected reserved word in the parameter.
A message, "Invalid unit" is displayed and an error occurs for transmitted command.	The specified unit is invalid.	Check the unit.
A message, "Insufficient data" is displayed and an error occurs for transmitted command.	A parameter that cannot be omitted is omitted.	Specify the parameter.
A message, "Out of range" is displayed and an error occurs for transmitted command.	The specified parameter is out of specified range.	Check the parameter range.
An error occurs for transmitted command.	Parameter setting conditions are not satisfied.	Check the parameter setting conditions.